

NAC1 Genset Control Software Version 2.0





WARNING

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.



CAUTION

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

Important definitions



WARNING

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.



CAUTION

indicates a potentially hazardous situation that, if not avoided, could result in damage to equipment.



NOTE

Provides other helpful information that does not fall under the warning or caution categories.

SEG reserves the right to update any portion of this publication at any time. Information provided by SEG is believed to be correct and reliable. However, no responsibility is assumed by SEG unless otherwise expressly undertaken.

© SEG
All Rights Reserved.

Revision History

Rev.	Date	Editor	Change
NEW	05-09-xx	TP	Release based on 37218A-draft01

Content

1	General Information	7
1.1	Related Documents.....	7
1.2	Overview	8
2	NAC1 Series Overview	9
3	Electrostatic Discharge Awareness	10
4	Housing.....	11
4.1	Dimensions/Panel Cut-Out	11
4.2	Installation	12
5	Wiring Diagrams	13
6	Connections	17
6.1	Terminal Arrangement.....	17
6.2	Power supply	18
6.3	Charging Alternator	18
6.4	Voltage Measuring	19
6.4.1	Voltage Measuring: Generator.....	20
6.4.2	Voltage Measuring: Mains, [M-L], [M-H].....	22
6.5	MPU (Pickup) [G-H], [M-H].....	24
6.6	Discrete Inputs.....	25
6.6.1	Discrete Inputs: Bipolar Signals.....	25
6.6.2	Discrete Inputs: Operation Logic	26
6.7	Relay Outputs	27
6.8	Interfaces	28
6.8.1	Overview.....	28
6.8.2	CAN Bus - [G-H], [M-H].....	29
6.8.3	FL-CABLE-RS232 - Direct Configuration Cable.....	30
7	Operation and Navigation.....	31
7.1	Operation and Display	32
7.1.1	Purpose of the Status LEDs	32
7.1.2	Operating the NAC 1	32
7.1.3	Acknowledging Alarm Messages.....	32
7.1.4	Configuring the NAC 1	33
7.1.5	Display of the Operating Values	33
7.1.6	Cycling Through the Displayed Operating Values	34
7.1.7	J1939 Visualisation [G-H], [M-H]	36
7.1.8	Alarm Messages	38
7.1.9	Configuration Displays	41
8	Functional Description.....	44
8.1	Overview	44
8.2	Application Modes	45
8.2.1	Application Mode {1 breaker open/close} – [G-L], [G-H], [M-L], [M-H].....	45
8.2.2	Application Mode {2 breakers open/close} – [M-L], [M-H].....	45
8.3	Operating Modes.....	46
8.3.1	Operating Mode STOP	46
8.3.2	Operating Mode MANUAL.....	47
	Operating Mode AUTOMATIC	51
8.4	Breaker Closure Limits	55
8.4.1	Generator Circuit Breaker	55
8.4.2	Mains Circuit Breaker.....	55
8.5	Functional Description of the Oil Pressure Input DI1	56
8.6	Firing Speed Detection	57
8.7	Functional Description of the Charging Alternator Input/Output.....	58
8.8	Functional Description of the 2 nd . CB Close Delay Time	59
8.9	Functional Description of the Engine Released Signal.....	60
9	Configuration	61
9.1	Restoring Default Values	61

9.1.1	Resetting Via the Front Panel	61
9.1.2	Resetting Via FL-SOFT3	61
9.2	Configuration Via the Front Panel	61
9.3	Configuration Using the PC	62
9.4	Editing the Configuration File	63
9.5	Configuring the Flags	63
10	Parameters	65
10.1	Measuring	66
10.2	Application	67
10.3	Engine	68
10.3.1	Engine: Diesel.....	68
10.3.2	Engine: Pickup	68
10.3.3	Engine: Start/Stop Automatic.....	69
10.4	Breaker	70
10.5	Emergency Power (AMF)	70
10.6	Monitoring	71
10.6.1	Monitoring: Generator.....	71
10.6.2	Monitoring: Generator Overfrequency	71
10.6.3	Monitoring: Generator Underfrequency.....	72
10.6.4	Monitoring: Generator Overvoltage	73
10.6.5	Monitoring: Generator Undervoltage.....	74
10.6.6	Monitoring: Mains	75
10.6.7	Monitoring: Mains Failure Limits	75
10.6.8	Monitoring: Engine Overspeed	77
10.6.9	Monitoring: Engine Underspeed	78
10.6.10	Monitoring: Engine Start Fail	79
10.6.11	Monitoring: Engine Unintended Stop	79
10.6.12	Monitoring: Battery Undervoltage.....	80
10.6.13	Monitoring: Battery Charge Voltage	81
10.6.14	Monitoring: Interface	82
10.7	Discrete Inputs	83
10.8	Relay Outputs	84
10.9	Counter.....	85
10.10	Interfaces.....	86
10.10.1	CAN Interface.....	86
10.10.2	J1939	86
10.11	System	87
10.11.1	Factory Settings	87
10.11.2	Parameter Access Level	87
10.11.3	Flags	88
10.11.4	Versions	89
11	Event Logger	90
11.1	GetEventLog Software	90
11.1.1	Installing GetEventLog	90
11.1.2	Starting GetEventLog	90
11.1.3	Resetting the Event Logger	91
12	Technical Data	92
13	Accuracy	94
Common.....		95
13.1	Alarm Classes	95
13.2	Conversion Factors	96
13.2.1	Conversion factors: Temperature.....	96
13.2.2	Conversion factors: Pressure	96
J1939 Protocol Descriptions		96
13.3	J1939 Measuring Values.....	96
13.3.1	J1939 Standard Measuring Values	96
13.3.2	Special EMR messages.....	97
13.3.3	Special S6 messages	97
Front Customisation		98
Troubleshooting.....		99
List of Parameters.....		104

Illustrations and Tables

Illustrations

Figure 4-1: Housing - panel cut-out	11
Figure 5-1: Wiring diagram - NAC1-G-L	13
Figure 5-2: Wiring diagram - NAC1-G-H	14
Figure 5-3: Wiring diagram - NAC1-M-L	15
Figure 5-4: Wiring diagram - NAC1-M-H	16
Figure 6-1: NAC1 back view - terminal arrangement	17
Figure 6-2: Power supply	18
Figure 6-3: Charging alternator input/output	18
Figure 6-4: Voltage measuring - generator 3Ph 4W	20
Figure 6-5: Voltage measuring - generator 3Ph 3W	20
Figure 6-6: Voltage measuring - generator 1Ph 3W	20
Figure 6-7: Voltage measuring - generator 1Ph 2W	21
Figure 6-8: Voltage measuring - mains 3Ph 4W	22
Figure 6-9: Voltage measuring - mains 3Ph 3W	22
Figure 6-10: Voltage measuring - mains 1Ph 3W	22
Figure 6-11: Voltage measuring - mains 1Ph 2W	23
Figure 6-12: MPU - principle overview	24
Figure 6-13: MPU input	24
Figure 6-14: Minimum required input voltage depending on frequency	24
Figure 6-15: Discrete inputs - alarm/control input - positive signal	25
Figure 6-16: Discrete inputs - alarm/control input - negative signal	26
Figure 6-17: Discrete inputs - alarm/control inputs - operation logic	26
Figure 6-18: Relay outputs	27
Figure 6-19: Interfaces - overview	28
Figure 6-20: Interfaces - CAN bus	29
Figure 6-21: Interfaces - CAN bus - wiring of shielding	29
Figure 6-22: Interfaces - CAN bus - schematic wiring and termination	29
Figure 7-1: Front panel and display	31
Figure 7-2: 6 digit 7 segment LED display	33
Figure 7-3: J1939 fault display	37
Figure 7-4: Additional alarm display	38
Table 7-5: Configuration displays	43
Figure 8-2: Discrete input DI1 - oil pressure	56
Figure 8-3: Starting procedure	56
Figure 8-4: Charging alternator input/output	58
Figure 8-5: AMF application with engine released signal	60
Figure 9-1: Configurable display flags	63
Figure 9-2: Flag configuration default	64
Figure 9-3: Flag configuration custom	64
Figure 10-1: Voltage/frequency hysteresis	76
Figure 10-2: Configurable display flags	88
Figure 11-1: GetEventLog - interface configuration	90
Figure 11-2: GetEventLog - event logger content	91
Figure 13-1: Paper strips	98

Tables

Table 1-1: Manual - overview	7
Table 2-1: NAC1 series product features	9
Table 4-1: Housing - panel cut-out	11
Table 6-1: Power supply - terminal assignment	18
Table 6-2: Charging alternator input/output - terminal assignment.....	18
Table 6-3: Voltage measuring principles	19
Table 6-4: Voltage measuring - terminal assignment - generator voltage	21
Table 6-5: Voltage measuring - terminal assignment - mains voltage	23
Table 6-6: MPU - terminal assignment	24
Table 6-7: Discrete input - terminal assignment - alarm/control input - positive signal	25
Table 6-8: Discrete input - terminal assignment - alarm/control inputs - negative signal	26
Table 6-9: Relay outputs - terminal assignment, part 1	27
Table 6-10: Relay outputs – configurable parameters.....	27
Table 6-11: Interfaces - connection overview	28
Table 6-12: Maximum CAN bus length.....	30
Table 7-1: Display of operating values	35
Table 7-2: J 1939 messages.....	37
Table 7-3: Alarm classes.....	38
Table 7-4: Alarm messages	40
Table 8-1: Functional description - Overview	44
Table 8-1: Discrete input DI1 - oil pressure	56
Table 10-1: Relay outputs - list of configurable parameters	84
Table 11-1: Event logger - operation states	91

1 General Information

1.1 Related Documents

Type	English	German	
NAC1 Series			
NAC1 – Manual	this manual ⇄	37350	-
Additional Manuals			
FL-SOFT3 – User Manual PC program for configuration, parameter visualisation, remote control, data logging, language upload, alarm and user management, and event recorder management. This manual describes the use of FL-SOFT3 software.	37305	GR37305	
FL-SOFT3 – Engineering Manual PC program for configuration, parameter visualisation, remote control, data logging, language upload, alarm and user management, and event recorder management. This manual describes the programming of FL-SOFT3 software.	37306	GR37306	

Table 1-1: Manual - overview

2 NAC1 Series Overview

The **NAC1** Series consists of four models which are intended for different applications and requirements. This manual covers all available versions of the **NAC1** Series. Please take information about the differences between the units from this section.

Functionality \ NAC 1	[G-L]	[G-H]	[M-L]	[M-H]
Generator measurement	✓	✓	✓	✓
Mains measurement	-	-	✓	✓
GCB	✓	✓	✓	✓
MCB	-	-	✓	✓
MPU (pickup) Input	-	✓	-	✓
CAN bus (J 1939 protocol)	-	✓	-	✓

Table 2-1: **NAC1** series product features



NOTE

Some parameters of the **NAC1** Series can only be configured using the FL-CABLE-RS232 and a notebook/PC with the software FL-SOFT3. These parameters are indicated with an FL in the parameter description under Parameters starting from page 65 and can not be configured at the unit directly.

The configuration with FL-SOFT3 via the FL-CABLE-RS232 is described under Configuration Using the PC on page 62.

The FL-CABLE-RS232 is not part of the **NAC1** shipment and sold separately.



IMPORTANT NOTE ABOUT COUNTERS

The counters for

- Operation hours
- Maintenance Interval
- Number of starts

can be recalibrated with FL-SOFT3 and the configuration files belonging to the unit. If 3rd party users are not allowed to change these values, you can easily remove the parameters which enable changing the counters by editing the FL-SOFT3 configuration files as described under Editing the Configuration File on page 63.

3 Electrostatic Discharge Awareness

All electronic equipment is static-sensitive, some components more than others. To protect these components from static damage, you must take special precautions to minimise or eliminate electrostatic discharges.

Follow these precautions when working with or near the control.

1. Before performing maintenance on the electronic control, discharge the static electricity on your body to ground by touching and holding a grounded metal object (pipes, cabinets, equipment, etc.).
2. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
3. Keep plastic, vinyl, and Styrofoam materials (such as plastic or Styrofoam cups, cup holders, cigarette packages, cellophane wrappers, vinyl books or folders, plastic bottles, and plastic ash trays) away from the control, the modules, and the work area as much as possible.
4. **Opening the control cover may void the unit warranty.**
Do not remove the Printed Circuit Board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Ensure that the device is completely de-energised (all connectors must be disconnected).
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, connectors, or components with conductive devices with your hands.
 - When replacing a PCB, keep the new PCB in the protective antistatic bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the protective antistatic bag.



CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

4 Housing

4.1 Dimensions/Panel Cut-Out




Figure 4-1: Housing - panel cut-out

Description		Dimension	Tolerance
Height	Total	158 mm	—
	Panel cut-out	138 mm	+ 1.0 mm
	Housing dimension	136 mm	
Width	Total	158 mm	—
	Panel cut-out	138 mm	+ 1.0 mm
	Housing dimension	136 mm	
Depth	Total	40 mm	—


Table 4-1: Housing - panel cut-out

4.2 Installation

For installation into a door panel, proceed as follows:


1. **Panel cut-out**

Cut out the panel according to the dimensions in Figure 4-1.




2. **Remove terminals**

Loosen the wire connection terminal screws on the back of the unit and remove the wire connection terminal strips if required (1).



3. **Loosen clamping screws**

Loosen the four clamping screws (1) until they are almost flush with the clamp inserts and tilt the clamp inserts down by 45° (2) to remove them from the housing. Do not completely remove the screws from the clamp inserts.




4. **Insert unit into cut-out**

Insert the unit into the panel cut-out. Verify that the unit fits correctly in the cut-out. If the panel cut-out is not big enough, enlarge it accordingly. Ensure that the gasket is placed properly if used. Ensure that the paper strip is not pinched between gasket and panel to maintain isolation.


5. **Attach clamp inserts**

Re-install the clamp inserts by tilting the insert to a 45° angle (1). Insert the nose of the insert into the slot on the side of the housing. Raise the clamp insert so that it is parallel to the control panel (2).




6. **Tighten clamping screws**

Tighten the clamping screws (1) until the control unit is secured to the control panel (2). Over tightening of these screws may result in the clamp inserts or the housing breaking. Do not exceed the recommended tightening torque of 0.1 Nm.



7. **Reattach terminals**

Reattach the wire connection terminal strips (1) and secure them with the side screws.



Note: If the gasket is damaged, it needs to be replaced. Use only the original gasket kit for replacement.

5 Wiring Diagrams




Figure 5-1: Wiring diagram - NAC1-G-L




Figure 5-2: Wiring diagram - NAC1-G-H




Figure 5-3: Wiring diagram - NAC1-M-L




Figure 5-4: Wiring diagram - NAC1-M-H

6 Connections

6.1 Terminal Arrangement




Figure 6-1: NAC1 back view - terminal arrangement

6.2 Power supply




Figure 6-2: Power supply

Terminal	Description	A _{min}
1	0 Vdc reference potential	2.5 mm ²
2	6.5 to 32.0 Vdc	2.5 mm ²

Table 6-1: Power supply - terminal assignment

For a proper operation of the device, a minimum initial voltage of 10.5 Vdc is necessary when switching on the *NAC1*. After this, a continuous operating voltage between 6.5 and 32 Vdc is possible to operate the *NAC1* safely. The control unit is capable of handling voltage drops to 0 V for a maximum of 10 ms.



CAUTION

Ensure that the engine will be shut down by an external device in case the power supply of the *NAC1* control unit fails. Failure to do so may result in damages to the equipment.

6.3 Charging Alternator




Figure 6-3: Charging alternator input/output

Terminal	Description	A _{min}
2	Battery B+	2.5 mm ²
3	Charging alternator input D+ 24 Vdc	2.5 mm ²
4	Charging alternator input D+ 12 Vdc	2.5 mm ²

Table 6-2: Charging alternator input/output - terminal assignment



CAUTION

Terminal 3 must be used for charging voltages exceeding 16 Volts. Connecting the terminals 3 and 4 incorrectly, may result in damage to the unit.



NOTE

The charging alternator D+ acts as an output for pre-exciting the charging alternator during engine start-up only. During regular operation, it acts as an input for monitoring the charging voltage. Refer to Firing Speed Detection on page 57 for more information.

6.4 Voltage Measuring

The *NAC1* Series allows the use of different voltage measuring methods for generator and mains voltage depending on the model. These are described in the following text.

Measuring method	Description
3Ph 4W	Measurement is performed Line-Neutral (WYE connected system). Phase voltages and the neutral must be connected for proper calculation. The measurement, display and protection are adjusted according to the rules for WYE or delta connected systems. Monitoring refers to the following voltages: <ul style="list-style-type: none"> • V_{-112^*}, V_{-123^*} and V_{-131^*} or • V_{-11N^*}, V_{-12N^*} and V_{-13N^*}.
3Ph 3W	Measurement is performed Line-Line (Delta connected system). Phase voltages must be connected for proper calculation. The measurement, display and protection are adjusted according to the rules for Delta connected systems. Monitoring refers to the following voltages: <ul style="list-style-type: none"> • V_{-112^*}, V_{-123^*}, V_{-131^*}.
1Ph 2W	Measurement is performed for single-phase systems. The measurement, display and protection are adjusted according to the rules for single-phase systems. Monitoring refers to the following voltages: <ul style="list-style-type: none"> • V_{-11N^*}.
1Ph 3W	Measurement is performed for single-phase systems. The measurement, display and protection are adjusted according to the rules for single-phase systems. Monitoring refers to the following voltages: <ul style="list-style-type: none"> • V_{-11N^*}, V_{-13N^*}.

Table 6-3: Voltage measuring principles

The above described voltage measuring methods are shown with appropriate wiring examples for the different models for generator and mains voltage measuring in Figure 6-4 to Figure 6-11.



NOTE

Please note that not all measuring methods can be performed with all models of the *NAC1* Series. The methods of measurement are indicated in the wiring diagrams for the respective models.



NOTE

FL-SOFT3 and a FL-CABLE-RS232 are required to configure the voltage measuring methods for all versions of the *NAC1* Series.

6.4.1 Voltage Measuring: Generator

a.) Voltage Measuring: Generator 3Ph 4W, [G-H], [M-H]




Figure 6-4: Voltage measuring - generator 3Ph 4W

b.) Voltage Measuring: Generator 3Ph 3W, [G-H], [M-H]




Figure 6-5: Voltage measuring - generator 3Ph 3W

c.) Voltage Measuring: Generator 1Ph 3W, [G-H], [M-H]




Figure 6-6: Voltage measuring - generator 1Ph 3W

d.) Voltage Measuring: Generator 1Ph 2W, [G-L], [G-H], [M-L], [M-H]




Figure 6-7: Voltage measuring - generator 1Ph 2W

Terminal	Description		A_{max}
29	Generator voltage - phase L3	480 Vac	2.5 mm ²
31	Generator voltage - phase L2	480 Vac	2.5 mm ²
33	Generator voltage - phase L1	480 Vac	2.5 mm ²
35	Generator voltage - phase N	480 Vac	2.5 mm ²

Table 6-4: Voltage measuring - terminal assignment - generator voltage

6.4.2 Voltage Measuring: Mains, [M-L], [M-H]

a.) Voltage Measuring: Mains 3Ph 4W




Figure 6-8: Voltage measuring - mains 3Ph 4W

b.) Voltage Measuring: Mains 3Ph 3W, [M-H]




Figure 6-9: Voltage measuring - mains 3Ph 3W

c.) Voltage Measuring: Mains 1Ph 3W, [M-H]




Figure 6-10: Voltage measuring - mains 1Ph 3W

d.) Voltage Measuring: Mains 1Ph 2W, [M-H]




Figure 6-11: Voltage measuring - mains 1Ph 2W

Terminal	Description		A_{max}
21	Mains voltage - phase L3	480 Vac	2.5 mm ²
23	Mains voltage - phase L2	480 Vac	2.5 mm ²
25	Mains voltage - phase L1	480 Vac	2.5 mm ²
27	Mains voltage - phase N	480 Vac	2.5 mm ²

Table 6-5: Voltage measuring - terminal assignment - mains voltage

6.5 MPU (Pickup) [G-H], [M-H]




Figure 6-12: MPU - principle overview




Figure 6-13: MPU input

Terminal	Description	A_{max}
37	MPU input	inductive/switching
38		GND
		2.5 mm ²
		2.5 mm ²

Table 6-6: MPU - terminal assignment

i NOTE
The shield of the MPU connection cable must be connected on one side to a ground terminal of the cabinet near the NAC1. The shield must not be connected at the MPU side of the cable.

i NOTE
The input frequency of the MPU must be limited to 14 kHz.




Figure 6-14: Minimum required input voltage depending on frequency

6.6 Discrete Inputs

6.6.1 Discrete Inputs: Bipolar Signals

The discrete inputs are galvanically isolated allowing for a bipolar connection. The discrete inputs are able to handle positive or negative signals.



NOTE

All discrete inputs must use the same polarity, either positive or negative signals, due to the common ground.

a.) Discrete Inputs: Positive Signal




Figure 6-15: Discrete inputs - alarm/control input - positive signal

Terminal Term.	Com.	Description	Type ↕	A _{max}
16	15	Discrete input [D1] Low oil pressure	fixed	2.5 mm ²
17		Discrete input [D2] High coolant temperature	fixed	2.5 mm ²
18		Discrete input [D3] Remote start	fixed	2.5 mm ²
19		Discrete input [D4] Reply MCB or alarm input	SW	2.5 mm ²
20		Discrete input [D5] Reply GCB or alarm input	SW	2.5 mm ²

SW..alarm input switchable via software, if parameter "Ignore CB reply" is set to "YES"

Table 6-7: Discrete input - terminal assignment - alarm/control input - positive signal



NOTE

The parameter "Ignore CB reply" (described on page 67) may only be configured via FL-SOFT3.

b.) Discrete Inputs: Negative Signal




Figure 6-16: Discrete inputs - alarm/control input - negative signal

Terminal Com.	Term.	Description	Type ↓	A _{max}
15	16	Discrete input [D1] Low oil pressure	fixed	2.5 mm ²
	17	Discrete input [D2] High coolant temperature	fixed	2.5 mm ²
	18	Discrete input [D3] Remote start	fixed	2.5 mm ²
	19	Discrete input [D4] Reply MCB or alarm input	SW	2.5 mm ²
	20	Discrete input [D5] - Reply GCB or alarm input	SW	2.5 mm ²

SW..alarm input switchable via software, if parameter "Ignore CB reply" is set to "YES"

Table 6-8: Discrete input - terminal assignment - alarm/control inputs - negative signal

6.6.2 Discrete Inputs: Operation Logic

Discrete inputs may be configured to be used for normally open (N.O) and normally closed (N.C.) contacts. The default condition for N.O. is that the voltage signal is low. If the N.O. contact closes, the signal becomes high and the **NAC1** will detect an appropriate alarm or status. The default condition for N.C. is that the voltage signal is high. If the N.C. contact opens, the signal becomes low and the **NAC1** will detect an appropriate alarm or status.

The N.O. or N.C. contacts may be connected to the signal terminal or to the ground terminal of the discrete input. See previous chapter Discrete Inputs: Bipolar Signals on page 25 for details.




Figure 6-17: Discrete inputs - alarm/control inputs - operation logic

For the **NAC1** Series, the discrete inputs 1-3 are configured to a factory default and cannot be changed. The discrete inputs 4 and 5 are freely configurable depending on the parameter "Ignore CB reply". If this parameter is set to "YES", the discrete inputs are freely configurable, and the operation logic may be configured either to N.O. or N.C.



NOTE

The parameter "Ignore CB reply" (described on page 67) may only be configured via FL-SOFT3.

6.7 Relay Outputs

The *NAC1* Series provides up to six (6) galvanically isolated relay outputs. Some relay outputs have fixed assignments and cannot be configured.




Figure 6-18: Relay outputs

Terminal Term.	Com.	Description	A_{max}
A	B	Type ↕	
5/6	7	Relay output [R1] [M-L], [M-H] Command: open MCB	fixed 2.5 mm ²
8	9	Relay output [R2] Command: close GCB	fixed 2.5 mm ²
10	11	Relay output [R3] [M-L], [M-H] one from the configurable parameter list	2.5 mm ²
12	11	Relay output [R4] one from the configurable parameter list	2.5 mm ²
13	11	Relay output [R5] Fuel relay	fixed 2.5 mm ²
14	11	Relay output [R6] Crank	fixed 2.5 mm ²

Table 6-9: Relay outputs - terminal assignment, part 1

The following conditions, located in Table 6-10, may be assigned to the relay outputs R3 [M-L], [M-H] and R4 (refer to Relay Outputs). If a signal is selected for an *NAC1* version without this feature, the relay will not be triggered.

.generator overfrequency	.generator underfrequency	.generator overvoltage
.generator undervoltage	.mains phase rotation mismatch [M-L], [M-H]	.overspeed [G-H], [M-H]
.underspeed [G-H], [M-H]	.start fail	.unintended stop
.maintenance hours exceeded	.battery undervoltage	.charge alternator low voltage
.discrete input 1	.discrete input 2	.discrete input 3
.discrete input 4	.discrete input 5	.preglow
.mode : automatic operation	.all alarm classes	.stopping alarm
.engine released	.horn	.delayed close MCB [M-L], [M-H]
.delayed close GCB		

Table 6-10: Relay outputs – configurable parameters

6.8 Interfaces

6.8.1 Overview




Figure 6-19: Interfaces - overview

No.	Connection from ...	to ...
#1	NAC 1 [FL-CABLE-RS232 connector]	FL-CABLE-RS232
#2	FL-CABLE-RS232	PC [COM-Port]
	PIN 1	PIN 4 (connect with PIN 8)
	PIN 2	PIN 3
	PIN 3	PIN 2
	PIN 4	PIN 1
	PIN 5	PIN 5
	N/A	N/A
	PIN 7	PIN 8 (connect with PIN 4)
	PIN 8	PIN 7
	PIN 9	PIN 9
		Connect PIN4/8
#3	NAC 1 [CAN terminals]	ECU [CAN port]
	Terminal 39 - CANL	CAN-H
	Terminal 40 - CANH	CAN-L
	CAN termination resistor between terminals 39/40	CAN termination resistor

Table 6-11: Interfaces - connection overview

i NOTE
The FL-CABLE-RS232 is intended for service operation only. Do not operate the **NAC1** with the FL-CABLE-RS232 plugged into the unit during regular operation.

i NOTE
The CAN interface is only used for the visualisation of J1939 data from the ECU.

6.8.2 CAN Bus - [G-H], [M-H]

a.) Wiring




Figure 6-20: Interfaces - CAN bus

Terminal	Description	A _{max}
39	CAN bus	CAN-L 2.5 mm ²
40		CAN-H 2.5 mm ²

b.) Shielding




Figure 6-21: Interfaces - CAN bus - wiring of shielding

Please note that the CAN bus must be terminated at each end of the bus! Figure 6-22 is a schematic of the CAN bus with the termination resistors installed.




Figure 6-22: Interfaces - CAN bus – schematic wiring and termination

c.) Possible CAN Bus Problems

If no data is transmitted on the CAN bus, check the following common reasons for CAN bus communication problems:

- T structure bus is utilised
- CAN-L and CAN-H are interchanged
- Not all devices on the bus are using identical Baud rates
- Terminating resistor are missing
- Baud rate to high for wiring length

d.) Maximum CAN bus Length

The maximum length of the communication bus wiring is dependent on the configured Baud rate. Refer to Table 6-12 for the maximum bus length (Source: CANopen; Holger Zeltwanger (Hrsg.); 2001 VDE VERLAG GMBH, Berlin und Offenbach; ISBN 3-8007-2448-0).

Baud rate	Max. length
1000 kbit/s	25 m
800 kbit/s	50 m
500 kbit/s	100 m
125 kbit/s	250 m
50 kbit/s	1000 m
20 kbit/s	2500 m

Table 6-12: Maximum CAN bus length

The maximum specified length for the communication bus wiring might not be achieved if wire of poor quality is utilised, there is high contact resistance, or other conditions exist. Reducing the baud rate may overcome these issues.

6.8.3 FL-CABLE-RS232 - Direct Configuration Cable



NOTE

Please note that the configuration via the direct configuration cable FL-CABLE-RS232 is possible starting with Revision B (first delivered July 2003). If you have an older model please contact technical sales.



NOTE

The connection cables delivered with the FL-CABLE-RS232 must be used to connect between the control unit and the computer to ensure a proper function of the **NAC1**. Utilisation of an extension or different cable types for the connection between **NAC1** and FL-CABLE-RS232 can result in a malfunction of the **NAC1**. This may possibly result in damage to components of the system. If an extension of the data connection line is required, only the serial cable between FL-CABLE-RS232 and notebook/PC may be extended.

Unplug the FL-CABLE-RS232 after configuration to ensure a safe operation!

7 Operation and Navigation




Figure 7-1: Front panel and display

Figure 7-1 illustrates the front panel/display which includes push-buttons, LEDs and the alphanumeric 7 segment LED display. A short description of the front panel is given below.



NOTE




This push-button is **ALWAYS** enabled and will stop the engine when pressed.



Push-buttons

The push buttons on the front panel are assigned to fixed functions of the unit.



LEDs

The LEDs indicate operating states of the unit and alarm messages. The right LED indicates that alarm messages are present in the unit.



7 segment LED display





This alphanumeric display is used to display all measured values, operating parameters, and alarm messages. A description of this display is detailed later in this manual.

7.1 Operation and Display














7.1.1 Purpose of the Status LEDs

The **NAC1** has several status LEDs to indicate the operating state. The LEDs indicate the following conditions:








- LED 9 (on): Mains voltage present (only NAC1-M-L and NAC1-M-H)
- LED 9 (flashing): Mains voltage and/or frequency are not within the Breaker Closure Limits (see page 55)
- LED 10: Mains circuit breaker (MCB) closed (only NAC1-M-L and NAC1-M-H)
- LED 11: Generator circuit breaker (GCB) closed
- LED 12 (on): Generator in operation
- LED 12 (flashing): Generator voltage and/or frequency are not within the Breaker Closure Limits. (see page 55)
- LED 13 (on): Engine in operation
- LED 13 (flashing): Engine in operation, but engine monitoring delay time (see page 69) not yet expired
- LED 14: Alarm message present
- LED 15: Genset in automatic operation
- LED 16: Genset in manual operation
- LED 17: Genset stopped

A function test of all LEDs and the seven-segment display may be conducted by pressing the   and   buttons simultaneously.










7.1.2 Operating the NAC 1

- When the **NAC1** control unit is powered up and the genset is not operating, LED 17 is illuminated and the MCB is closed (only NAC1-M-L and NAC1-M-H).
- The control unit may be started in automatic mode or have the operation mode changed from automatic to manual by pressing the Auto - Manual button  . LED 15 (automatic) or LED 16 (manual) will indicate the current mode of operation by the corresponding LED being illuminated.
- The Breaker Control button   enables the operator to open or close the circuit breaker(s) depending on the current state of the breaker and the control unit being in manual operation mode. This button is disabled in automatic operation mode.
- The Start/Stop Engine button   will start and stop the engine when the control unit is in manual operation mode. This button is disabled when the control unit is in automatic operation mode.
- The Stop button   is always enabled and when pressed while in the automatic mode will shut the engine down after the configured cool down period has expired. Pressing this button twice will shutdown the genset immediately.
- Active alarm messages may be acknowledged with the Alarm button  . Alarm conditions are indicated when LED 14 is illuminated.
- When the **NAC1** is in normal operation, the operator may view the monitored parameters by using the Scroll button  . The monitored values will be displayed on the 7-segment display  (a detailed description of the displayed operating values may be found later in this manual).


7.1.3 Acknowledging Alarm Messages


LED 14 will flash when an alarm is active. The alarm message will be displayed in the 7-segment display . Pressing the alarm button   will acknowledge the alarm, reset the alarm relay (if relay is configured for alarm input), and the LED will change from flashing to continuously illuminated. If more than one fault condition is present, the operator may display these messages by pressing the Scroll button  . The alarm may be deleted by pressing and holding the Alarm button   a second time until the LED 14 is no longer illuminated. If the fault condition is still present, the LED 14 will remain illuminated and the unit stays in a locked mode according to the appropriate alarm condition.

7.1.4 Configuring the NAC 1

To enter the configuration mode, press the Scroll  ① and Alarm  ② buttons simultaneously. Pressing the Scroll button  ① will display the various parameters that may be changed. The displayed values for the parameters may be changed by pressing the  ⑦ and  ⑧ buttons (a detailed description of the parameters begins on page 65 of this manual). If the operator presses and holds these buttons, the rate of change for the value will increase. After the parameter has been adjusted to the desired value, enter it into the control unit by pressing the Scroll button  ① once. After a parameter has been changed and entered into the control unit, the operator may advance to the next parameters by pressing the Scroll button  ① a second time. To exit the configuration mode, press the Scroll  ① and Alarm  ② buttons simultaneously again.

7.1.5 Display of the Operating Values

The *NAC1* Series control units are able to display various measured values during operation depending on the respective *NAC1* model. You may advance through the single value displays using the Scroll button  ①.

The values are displayed numerically, while the engineering unit, source, and phase are coded in the seven-segment display  if applicable. See the example below:




Figure 7-2: 6 digit 7 segment LED display

- The first digit (counted from left) indicates what is being measured, (mains, engine, or generator). The top horizontal segment indicates mains, the middle horizontal segment indicates engine, and the bottom horizontal segment indicates generator.
- The second digit indicates the measured phase. The top segment indicates L1, the middle horizontal segment indicates L2, and the bottom horizontal segment indicates L3. If only one line is displayed for phase measurement, a phase to neutral measurement is displayed. If two lines are displayed, a phase to phase measurement is shown.
- Digits 3-6 indicate what the measured value of the displayed parameter is.
- The indicators located at the top left of the first four digits of the display indicate the engineering unit of measure to be utilised. The indicators are assigned the following engineering units of measure.
 - Digit 1: Operating hours [h]
 - Digit 2: Revolutions [rpm]
 - Digit 3: Frequency [Hz]
 - Digit 4: Voltage [V]

With this information, the example in the figure above reads as follows:

Voltage at generator between phase L2 and N is at 235.0 volts

Digit 1: Generator

Digit 2: Measurement between phase L2 and N


Digits 3 to 6: Numerical value 235.0













Indicator at digit 4: Voltage [V]

Digits 5 and 6 of the display are used to display eight different alarm states. The upper and lower vertical segments are used to indicate the various alarm states. Refer to *Alarm Messages* on page 37 for the description of the alarm messages.

For customisation of your *NAC1* front using the paper strips, refer to *Front Customisation* on page 98.



7.1.6 Cycling Through the Displayed Operating Values

If the NAC1 is in normal operation, the operator may advance through the different operating parameters using the Scroll button  ①. The parameters are displayed in the order shown below (some parameters will not display if the related function is disabled or not available on the control unit):

Parameter	Display	Applies to
Generator voltage V_{12} (phase-phase)		NAC1-MH ✓
		NAC1-ML -
		NAC1-GH ✓
		NAC1-GL -
Generator voltage V_{23} (phase-phase)		NAC1-MH ✓
		NAC1-ML -
		NAC1-GH ✓
		NAC1-GL -
Generator voltage V_{31} (phase-phase)		NAC1-MH ✓
		NAC1-ML -
		NAC1-GH ✓
		NAC1-GL -
Generator voltage Average of the phase-phase voltages (two of the three phase- phase indicators are displayed alternately)		NAC1-MH ✓
		NAC1-ML -
		NAC1-GH ✓
		NAC1-GL -
Generator voltage V_{1N} (phase voltage)		NAC1-MH ✓
		NAC1-ML ✓
		NAC1-GH ✓
		NAC1-GL ✓
Generator voltage V_{2N} (phase voltage)		NAC1-MH ✓
		NAC1-ML -
		NAC1-GH ✓
		NAC1-GL -
Generator voltage V_{3N} (phase voltage)		NAC1-MH ✓
		NAC1-ML -
		NAC1-GH ✓
		NAC1-GL -
Generator voltage Average of the phase voltages (one of the three phase indica- tors is displayed alternately)		NAC1-MH ✓
		NAC1-ML -
		NAC1-GH -
		NAC1-GL -
Mains voltage V_{12} (phase-phase)		NAC1-MH ✓
		NAC1-ML ✓
		NAC1-GH -
		NAC1-GL -
Mains voltage V_{23} (phase-phase)		NAC1-MH ✓
		NAC1-ML ✓
		NAC1-GH -
		NAC1-GL -
Mains voltage V_{31} (phase-phase)		NAC1-MH ✓
		NAC1-ML ✓
		NAC1-GH -
		NAC1-GL -
Mains voltage Average of the phase-phase voltages (two of the three phase indicators are displayed alter- nately)		NAC1-MH ✓
		NAC1-ML ✓
		NAC1-GH -
		NAC1-GL -

Parameter	Display	Applies to
Mains voltage V_{1N} (phase voltage)		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH - NAC1-GL -
Mains voltage V_{2N} (phase voltage)		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH - NAC1-GL -
Mains voltage V_{3N} (phase voltage)		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH - NAC1-GL -
Mains voltage Average of the phase voltages (one of the three phase indicators is displayed alternately)		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH - NAC1-GL -
Rated generator frequency		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH ✓ NAC1-GL ✓
Rated mains frequency		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH - NAC1-GL -
Engine speed (display is not shown if the MPU is disabled)		NAC1-MH ✓ NAC1-ML - NAC1-GH ✓ NAC1-GL -
Operating hours counter (display is six-digit with one decimal)		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH ✓ NAC1-GL ✓
Hours to next maintenance (a negative value indicates excess hours, maintenance overdue)		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH ✓ NAC1-GL ✓
Battery voltage		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH ✓ NAC1-GL ✓
Charging voltage (display is suppressed if the charging voltage monitoring is disabled)		NAC1-MH ✓ NAC1-ML ✓ NAC1-GH ✓ NAC1-GL ✓

Table 7-1: Display of operating values

If the Scroll button   is pressed again, the display returns to generator voltage V_{12} .
The display automatically returns after 180 second to generator voltage V_{12} being displayed if a button isn't pressed.

7.1.7 J1939 Visualisation [G-H], [M-H]

The *NAC1* with the X package is able to display standard J1939 messages, which are sent by the engine control to the *NAC1* via the CAN bus. The values are displayed on the unit and in FL-SOFT3. The PC/laptop running FL-SOFT3 must be connected via the FL-CABLE-RS232 (refer to page 29). It is also possible to display Scania S6 and Deutz EMR2 messages in FL-SOFT3. The J1939 visualisation can be configured with parameter **90**, J1939 device type. If this parameter is configured to Standard, the standard J1939 messages are displayed on the unit immediately following the operating values as described in the chapter Display of the Operating Values on page 34.










You find detailed information about the J1939 protocol under J1939 Protocol Descriptions starting on page 96.



NOTE

Only signals, which are present, will be displayed. If a signal is not sent to the control unit, the display of this value is not shown. If the sent values exceed the specified range, the displayed value is not defined.

The following J1939 messages can be displayed by the *NAC1*. The J1939 messages follow the operating values and can be viewed in the following order using the Scroll button  . The values are updated by pressing the scroll button.

J1939 message	Display	Range
1 Throttle position		0 to 100 % Display 000.0 SPN 91 PGN 61443
2 Percent load at current RMP		0 to 250 % Display 000 SPN 92 PGN 61443
3 Actual engine % torque		-125 to 125 % Display 0000 SPN 513 PGN 61444
4 Engine speed		0 to 8032 rpm Display 0000 SPN 190 PGN 61444
5 Total engine hours		0 to 9999 h Display 0000 SPN 247 PGN 65253
6 Engine coolant temp		-40 to 210 °C Display 000 SPN 110 PGN 65262
7 Fuel temperature		-40 to 210 °C Display 000 SPN 174 PGN 65262
8 Engine oil temperature		-273 to 1735 °C Display 0000 SPN 175 PGN 65262
9 Engine oil level		0 to 100 % Display 000 SPN 98 PGN 65263

J1939 message	Display	Range
10 Engine oil pressure		0 to 1000 kPa Display 0000 SPN 100 PGN 65263
11 Coolant level		0 to 100 % Display 000 SPN 111 PGN 65263
12 Fuel rate		0 to 3213 L/h Display 0000 SPN 183 PGN 65266
13 Barometric pressure		0 to 125 kPa Display 000 SPN 108 PGN 65269
14 Air inlet temperature		-40 to 210 °C Display 000 SPN 172 PGN 65269
15 Boost pressure		0 to 500 kPa Display 000 SPN 102 PGN 65270
16 Intake manifold temp.		-40 to 210 °C Display 000 SPN 105 PGN 65270
17 Exhaust gas temperature		-273 to 1735 °C Display 0000 SPN 173 PGN 65270

Table 7-2: J 1939 messages

In case of a defective sensor or a broken wire the **NAC1** displays four dashes instead of the J1939 value following the respective J1939 identifier.








Figure 7-3: J1939 fault display

The above display shows that the engine oil pressure (identifier 9r) sensor is defective or the cable from the sensor to the ECU is unplugged or broken. A defective sensor or a broken wire is also displayed in FL-SOFT3. The display appearing in this case is described under J1939 Protocol Descriptions starting on page 96.

7.1.8 Alarm Messages

If the NAC1 detects a fault condition, LED 14 starts to flash. The alarm message is displayed in the seven-segment display 18 with a blinking "A" for alarm, an alarm number, and the respective alarm segment, if applicable. The alarm may be acknowledged by pressing the Alarm button 2. The flashing LED and "A" will change to a continuously illuminated state and the relay will be reset. If more alarm conditions are present, the operator may advance through the different alarm messages using the Scroll button 1. By pressing the Alarm button 2 again, the alarm may be cleared unless the fault condition is still present.

Figure 7-4 shows the additional alarm states using the vertical segments of the last two digits of the seven-segment display 18. The four top segments are pre-assigned with the alarms shown in Figure 7-4, but are freely configurable via FL-SOFT3 for common alarms from a list of alarms located in Table 7-4. The customer-defined paper strip label allows for a customised front display panel. The lower four segments are permanently assigned to engine alarms (battery undervoltage (alarm no. 50A), engine over-/underspeed (no. 20A/21A), oil pressure (no. 60A), and coolant temperature (no. 61A)).

Symbol	Alarm
	Battery undervoltage
	Engine over-/underspeed
	Oil pressure
	Coolant overtemperature




Figure 7-4: Additional alarm display

The alarm messages are assigned to different alarm classes depending on their importance and required reaction. You find more information about this under Alarm Classes. on page 95. The following alarm classes exist:

Class	Description	Reaction of the system
B	Alarm	The operation is not interrupted but a centralised alarm is issued.
F	Shutdown	The GCB will be opened immediately and the engine will be stopped without cool down.

Table 7-3: Alarm classes

The following table displays the possible alarm messages:

Alarm		Alarm class	Display	Applies to							
10	Generator overfrequency	F: Shutdown		M-H	✓	M-L	✓	G-H	✓	G-L	✓
11	Generator underfrequency	F: Shutdown		M-H	✓	M-L	✓	G-H	✓	G-L	✓
12	Generator overvoltage	F: Shutdown		M-H	✓	M-L	✓	G-H	✓	G-L	✓
13	Generator undervoltage	F: Shutdown		M-H	✓	M-L	✓	G-H	✓	G-L	✓
14	Mains rotation field mismatch	B: Alarm		M-H	✓	M-L	✓	G-H	-	G-L	-
20	Engine overspeed	F: Shutdown		M-H	✓	M-L	-	G-H	✓	G-L	-
21	Engine underspeed	F: Shutdown		M-H	✓	M-L	-	G-H	✓	G-L	-
30	Start fail	F: Shutdown		M-H	✓	M-L	✓	G-H	✓	G-L	✓
31	Unintended stop	F: Shutdown		M-H	✓	M-L	✓	G-H	✓	G-L	✓
40	Maintenance hours	B: Alarm		M-H	✓	M-L	✓	G-H	✓	G-L	✓
50	battery undervoltage	B: Alarm		M-H	✓	M-L	✓	G-H	✓	G-L	✓
51	Charge failure	B: Alarm		M-H	✓	M-L	✓	G-H	✓	G-L	✓
60	DI1: Oil pressure	F: Shutdown		M-H	✓	M-L	✓	G-H	✓	G-L	✓

Alarm		Alarm class	Display	Applies to	
61	DI2: Coolant temperature	F: Shutdown		MH	✓
				ML	✓
				GH	✓
				GL	✓
62	DI4: MCB reply or free configurable	Control input/ Selectable B or F		MH	✓
				ML	✓
				GH	✓
				GL	✓
63	DI5: GCB reply or free configurable	Control input/ Selectable B or F		MH	✓
				ML	✓
				GH	✓
				GL	✓
64	J1939 CAN Error	Selectable B or F		MH	✓
				ML	-
				GH	✓
				GL	-

Table 7-4: Alarm messages



NOTE













Discrete Inputs 4 & 5: If the parameter "Ignore Breaker Replies" (only changeable via FL-SOFT3) is set to "YES", the discrete inputs for 4 and 5 are no longer control inputs. These discrete inputs may now be used as freely configurable alarm inputs. All alarm classes may be configured for these discrete inputs.

7.1.9 Configuration Displays

The following parameters can be configured as described under Configuring the on page 33:

Parameter		Range	Display	Applies to	
01 DL 1	Time until horn reset	0 to 1000 s [1 s interval]		M-H	✓
				M-L	✓
				G-H	✓
				G-L	✓
10 DL 3	Rated frequency	50 Hz, 60 Hz		M-H	✓
				M-L	✓
				G-H	✓
				G-L	✓
11 DL 3	Generator rated voltage	50 to 480 V [1 V interval]		M-H	✓
				M-L	✓
				G-H	✓
				G-L	✓
12 DL 3	Mains rated voltage	50 to 480 V [1 V interval]		M-H	✓
				M-L	✓
				G-H	-
				G-L	-
20 DL 3	Fuel relay (open/close)	0 = open to stop 1 = close to stop		M-H	✓
				M-L	✓
				G-H	✓
				G-L	✓
21 DL 3	Preglow time	0 to 999 s [1 s interval]		M-H	✓
				M-L	✓
				G-H	✓
				G-L	✓
30 DL 3	MPU (pickup) on/off	0 = off, 1 = on		M-H	✓
				M-L	-
				G-H	✓
				G-L	-
31 DL 3	Nominal speed	500 to 4000 rpm [1 rpm interval]		M-H	✓
				M-L	-
				G-H	✓
				G-L	-
32 DL 3	Number of teeth	2 to 260 teeth [1 tooth interval]		M-H	✓
				M-L	-
				G-H	✓
				G-L	-
40 DL 3	Cooldown time	0 to 999 s [1 s interval]		M-H	✓
				M-L	✓
				G-H	✓
				G-L	✓
50 DL 3	Generator overfrequency threshold	50.0 to 130.0 % [0.1 % interval]		M-H	✓
				M-L	✓
				G-H	✓
				G-L	✓
51 DL 3	Generator overfrequency delay time	0.1 to 99.9 s [0.1 s interval]		M-H	✓
				M-L	✓
				G-H	✓
				G-L	✓

DL..Display Level (parameter 72)

	Parameter	Range	Display	Applies to
52 DL 3	Generator under-frequency threshold	50.0 to 130.0 % [0.1 % interval]		MH ✓ ML ✓ GH ✓ GL ✓
53 DL 3	Generator under-frequency delay time	0.1 to 99.9 s [0.1 s interval]		MH ✓ ML ✓ GH ✓ GL ✓
54 DL 3	Generator over-voltage threshold	50.0 to 125.0 % [0.1 % interval]		MH ✓ ML ✓ GH ✓ GL ✓
55 DL 3	Generator over-voltage delay time	0.1 to 99.9 s [0.1 s interval]		MH ✓ ML ✓ GH ✓ GL ✓
56 DL 3	Generator under-voltage threshold	50.0 to 125.0 % [0.1 % interval]		MH ✓ ML ✓ GH ✓ GL ✓
57 DL 3	Generator under-voltage delay time	0.1 to 99.9 s [0.1 s interval]		MH ✓ ML ✓ GH ✓ GL ✓
58 DL 3	Engine overspeed monitoring on/off	0 = off, 1 = on		MH ✓ ML - GH ✓ GL -
59 DL 3	Engine overspeed threshold	0 to 9999 rpm [1 rpm interval]		MH ✓ ML - GH ✓ GL -
60 DL 3	Battery undervoltage threshold	8.0 to 42.0 V [0.1 V interval]		MH ✓ ML ✓ GH ✓ GL ✓
61 DL 3	Battery charge failure monitoring on/off	0 = off, 1 = on		MH ✓ ML ✓ GH ✓ GL ✓
62 DL 3	Battery charge failure monitoring threshold	0.0 to 32.0 V [0.1 V interval]		MH ✓ ML ✓ GH ✓ GL ✓
71 DL 1	Reset maintenance hours	0 = no, 1 = yes		MH ✓ ML ✓ GH ✓ GL ✓

DL..Display Level (parameter 72)

	Parameter	Range	Display	Applies to
72	Display level	1, 2, 3		M-H ✓ M-L ✓ G-H ✓ G-L ✓
DL 1				
80	Mains settling time	0 to 9999 s [1 s interval]		M-H ✓ M-L ✓ G-H - G-L -
DL 3				
81	Mains over-voltage thresh- old	50.0 to 130.0 % [0.1 % interval]		M-H ✓ M-L ✓ G-H - G-L -
DL 3				
82	Mains under-voltage thresh- old	50.0 to 130.0 % [0.1 % interval]		M-H ✓ M-L ✓ G-H - G-L -
DL 3				
83	Mains voltage hysteresis	0.0 to 50.0 % [0.1 % interval]		M-H ✓ M-L ✓ G-H - G-L -
DL 3				
84	Mains overfre- quency thresh- old	70.0 to 160.0 % [0.1 % interval]		M-H ✓ M-L ✓ G-H - G-L -
DL 3				
85	Mains under- frequency threshold	70.0 to 160.0 % [0.1 % interval]		M-H ✓ M-L ✓ G-H - G-L -
DL 3				
86	Mains fre- quency hys- teresis	0.0 to 50.0 % [0.1 % interval]		M-H ✓ M-L ✓ G-H - G-L -
DL 3				
90	J1939 Device Type	0 = Off 1 = J1939 2 = Scania S6 3 = Deutz EMR		M-H ✓ M-L - G-H ✓ G-L -
DL 3				
91	Requested Send Address	0 to 255 [1 step interval]		M-H ✓ M-L - G-H ✓ G-L -
DL 3				
92	Receive Device Number	0 to 255 [1 step interval]		M-H ✓ M-L - G-H ✓ G-L -
DL 3				
93	J1939 Monito- ring	0 = Off 1 = On		M-H ✓ M-L - G-H ✓ G-L -
DL 3				

DL..Display Level (parameter 72)

Table 7-5: Configuration displays



NOTE

The display automatically returns to generator voltage V_{12} being displayed if a button isn't pressed within 180 seconds.

8 Functional Description

8.1 Overview

	Application mode			
	{1 breaker open/close}		{2 breakers open/close }	
NAC1 Version	[G-L], [G-H], [M-L], [M-H]		[M-L], [M-H]	
Operation Mode	MAN	AUTO	MAN	AUTO

Operate the engine					
• Start engine by:					
	the engine START - STOP push button	YES	–	YES	–
	the discrete input DI3 (remote start)	–	YES	–	YES
	emergency power (AMF)	–	–	–	YES
• Stop engine by:					
	the STOP push button	YES	YES	YES	YES
	the engine START - STOP push button	YES	–	YES	–
	the discrete input DI3 (remote start)	–	YES	–	YES
	emergency power (AMF)	–	–	–	YES
	an alarm (i.e. overspeed)	YES	YES	YES	YES

Operate GCB					
• close GCB					
	the BREAKER CONTROL push button (only if engine is running)	YES	–	YES	–
	emergency power (AMF)	–	–	–	YES
• open GCB					
	the STOP push button	YES	YES	YES	YES
	the BREAKER CONTROL push button	YES	–	YES	–
	emergency power (AMF)	–	–	–	YES
	an alarm (i.e. overvoltage)	YES	YES	YES	YES

Operate MCB					
• open MCB					
	the BREAKER CONTROL push button	–	–	YES	–
	emergency power (AMF)	–	–	–	YES
• close MCB					
	the STOP push button	–	–	YES	YES
	the BREAKER CONTROL push button (only if mains are present)	–	–	YES	–
	emergency power (AMF)	–	–	–	YES


Table 8-1: Functional description - Overview

- **Application Mode** (page 45): depends on the application; defines the number/function of the breakers.
- **NAC1 Version** (page 9): indicates, which **NAC1** versions permit this application mode.
- **Operating Mode** (page 46): depends on the application; differs between STOP, MANUAL and AUTOMATIC modes.

8.2 Application Modes

The most important features of the application modes are illustrated in the following. Please note that the 2 breaker application mode is only possible with the *NAC1* versions [M-L], and [M-H].


8.2.1 Application Mode {1 breaker open/close} – [G-L], [G-H], [M-L], [M-H]



This application mode provides the following functions:

- operation of the engine (start/stop)
- monitoring and display of generator and engine parameters
- monitoring of selected parameters and protection of the generator and the engine
- opening and closing the GCB
- dead bus monitoring and logic

8.2.2 Application Mode {2 breakers open/close} – [M-L], [M-H]



This application mode provides the following functions:

- operation of the engine (start/stop)
- monitoring and display of generator and engine parameters
- monitoring of selected parameters and protection of the generator and the engine
- opening and closing the GCB
- dead bus monitoring and logic
- operating the MCB (open/close)
- emergency power (AMF automatic mains failure) operation

8.3 Operating Modes

8.3.1 Operating Mode STOP



NOTE

Selecting the operating mode STOP is not the same as an EMERGENCY STOP. In some cases the *NAC1* will perform additional logic functions, such as an engine cool down period, before the engine is stopped. It is recommended that an EMERGENCY STOP discrete input is utilised and programmed as a class F alarm (only configurable via FL-SOFT3).



In the STOP operating mode neither the engine or the power circuit breakers can be operated. The following occurs if operating mode STOP has been selected while...

...the engine is not running

1. The GCB will not close
2. The fuel solenoid relay cannot be enabled
3. The discrete inputs "Oil pressure" and "Coolant Temperature" are ignored
4. The push buttons START - STOP and BREAKER CONTROL are disabled
5. The engine/generator monitoring remains de-activated (exception: all monitoring that is not delayed by the delayed engine speed monitoring)

...the engine is running

1. The GCB will open if it is closed
2. The MCB will close if the GCB is open and mains are present
3. An engine cool down will be performed
4. The fuel solenoid relay will be disabled
5. Selected engine/generator monitoring functions (this includes under-voltage, -frequency, -speed, oil pressure) will be de-activated (exception: all monitoring that is not delayed by the delayed engine speed monitoring)

8.3.2 Operating Mode MANUAL



NOTE

You find an overview about the buttons, LEDs and the seven-segment display under Operation and Navigation on page 31.



In the MANUAL operating mode (AUTO - MANUAL button 3) the engine and the power circuit breakers are operated via the BREAKER CONTROL button 4. The LED 16 in the upper right corner of the AUTO - MANUAL button 3 indicates the manual operating mode.

You can perform the following actions in the MANUAL operating mode depending on the application mode:

a.) Application Mode {2 breakers open/close} – [M-L], [M-H]



The START - STOP button 5
Start the engine (if the engine is stopped, LED 13 is not illuminated)
Stop the engine (if the engine is running, LED 13 is illuminated)



The BREAKER CONTROL button 4
Open the GCB and close the MCB (if the control unit is in generator operation (LEDs 11 and 12 are illuminated) and mains are present, LED 9 is illuminated)
Open the MCB and close the GCB (if the control unit is in mains operation (LEDs 9 and 10 are illuminated) and engine is running, LED 13 is illuminated)

Detailed operation with 2 CBs in manual mode (mains are present)

- Preconditions:**
- Generator is stopped – LED 12 is not illuminated
 - MCB is closed – LED 10 is illuminated
 - Mains are present – LED 9 is illuminated
 - Unit is in manual mode – LED 16 is illuminated

Engine start sequence:

Action	START	Press the START - STOP button 5
Delay	Preglow time	The relay will energise the glow plugs for the time configured in the engine parameters (page 68)
Operation	Fuel relay	The fuel relay (relay 5) is energised to enable the fuel solenoid
Operation	Crank relay	The crank relay (relay 6) is energised to engage the starter – LED 12 illuminates and LED 13 starts flashing when generator speed has been detected
Delay	Engine delay time	The engine monitoring is delayed until time configured in the engine parameters (page 69) expires – LED 13 changes to steady illumination after the time expires

GCB close sequence:

Action	Breaker control	Pressing the BREAKER CONTROL button 4
Operation	Open MCB	The MCB open relay (relay 1) energises to open the MCB – LED 10 goes out
Delay	Breaker delay	The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire
Operation	Close GCB	The GCB close relay (relay 2) energises to close the GCB – LED 11 illuminates

MCB close sequence:

Action *Breaker control*
Operation *Open GCB*
Delay *Breaker delay*

Press the BREAKER CONTROL button 4

The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire

Operation *Close MCB*

The MCB open relay (relay 2) de-energises to close the MCB – LED 10 illuminates

Stop sequence via

START - STOP:

Action *STOP*
Operation *Open GCB*
Operation *Engine stop*
Action *Breaker control*
Operation *Close MCB*

Press the START - STOP button 5

The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out

The engine stops – LEDs 12 and 13 go out

Pressing the BREAKER CONTROL button 4

The MCB open relay (relay 1) de-energises to close the MCB – LED 10 illuminates

Stop sequence via

STOP one time:

Action *STOP*
Operation *Open GCB*
Delay *Breaker delay*

Operation *Close MCB*
Delay *Cool down time*

Press the STOP button 6 once

The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire

The MCB open relay (relay 1) de-energises to close the MCB – LED 10 illuminates

The control unit waits for the cool down time configured in the engine parameters (page 69) to expire

The engine stops – LEDs 12 and 13 go out

Operation *Engine stop*

Stop sequence via

STOP two times:

Action *STOP*
Operation *Open GCB*
Delay *Breaker delay*

Operation *Close MCB*
Operation *Engine stop*

Press the STOP button 6 twice

The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire

The MCB open relay (relay 1) de-energises to close the MCB – LED 10 illuminates

The engine stops immediately without a cool down period – LEDs 12 and 13 go out

Detailed operation with 2 CBs in manual mode (mains are not present) - [M-L], [M-H]

- Preconditions:
- Generator is stopped – LED 12 is not illuminated
 - MCB is closed – LED 10 is illuminated
 - Mains are not present – LED 9 is not illuminated
 - Unit is in manual mode – LED 16 is illuminated

Engine start sequence:

Action	START
Delay	Preglow time
Operation	Fuel relay
Operation	Crank relay
Delay	Engine delay time

Press the START - STOP button **5**
 If diesel start logic is selected the relay will energise the glow plugs for the time configured in the engine parameters (page 68)
 The fuel relay (relay 5) is energised to enable the fuel solenoid
 The crank relay (relay 6) is energised to engage the starter – LED **12** illuminates and LED **13** starts flashing when generator speed has been detected
 The control unit waits for the engine monitoring delay time configured in the engine parameters (page 69) to expire – LED **13** changes to steady illumination after the time expires

GCB close sequence:

Action	Breaker control
Operation	Open MCB
Delay	Breaker delay
Operation	Close GCB

Press the BREAKER CONTROL button **4**
 The MCB open relay (relay 1) energises to open the MCB – LED **10** goes out
 The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire
 The GCB close relay (relay 2) energises to close the GCB – LED **11** illuminates

GCB open sequence:

Action	Breaker control
Operation	Open GCB

Press the BREAKER CONTROL button **4**
 The GCB close relay (relay 2) de-energises to open the GCB – LED **11** goes out

Note The MCB close command will not be issued unless the mains return

Stop sequence via START - STOP:

Action	STOP
Operation	Open GCB
Operation	Engine stop
Action	Breaker control
Operation	Close MCB

Press the START - STOP button **5**
 The GCB close relay (relay 2) de-energises to open the GCB – LED **11** goes out
 The engine stops – LEDs **12** and **13** go out
 Pressing the BREAKER CONTROL button **4**
 The MCB open relay (relay 1) de-energises to close the MCB – LED **10** illuminates

Stop sequence via STOP one time:

Action	STOP
Operation	Open GCB
Delay	Breaker delay
Operation	Close MCB
Delay	Cool down time
Operation	Engine stop

Press the STOP button **6** once
 The GCB close relay (relay 2) de-energises to open the GCB – LED **11** goes out
 The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire
 The MCB open relay (relay 1) de-energises to close the MCB – LED **10** illuminates
 The control unit waits for the cool down time configured in the engine parameters (page 69) to expire
 The engine stops – LEDs **12** and **13** go out

Stop sequence via STOP two times:

Action	STOP
Operation	Open GCB
Delay	Breaker delay
Operation	Close MCB
Operation	Engine stop

Press the STOP button **6** twice
 The GCB close relay (relay 2) de-energises to open the GCB – LED **11** goes out
 The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire
 The MCB open relay (relay 1) de-energises to close the MCB – LED **10** illuminates
 The engine stops – LEDs **12** and **13** go out

b.) Application Mode {1 breaker open/close} – [G-L], [G-H], [M-L], [M-H]



The START - STOP button **5**

Starts the engine (if the engine is stopped, LED **13** is not illuminated)

Stops the engine (if the engine is running, LED **13** is illuminated)



The BREAKER CONTROL button **4**

Opens the GCB (if the GCB is closed LED **11** is illuminated)

Closes the GCB (if the GCB is open (LED **11** not illuminated) and the engine is running(LED **13** is illuminated))

Detailed operation with 1 CB in manual mode

- Preconditions:**
- Generator is stopped – LED **12** is not illuminated
 - Unit is in manual mode – LED **16** is illuminated

Engine start sequence:

Action	START	Press the START - STOP button 5
Delay	Preglow time	If diesel start logic is selected the relay will energise the glow plugs for the time configured in the engine parameters (page 68)
Operation	Fuel relay	The fuel relay (relay 5) is energised to enable the fuel solenoid
Operation	Crank relay	The crank relay (relay 6) is energised to engage the starter – LED 12 illuminates and LED 13 starts flashing when generator speed has been detected
Delay	Engine delay time	The control unit waits for the engine monitoring delay time configured in the engine parameters (page 69) to expire – LED 13 changes to steady illumination after the time expires

GCB close sequence:

Action	Breaker control	Press the BREAKER CONTROL button 4
Operation	Close GCB	The GCB close relay (relay 2) energises to close the GCB – LED 11 illuminates

GCB open sequence:

Action	Breaker control	Press the BREAKER CONTROL button 4
Operation	Open GCB	The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out

Stop sequence via START - STOP:

Action	STOP	Press the START - STOP button 5
Operation	Open GCB	The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
Operation	Engine stop	The engine stops – LEDs 12 and 13 go out

Stop sequence via STOP one time:

Action	STOP	Press the STOP button 6 once
Operation	Open GCB	The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
Delay	Cool down time	The control unit waits for the cool down time configured in the engine parameters (page 69) to expire
Operation	Engine stop	The engine stops – LEDs 12 and 13 go out

Stop sequence via STOP two times:

Action	STOP	Press the STOP button 6 twice
Operation	Open GCB	The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
Operation	Engine stop	The engine stops – LEDs 12 and 13 go out

Operating Mode AUTOMATIC



In the AUTOMATIC operating mode, all engine, GCB, and/or MCB functions are operated via the discrete inputs or automatically by the control unit (i.e. a mains failure). The function of the **NAC1** depends on the configuration of the unit and how the external signals are used. LED **15**, in the upper left corner of the AUTO - MANUAL button **3**, indicates the automatic operating mode.

c.) Detailed operation with 2 CBs in automatic mode (mains are present) - [M-L], [M-H]

- Preconditions:**
- Generator is stopped – LED **12** is not illuminated
 - MCB is closed – LED **10** is illuminated
 - Mains are present – LED **9** is illuminated
 - Unit is in automatic mode – LED **15** is illuminated

Start sequence:

Action	<i>Remote start</i>	Discrete input DI3 (remote start) is activated (active HIGH signal) at terminal 18
Delay	<i>Preglow time</i>	If diesel start logic is selected the relay will energise the glow plugs for the time configured in the engine parameters (page 68)
Operation	<i>Fuel relay</i>	The fuel relay (relay 5) is energised to enable the fuel solenoid
Operation	<i>Crank relay</i>	The crank relay (relay 6) is energised to engage the starter – LED 12 illuminates and LED 13 starts flashing when generator speed has been detected
Delay	<i>Engine delay time</i>	The control unit waits for the engine monitoring delay time configured in the engine parameters (page 69) to expire – LED 13 changes to steady illumination after the time expires
Operation	<i>Open MCB</i>	The MCB open relay (relay 1) energises to open the MCB – LED 10 goes out
Delay	<i>Breaker delay</i>	The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire
Operation	<i>Close GCB</i>	The GCB close relay (relay 2) energises to close the GCB – LED 11 illuminates

Stop sequence:

Action	<i>Remote stop</i>	Discrete input DI3 (remote start) is deactivated (active LOW signal) at terminal 18
Operation	<i>Open GCB</i>	The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
Delay	<i>Breaker delay</i>	The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire
Operation	<i>Close MCB</i>	The MCB open relay (relay 1) de-energises to close the MCB – LED 10 illuminates
Delay	<i>Cool down time</i>	The control unit waits for the cool down time configured in the engine parameters (page 69) to expire
Operation	<i>Engine stop</i>	The engine stops – LEDs 12 and 13 go out

d.) Detailed operation with 2 CBs in automatic mode (mains are not present) - [M-L], [M-H]

- Preconditions:**
- Generator is stopped – LED 12 is not illuminated
 - MCB is closed – LED 10 is illuminated
 - Mains are not present – LED 9 is not illuminated
 - Unit is in automatic mode – LED 15 is illuminated

Start sequence:

Action	<i>Remote start</i>	Discrete input DI3 (remote start) is activated (active HIGH signal) at terminal 18
Delay	<i>Preglow time</i>	If diesel start logic is selected the relay will energise the glow plugs for the time configured in the engine parameters (page 68)
Operation	<i>Fuel relay</i>	The fuel relay (relay 5) is energised to enable the fuel solenoid
Operation	<i>Crank relay</i>	The crank relay (relay 6) is energised to engage the starter – LED 12 illuminates and LED 13 starts flashing when generator speed has been detected
Delay	<i>Engine delay time</i>	The control unit waits for the engine monitoring delay time configured in the engine parameters (page 69) to expire – LED 13 changes to steady illumination after the time expires
Operation	<i>Open MCB</i>	The MCB open relay (relay 1) energises to open the MCB – LED 10 goes out
Delay	<i>Breaker delay</i>	The control unit waits for the breaker transfer time configured in the breaker parameters (page 70) to expire
Operation	<i>Close GCB</i>	The GCB close relay (relay 2) energises to close the GCB – LED 11 illuminates

Stop sequence:

Action	<i>Remote stop</i>	Discrete input DI3 (remote start) is deactivated (active LOW signal) at terminal 18
Operation	<i>Open GCB</i>	The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
Delay	<i>Cool down time</i>	The control unit waits for the cool down time configured in the engine parameters (page 69) to expire
Operation	<i>Engine stop</i>	The engine stops – LEDs 12 and 13 go out



NOTE

The MCB described in the above text will only close if the mains return.

e.) AMF/Auto Mains Failure Operation - [M-L], [M-H]

The operation sequence for an AMF operation is similar to the above sequence with the difference that a remote start signal is not required for the engine start and the engine monitoring delay time is not considered, i.e. the CBs are operated immediately. For an AMF operation in automatic mode the parameter Emergency power monitoring (page 70) must be configured to ON, no class F alarms may be present, the engine must be ready for operation, and the configured mains fail delay time (page 70) must expire to start the engine.

Example for an AMF Operation:

Initial situation:

- Mains are present
- Mains circuit breaker is closed
- The generator controller is in the automatic operation mode and emergency stand-by

A mains failure occurs:


- Mains are not present

Reaction of the unit:

- The mains failure is detected by the unit
- The period configured in the parameter "Mains fail delay time" expires
- The period configured in the parameter "Preglow time" expires
- The generator will be started
- The mains circuit breaker will be opened
- The time configured in the parameter "Transfer time GCBMCB" expires
- The generator circuit breaker will be closed
- The unit is in auto emergency power operation now

The mains return:

- The return of the mains is detected by the unit
- The period configured in the parameter "Mains settling time" expires
- The generator circuit breaker will be opened
- The "Transfer time GCBMCB" and "Cool down time" timers start to run
- If the time configured in the parameter "Transfer time GCBMCB" expires, the MCB will be closed
- If the time configured in the parameter "Cool down time" expires, the generator/engine will be shut down
- The unit is back in emergency stand-by



f.) Detailed operation with 1 CB in Automatic mode

- Preconditions:
- Generator is stopped – LED 12 is not illuminated
 - Unit is in Automatic mode – LED 15 is illuminated

Start sequence:		
Action	<i>Remote start</i>	Discrete input DI3 (remote start) is activated (active HIGH signal) at terminal 18
Delay	<i>Preglow time</i>	If diesel start logic is selected the relay will energise the glow plugs for the time configured in the engine parameters (page 68)
Operation	<i>Fuel relay</i>	The fuel relay (relay 5) is energised to enable the fuel solenoid
Operation	<i>Crank relay</i>	The crank relay (relay 6) is energised to engage the starter – LED 12 illuminates and LED 13 starts flashing when generator speed has been detected
Delay	<i>Engine delay time</i>	The control unit waits for the engine monitoring delay time configured in the engine parameters (page 69) to expire – LED 13 changes to steady illumination after the time expires
Operation	<i>Close GCB</i>	The GCB close relay (relay 2) energises to close the GCB – LED 11 illuminates
Stop sequence:		
Action	<i>Remote stop</i>	Discrete input DI3 (remote start) is deactivated (active LOW signal) at terminal 18
Operation	<i>Open GCB</i>	The GCB close relay (relay 2) de-energises to open the GCB – LED 11 goes out
Delay	<i>Cool down time</i>	The control unit waits for the cool down time configured in the engine parameters (page 69) to expire
Operation	<i>Engine stop</i>	The engine stops – LEDs 12 and 13 go out

8.4 Breaker Closure Limits

8.4.1 Generator Circuit Breaker

The *NAC1* Series has fixed breaker closure limits which prevent the GCB closure if the generator voltage and/or frequency is/are not within these limits. These limits depend on the parameters rated system frequency and rated generator voltage (refer to *Measuring*, on page 66.) and cannot be changed. The limits are set as follows:

$f_{\text{generator}}$ must be within $f_{\text{rated system}} \pm 10\%$

Examples:

If the rated system frequency is set to 50 Hz, the upper limit is at 55 Hz and the lower limit is at 45 Hz.


If the rated system frequency is set to 60 Hz, the upper limit is at 66 Hz and the lower limit is at 54 Hz.


$V_{\text{generator}}$ must be within $V_{\text{rated generator}} \pm 10\%$

Examples:

If the rated generator voltage is set to 400 V, the upper limit is at 440 V and the lower limit is at 360 V.

If the rated generator voltage is set to 120 V, the upper limit is at 108 V and the lower limit is at 132 V.

If the generator voltage and/or frequency is/are not within these limits, the generator LED  is flashing and the GCB cannot be closed.

If the generator voltage and frequency are within these limits, the generator LED  is permanently on and the GCB may be closed.

8.4.2 Mains Circuit Breaker


The *NAC1-M-L* and *M-H* have flexible breaker closure limits which prevent the MCB closure if the mains voltage and/or frequency is/are not within the mains failure limits.


These limits depend on the parameters rated system frequency and rated mains voltage and can be freely configured (refer to *Monitoring: Mains Failure Limits*, on page 75 for details).

The conditions for closing the MCB are specified as follows and all conditions must be fulfilled:

- The mains voltage is present.
- The mains settling time (refer to *Emergency Power (AMF)* on page 70) has expired.
- NONE of the following alarms is present:
 - Mains over/underfrequency
 - Mains over/undervoltage
 - Mains rotation field alarm

If the mains voltage is present, but the voltage and/or frequency is/are not within these limits, the mains LED  is flashing, and the MCB cannot be closed.

If the mains voltage and frequency are within these limits, and the mains settling time has expired, the mains LED  is illuminated permanently, and the MCB may be closed.

The mains LED  is off, if the phase-neutral measuring voltage is below 10V.

8.5 Functional Description of the Oil Pressure Input DI1

The *NAC1* Series is provided with an input for oil pressure. The function of this discrete input is described in the following.




Figure 8-2: Discrete input DI1 - oil pressure

Terminal	Description	A_{max}
15	DI1 oil pressure common	2.5 mm ²
16	DI1 oil pressure signal	2.5 mm ²

Table 8-1: Discrete input DI1 - oil pressure

The oil pressure switch is connected to the terminals 15 (common) and 16 (DI1 signal) on the *NAC1*. The oil pressure switch (OPS) must be a N.C. contact. If the oil pressure is below the minimum required pressure, the contacts need to close. If the oil pressure is above the minimum required pressure, the contacts need to be open. The oil pressure is only monitored if the *NAC1* detects speed/frequency from the genset. If the genset is in a stand-by or stop mode, the oil pressure switch is disabled.

a.) Parameter "Crank termination by DI1"

If the parameter "Crank termination by DI1" is enabled, the oil pressure can be used to terminate the starting system for the engine. 2 seconds after oil pressure is detected, the crank relay will be disabled. The delay ensures that the crank relay is not disabled prior to the engine reaching firing speed.

b.) Parameter "Starter time"

In all other applications, the starter is active only for the time configured in the parameter "Starter time".

The following diagram shows the starting procedure as a function of time.




Figure 8-3: Starting procedure

8.6 Firing Speed Detection

The firing speed is used for crank termination if the parameter "Crank termination by DI1" is not enabled (refer to .Parameter "Crank termination by DI1". on page 56 if this parameter is enabled). When "Crank termination by DI1" is disabled, the firing speed is determined by the generator frequency or is calculated from the nominal speed and the rated system frequency. The control unit shows the following behavior:

Case 1:

Firing speed is reached if a minimum generator frequency of 15 Hz is detected. The *NAC1* versions [G-L] and [M-L] operate in this manner. It is possible for the *NAC1* versions [G-H] and [M-H] to also operate in this manner if the parameter "Speed pickup" is disabled.

Case 2:

Firing speed is reached if the calculated firing speed is detected via an MPU. The *NAC1* versions [G-H] and [M-H] must have the parameter "Speed pickup" enabled to operate in this manner.

The firing speed is calculated according to the following formula:

$$\text{Firing Speed} = \frac{\text{Nominal Speed}}{\text{Rated System Frequency}} * 15 \text{ Hz}$$

Example: If the nominal speed is 1,500 rpm and the rated system frequency is 50 Hz, the firing speed will be (1,500 rpm / 50Hz) * 15 Hz = 450 rpm. The crank will be terminated if the calculated speed exceeds 450 rpm.

8.7 Functional Description of the Charging Alternator Input/Output

The **NAC1** Series monitors the charging alternator operation with the following functionality.

If the engine is started, the internal switch is closed simultaneously with the crank relay output, and the battery voltage is applied to the exciter winding D+ through the internal switch contacts. This pre-excites the charging alternator so that voltage is generated. The internal switch will be opened when the engine has started properly and the crank relay output has been de-energised to terminate the crank cycle. If the engine is driving the charging alternator, the battery will be charged from the charging alternator. Terminal 3 (for 24V systems or terminal 4 for 12V systems) now acts as the charging alternator input for monitoring the charging voltage. Terminal 2 (battery voltage +) serves as the input for measuring the battery voltage of the unit at the same time.

Usually the alternator charges the battery while the engine is running. This ensures that the battery is charged and ready to energise the cranking circuit and other auxiliary components for the next start.

In some cases the alternator itself needs excitation from an auxiliary source for generating its own terminal voltages. In this case the battery will be connected into the alternator excitation windings during the engine start-up. This ensures that the alternator will be self-excited and provides voltage for charging the battery after the start-up sequence.

The **NAC1** provides two features:

1. Aux-excitation for the alternator
2. Continuous monitoring of the alternator terminal voltage

The D+ Terminals are internal connected to the crank-relay-contacts:

During engine-start up the battery will be connected across internal contacts and resistors to the D+ input of the alternator. The alternator will be excited by the battery. Once the engine exceeds firing speed the internal switch opens and the D+ terminals will be disconnected from the alternator excitation windings.

While the engine is running the D+ terminals are still connected to the **NAC1** which will measure the terminal voltage of the alternator.

If the voltage drops below a limit the **NAC1** will initiate the fault "alternator charge failure".

Depending on the battery system the **NAC1** provides terminals for 12V and for 24V battery systems.

The internal resistors limit the charge current for each of the two systems.




Figure 8-4: Charging alternator input/output



NOTE

The charging alternator D+ acts as an output for pre-exciting the charging alternator during engine start-up only. During regular operation, it acts as an input for monitoring the charging voltage.

8.8 Functional Description of the 2nd. CB Close Delay Time

The *NAC1* Series provides Delayed close GCB and Delayed close MCB (only [M-L], [M-H]) signals in the list of configurable parameters (find more details about this under Relay Outputs on page 84) in order to meet the requirements of some special circuit breaker types which require an Enable CB Close signal before the actual CB close signal. The function of these signals is described in the following text.

If those CBs are utilised, they require two Close CB signals with a time delay in between from two different relays. This can be achieved by selecting Delayed close GCB (MCB) from the list of configurable parameters for a freely configurable relay (relay 3 or 4). The delay time can be configured with the parameter 2nd GCB (MCB) Close Delay Time. If the user initiates the command Close GCB (MCB), the signal is immediately issued from the fixed relay (relay2 for GCB or relay 1 for MCB) assigned to give the close command. After the configured delay time has expired, the second Close GCB (MCB) signal is issued. The user configures the delay time for the second close command at the relay output.


Example for the functionality:

Assumption: The close GCB signal is to be issued parallel on a second relay with a delay. Relay 4 shall be used in this example for this. The parameter "Relay 4" has to be configured to "Delayed close GCB" from the list of configurable parameters (refer to Relay Outputs on page 84). The delay time may be configured with the parameter "2nd GCB close delay time"(refer to Application on page 67). A period of 2 seconds shall be configured for this example.

If the user triggers the command "Close GCB" now, the following sequence will be performed:

The signal "Close GCB" energises the relay firmly assigned to it (relay 2) immediately.

After the configured delay has expired, the signal "Close GCB" energises the relay assigned by the user (relay 4 in this example) with the configured delay.



The delay "t" corresponds with the values of the parameters "2nd GCB close delay time" and "2nd MCB close delay time".

If the respective circuit breaker is opened, both relays return to their initial state.



NOTE

This functionality can only be configured using FL-SOFT3.

8.9 Functional Description of the Engine Released Signal

The *NAC1* Series provides the engine released signal in the list of configurable parameters (find more details about this under Relay Outputs on page 84). It is possible to use this signal for some special applications. Its functionality is described in the following for an emergency power supply.

Emergency power supply systems often require that all external system components (i.e. governors, etc.) except the genset control be disconnected from the battery power supply and that the battery is not loaded unnecessarily during engine downtime. This means that the external components shall only be connected with battery power, if the engine is operating. To achieve this, a genset control signal is required, which connects the external components to the battery, as soon as the engine is started. This can be accomplished using the engine released signal when configuring a relay (relay 3 [M-L], [M-H] or 4) to initiate this signal. The functionality is described in the following text with relay 4.




Figure 8-5: AMF application with engine released signal

The following functionality depends on the setting of the fuel relay (page 68):

Fuel relay configured as operating solenoid:

The *NAC1* detects the mains loss and initiates the engine start. Relay 4 (configured to engine released) and relay 5 (fuel relay) are energised. The fuel relay provides the fuel supply to the engine. Relay 4 closes the contact K1 and connects the battery power to the external components that they are ready for operation. This ensures that these external components are not energised until they are needed.

Fuel relay configured as stop solenoid:

The *NAC1* detects the mains loss and initiates the engine start. Relay 4 (configured to engine released) is energised. Relay 4 closes the contact K1 and connects the battery power to the external components that are needed for operation. This ensures that these external components are not energised if they are not used. If the engine is stopped, relay 5 (fuel relay) will be energised, cutting off the fuel supply.



NOTE

It is not recommended to use the fuel relay signal for connecting the external equipment with the battery since this signal drops in amplitude with every possible start pause in contrast to the engine released signal.

9 Configuration

9.1 Restoring Default Values

The *NAC1* can be reset to factory settings easily. This may be comfortable for configuring the *NAC1* from a known state.



NOTE

The unit has to be in Operating Mode STOP (page 46) to load the default values.

9.1.1 Resetting Via the Front Panel

Preconditions for loading the default values:

- Unit must be in operation mode STOP – LED 17 is illuminated
- The engine must be stopped – LED 13 is not illuminated
- No generator voltage may be present – LED 12 is not illuminated

Press and hold the UP  7, ALARM  2, and STOP  6 buttons simultaneously for at least 10 seconds to reset the values. The factory default values have been restored when all the LEDs flash briefly,.

9.1.2 Resetting Via FL-SOFT3

Precondition for loading the default values:

- Unit has to be in operation mode STOP – LED 17 is illuminated

Connect the *NAC1* with your PC and start FL-SOFT3 as described in Configuration Using the PC on page 62.

Set the parameter Factory settings FL-CABLE-RS232 to YES.

Set the parameter Set default values to YES.

Now, the default values are loaded.

9.2 Configuration Via the Front Panel

Operating the control unit via the front panel is explained in Configuring the *NAC1* on page 33. Familiarise yourself with the unit, the buttons' meaning/function, and the display monitoring using this section. The display of the parameters via the front panel and the display of the parameters via the computer program FL-SOFT3 will differ.



NOTE

Not all parameters may be accessed or changed when configuring the control unit via the front panel. To properly commission a control unit, FL-SOFT3 v3.1xxx or higher and a FL-CABLE-RS232 are required.

9.3 Configuration Using the PC



CAUTION

For the configuration of the unit via the PC please use the FL-SOFT3 software with the following software version:

FL-SOFT3 3.1 or higher



NOTE

Please note that configuration using the direct configuration cable FL-CABLE-RS232 is possible starting with revision B (first delivered July 2003). If you have an older model please contact our sales department.

For configuration of the unit via PC program please proceed as follows:

- Install the FL-SOFT3 program on your notebook/PC according to the provided user manual 37305. Consider the options that are given during the installation.
- Prior to the completion of the installation you will be prompted to select the language with which you want to start the PC program. The language of FL-SOFT3 may be changed at any time. The selection of the language refers only to language with which the menus and subprograms that FL-SOFT3 program works with. This setting will not change the configured language of the control unit.
- After the installation of FL-SOFT3 has been completed it is necessary to reboot your notebook/PC.
- Establish a connection between your notebook/PC and the control unit via the FL-CABLE-RS232. Insert the RJ45 plug into the RJ45 port on the control unit (see FL-CABLE-RS232 - Direct Configuration Cable on page 29 for details) and the serial cable to the COM1 port of your notebook/PC.
- You can now start the PC program as follows:
 - by "Start/Program/SEG FL/FL-SOFT3" (version 3.1 or higher) and opening the respective cfg file, or
 - by a double click on the respective file ending ".cfg" in the subdirectory "/FL-SOFT3".The cfg files differ in their language used. Use the file on the enclosed floppy disk with the language you want, i.e. US for US English or DE for German.
- After the FL-SOFT3 program has started, establish communication by pressing the F2 button or selecting Communication - > Connect from the menu. This will establish a data link between the control unit and the notebook/PC.
- Start the configuration routine pressing the F3 button or selecting Devices -> Parameterise from the menu and adjust the parameter of the unit to your application using this manual.



NOTE

You find detailed information about FL-SOFT3 and the utilisation of the software in the user manual 37305 belonging to it.



NOTE

The connection cables delivered with the FL-CABLE-RS232 must be used to connect it to ensure a proper function of the **NAC1**. An extension or utilisation of different cable types for the connection between **NAC1** and FL-CABLE-RS232 may result in a malfunction of the **NAC1**. This may further result in damage to components of the system. If an extension of the data connection line is required, only the serial cable between FL-CABLE-RS232 and notebook/PC may be extended.



NOTE

Unplug the FL-CABLE-RS232 after configuration to ensure a safe operation! If the FL-CABLE-RS232 remains plugged into the **NAC1** unit, a safe operation of the unit can not be guaranteed.

9.4 Editing the Configuration File

If you want to edit the configuration file in order to inhibit resetting the counters, you have to proceed as follows:

Open the configuration file in a text editor

In order to edit the configuration file, open the respective *.asm file in the "Tools" subdirectory of your FL-SOFT3 installation path with a text editor like Microsoft Notepad. An example of a name (depending on unit and software version) for a configuration file is:

```
8440-1746_NEW_pDirUS.asm
```

Delete the lines which are used to display the counter entries in the FL-SOFT3 configuration

The lines to be deleted in the *.asm file are:

```
;IK <b> <color=EE0000> -CONFIG.COUNTERS-</b>
%TAB 0,0,0,H'03;lz2550,"> Maintenance hours","0000h",1.0,0,9999
%TAB 0,0,0,H'03;IM2562,"> reset maintenance period h" ,H'FFFF,2,"No","Yes"
%TAB 0,0,0,H'03;ll2515,"> Counter value preset","00000000",1.0
%TAB 0,0,0,H'03;IM2554,"> Set operation hours" ,H'FFFF,2,"No","Yes"
%TAB 0,0,0,H'03;lz2540,"> Number of starts","00000",1.0,0,65535
```

Store the modified file

Store the modified configuration file back to the "Tools" subdirectory of your FL-SOFT3 installation path under the same file name.

If you load the modified file in FL-SOFT3 now, the deleted lines will not be displayed in the configuration menu anymore.

9.5 Configuring the Flags

The **NAC1** Series provides four configurable LED flags in the alphanumeric display to indicate alarms. One or more alarm messages can be assigned to each one of these flags (i.e. the respective flag will be illuminated if the configured alarm state(s) occur(s) in addition to the regular alarm indication). A detailed description of these flags can be found in the chapter Alarm Messages on page 37. The configuration parameter is described in detail under Flags on page 88. The flags may only be configured using FL-SOFT3.




Figure 9-1: Configurable display flags

The flag parameters are displayed in FL-SOFT3 (refer to Configuration Using the PC on page 62 and the FL-SOFT3 user manual 37305 for more information) under System – Codes like shown in Figure 9-2 in default state (alarm "Start fail" is assigned to flag 1). The parameter with the name "Flag 1 Start fail" has the value "Yes", i.e. the alarm "Start fail" is assigned to flag 1.




Figure 9-2: Flag configuration default

You may assign as many alarms as required to one flag using FL-SOFT3. Just mark the respective entry and press Input to configure the alarm assignment or double-click the entry for configuration. The example in Figure 9-3 shows that the alarms "Unintended stop" and "Start fail" are assigned to flag 1, i.e. the flag is illuminated (flashing) if at least one of these alarms is present.





Figure 9-3: Flag configuration custom

10 Parameters

The following description of parameters is expanded to include all parameters that are accessible through FL-SOFT3. Not all parameters are accessible via the front panel.



10.1 Measuring

⌘	Rated system frequency			
⌘	Nennfrequenz im System			

10	[G-L]	[G-H]	[M-L]	[M-H]
3	✓	✓	✓	✓

Rated system frequency

50/60 Hz

The rated frequency of the system has to be configured here.
The generator frequency monitoring as well as the mains failure limits refer to the value configured in this parameter.

⌘	Rated voltage generator			
⌘	Nennspannung Generator			

11	[G-L]	[G-H]	[M-L]	[M-H]
3	✓	✓	✓	✓

Rated generator voltage

50 to 480 V

The rated voltage of the generator has to be configured here.
The generator voltage monitoring refers to the value configured in this parameter.

⌘	Rated voltage mains			
⌘	Nennspannung Netz			

12	[G-L]	[G-H]	[M-L]	[M-H]
3	–	–	✓	✓

Rated mains voltage

50 to 480 V

The rated voltage of the mains has to be configured here.
The mains failure limits refer to the value configured in this parameter.

⌘	Generator voltage measuring			
⌘	Gen. Spannungsmessung			

---	[G-L]	[G-H]	[M-L]	[M-H]
FL	✓	✓	✓	✓

Generator voltage measurement 3Ph 4W/3Ph 3W/1Ph 2W/1Ph 3W

The method of voltage measurement for the generator. This parameter is set to 1Ph 2W and cannot be changed for the *NAC1* models [G-L] and [M-L].

A detailed description of the different measurement methods can be found in Voltage Measuring on page 19.

⌘	Mains voltage measuring			
⌘	Netz Spannungsmessung			

---	[G-L]	[G-H]	[M-L]	[M-H]
FL	---	---	✓	✓

Mains voltage measurement

3Ph 4W/3Ph 3W/1Ph 2W/1Ph 3W

The measurement principle for the mains. This parameter is set to 3Ph 4W and cannot be changed for [M-L].

A detailed description of the different measurement methods can be found in Voltage Measuring on page 19.



NOTE

The correct configuration of these parameters is essential for a proper operation of the control unit.

10.2 Application

EN	Ignore CB reply	Ignore CB reply					YES/NO
DE	Ignoriere Rückmeldung LS	Ignoriere Rückmeldung LS					
---	[G-L]	[G-H]	[M-L]	[M-H]			
FL	✓	✓	✓	✓			

This parameter controls the function of the discrete inputs DI4 and DI5.

YES.....The discrete inputs DI4 and DI5 are freely configurable. The parameters of the discrete inputs can be accessed and configured via FL-SOFT3.

NOThe discrete inputs DI4 and DI5 operate as reply inputs for the mains (DI4) or generator (DI5) circuit breaker. The parameters of the discrete inputs can be accessed via FL-SOFT3 but cannot be changed.



CAUTION

The customer must ensure that a mechanical interlock for the circuit breakers exists for the case that the parameter "Ignore CB reply" is configured to "YES".

EN	2nd GCB close Delay time	2nd GCB close Delay time					0.00 to 650.00 s
DE	Verz. Zeit zweiten GLS schließen	Verz. Zeit zweiten GLS schließen					
---	[G-L]	[G-H]	[M-L]	[M-H]			
FL	✓	✓	✓	✓			

This parameter controls the delay for the 2nd GCB close signal. The application and behavior of this signal is described under Functional Description of the 2nd CB Close Delay Time on page 58.

EN	2nd MCB close Delay time	2nd MCB close Delay time					0.00 to 650.00 s
DE	Ver. Zeit zweiten NLS schließen	Ver. Zeit zweiten NLS schließen					
-	[G-L]	[G-H]	[M-L]	[M-H]			
FL	---	---	✓	✓			

This parameter controls the delay for the 2nd MCB close signal. The application and behavior of this signal is described under Functional Description of the 2nd CB Close Delay Time on page 58.

10.3 Engine

10.3.1 Engine: Diesel

		Fuel relay: close to stop			
		Kraftstoffmagnet: Stopmag.			
		[G-L]	[G-H]	[M-L]	[M-H]
20		✓	✓	✓	✓
3		✓	✓	✓	✓

Fuel relay close to stop/open to stop

close to stop To stop the engine the stop solenoid is energised. Once speed is no longer detected, the stop solenoid remains closed for an additional 30 s.

open to stop Before the starting sequence is initiated, the operating solenoid is energised. To stop the engine the operating solenoid is de-energised.

		Preglow time			
		Vorglühzeit			
		[G-L]	[G-H]	[M-L]	[M-H]
21		✓	✓	✓	✓
3		✓	✓	✓	✓

Preglow time 0 to 300 s

Before each starting the diesel engine is preglowed for this time (if a "0" has been configured here the engine will be started without preglow).

10.3.2 Engine: Pickup

		Speed pickup			
		Pickup			
		[G-L]	[G-H]	[M-L]	[M-H]
30		---	✓	---	✓
3		---	✓	---	✓

Speed pick-up ON/OFF

ON..... Speed monitoring of the engine is performed using an MPU.

OFF..... Speed/frequency monitoring of the generator/engine is carried out by measuring the frequency of the generator. There is no MPU wired to this unit.

		Nominal speed			
		Nenn Drehzahl			
		[G-L]	[G-H]	[M-L]	[M-H]
31		---	✓	---	✓
3		---	✓	---	✓

Nominal speed 500 to 4,000 RPM

Revolutions per minute of the engine at rated engine speed.

		Number of gear teeth			
		Zähneanzahl			
		[G-L]	[G-H]	[M-L]	[M-H]
32		---	✓	---	✓
3		---	✓	---	✓

Number of gear teeth 5 to 260

Number of pulses per revolution.

Note: If the number of gear teeth is not correct, the speed will not be calculated correctly and this will lead to a speed/frequency mismatch alarm.

10.3.3 Engine: Start/Stop Automatic

<table border="1"> <tr> <td>EN</td> <td colspan="4">Starter time</td> </tr> <tr> <td>DE</td> <td colspan="4">Einrückzeit Anlasser</td> </tr> <tr> <td>---</td> <td>[G-L]</td> <td>[G-H]</td> <td>[M-L]</td> <td>[M-H]</td> </tr> <tr> <td>FL</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> </tr> </table>	EN	Starter time				DE	Einrückzeit Anlasser				---	[G-L]	[G-H]	[M-L]	[M-H]	FL	✓	✓	✓	✓	<p>Starter time 1 to 10 s</p> <hr/> <p>The maximum time during which the crank relay remains enabled. The starter relay de-energises when the engine reaches ignition speed or the configured time expires.</p>
EN	Starter time																				
DE	Einrückzeit Anlasser																				
---	[G-L]	[G-H]	[M-L]	[M-H]																	
FL	✓	✓	✓	✓																	
<table border="1"> <tr> <td>EN</td> <td colspan="4">Start pause time</td> </tr> <tr> <td>DE</td> <td colspan="4">Startpausenzeit</td> </tr> <tr> <td>---</td> <td>[G-L]</td> <td>[G-H]</td> <td>[M-L]</td> <td>[M-H]</td> </tr> <tr> <td>FL</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> </tr> </table>	EN	Start pause time				DE	Startpausenzeit				---	[G-L]	[G-H]	[M-L]	[M-H]	FL	✓	✓	✓	✓	<p>Start pause time 10 to 99 s</p> <hr/> <p>Time between the individual starting attempts. (This time is used to protect the starter relay.)</p>
EN	Start pause time																				
DE	Startpausenzeit																				
---	[G-L]	[G-H]	[M-L]	[M-H]																	
FL	✓	✓	✓	✓																	
<table border="1"> <tr> <td>EN</td> <td colspan="4">Cool down time</td> </tr> <tr> <td>DE</td> <td colspan="4">Motor Nachlaufzeit</td> </tr> <tr> <td>40</td> <td>[G-L]</td> <td>[G-H]</td> <td>[M-L]</td> <td>[M-H]</td> </tr> <tr> <td>3</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> </tr> </table>	EN	Cool down time				DE	Motor Nachlaufzeit				40	[G-L]	[G-H]	[M-L]	[M-H]	3	✓	✓	✓	✓	<p>Cool down time 0 to 999 s</p> <hr/> <p>Regular stop: If the engine performs a normal stop or changed into the STOP operation mode, a cool down with an opened GCB is carried out. This time is adjustable.</p> <p>Stop by an alarm of class F: If a class F alarm is detected, the GCB will open immediately and the engine will shutdown without a cool down.</p>
EN	Cool down time																				
DE	Motor Nachlaufzeit																				
40	[G-L]	[G-H]	[M-L]	[M-H]																	
3	✓	✓	✓	✓																	
<table border="1"> <tr> <td>EN</td> <td colspan="4">Crank termination by DI1</td> </tr> <tr> <td>DE</td> <td colspan="4">Anlasser ausspuren über DI1</td> </tr> <tr> <td>---</td> <td>[G-L]</td> <td>[G-H]</td> <td>[M-L]</td> <td>[M-H]</td> </tr> <tr> <td>FL</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> </tr> </table>	EN	Crank termination by DI1				DE	Anlasser ausspuren über DI1				---	[G-L]	[G-H]	[M-L]	[M-H]	FL	✓	✓	✓	✓	<p>Crank termination by DI1 YES/NO</p> <hr/> <p>YES The starting system is disengaged when the oil pressure monitoring input DI1 indicates that adequate oil pressure has been detected (refer to .Parameter "Crank termination by DI1". on page .56).</p> <p>NO The crank termination will be performed if the firing speed is reached (refer to Firing Speed Detection on page 57) and the discrete input DI1 is only used for oil pressure monitoring.</p>
EN	Crank termination by DI1																				
DE	Anlasser ausspuren über DI1																				
---	[G-L]	[G-H]	[M-L]	[M-H]																	
FL	✓	✓	✓	✓																	
<table border="1"> <tr> <td>EN</td> <td colspan="4">Engine monit. delay time</td> </tr> <tr> <td>DE</td> <td colspan="4">Motorverzögerung</td> </tr> <tr> <td>---</td> <td>[G-L]</td> <td>[G-H]</td> <td>[M-L]</td> <td>[M-H]</td> </tr> <tr> <td>FL</td> <td>✓</td> <td>✓</td> <td>✓</td> <td>✓</td> </tr> </table>	EN	Engine monit. delay time				DE	Motorverzögerung				---	[G-L]	[G-H]	[M-L]	[M-H]	FL	✓	✓	✓	✓	<p>Engine monitoring delay time 0 to 99 s</p> <hr/> <p>The engine monitoring is delayed to prevent initiating an alarm while the generator set is starting. The <i>NAC1</i> does not monitor under-voltage and –frequency and low oil pressure alarms until the delay time has expired.</p>
EN	Engine monit. delay time																				
DE	Motorverzögerung																				
---	[G-L]	[G-H]	[M-L]	[M-H]																	
FL	✓	✓	✓	✓																	

10.4 Breaker

☒	Transfer time GCB/MCB				Transfer time GCB/MCB	0.10 to 99.99 s
☒	Pasuzeit GLSNLS					
---	[G-L]	[G-H]	[M-L]	[M-H]	Switching from generator supply to mains supply or from mains supply to generator supply occurs automatically depending on the operating conditions. The time between the reply "power circuit breaker is open" and a close-pulse is set by this parameter. This time applies for both directions. During this time the busbar is dead.	
FL	---	---	✓	✓		

10.5 Emergency Power (AMF)

☒	On/Off				Emergency power monitoring On/Off	ON/OFF
☒	Ein/Aus					
---	[G-L]	[G-H]	[M-L]	[M-H]	ON If the unit is in operating mode AUTOMATIC and a mains fault according to the following parameters occurs, the engine is started and an automatic emergency operation is carried out.	
FL	---	---	✓	✓		
					OFF No emergency operation is carried out.	

☒	Mains fail delay time				Mains fail delay time	0.20 to 99.99 s
☒	Startverzögerung					
---	[G-L]	[G-H]	[M-L]	[M-H]	The minimum period of time that the monitored mains must be dead without interruption for the generator to start and carry out an emergency operation.	
FL	---	---	✓	✓		

☒	Mains settling time				Mains settling time	0 to 9,999 s
☒	Netzberuhigungszeit					
80	[G-L]	[G-H]	[M-L]	[M-H]	The NAC1 will recognise that the mains have returned and are stable after they have been detected within the rated limits without interruption for the time configured in this parameter. If the mains drop below or rise above the configured limits the timer will start over. The load transfer from generator back to mains will be delayed by this parameter after an emergency power operation.	
3	---	---	✓	✓		

10.6 Monitoring

EN	Time until horn reset				Time until horn reset	0 to 1,000 s
DE	Zeit bis Hupenreset					
01	[G-L]	[G-H]	[M-L]	[M-H]	The alarm LED flashes and the centralised alarm (horn) is issued when a new B to F class alarm is detected. After the delay time configured in "Time until horn reset" has expired, the flashing alarm LED changes to steady illumination and the centralised alarm (horn) is reset. If this parameter is configured to 0 the horn will never be set.	
1	✓	✓	✓	✓		

10.6.1 Monitoring: Generator

EN	Voltage monitoring generator				Voltage monitoring generator	fixed to 4 phase
DE	Spg. Überwachung Generator					
---	[G-L]	[G-H]	[M-L]	[M-H]	The line voltages are monitored for the setting 3Ph 3W. The star voltages are monitored for all other voltage systems.	
---	✓	✓	✓	✓		

10.6.2 Monitoring: Generator Overfrequency

EN	Monitoring				Generator overfrequency monitoring	fixed to ON
DE	Überwachung					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator overfrequency monitoring is always enabled and cannot be disabled.	
---	✓	✓	✓	✓		

EN	Limit				Generator overfrequency limit	50.0 to 130.0 %
DE	Limit					
50	[G-L]	[G-H]	[M-L]	[M-H]	① This value refers to the Rated system frequency (see page 66).	
3	✓	✓	✓	✓	The percentage threshold value that is to be monitored. If this value is reached or exceeded for at least the delay time, the action specified by the configured alarm class is initiated.	

EN	Delay				Generator overfrequency delay	0.1 to 99.9 s
DE	Verzögerung					
51	[G-L]	[G-H]	[M-L]	[M-H]	If the monitored value exceeds the threshold value for the configured delay time, an alarm will be issued. If the monitored value falls below the threshold (minus the hysteresis) before the delay expires, the delay will be reset.	
3	✓	✓	✓	✓		

EN	Alarm class				Generator overfrequency alarm class	fixed to F
DE	Alarmklasse					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator overfrequency alarm class is set to "F" and cannot be changed.	
---	✓	✓	✓	✓		

EN	Self acknowledge				Generator overfrequency self acknowledgement	fixed to NO
DE	Selbstquittierend					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator overfrequency self-acknowledgement is set to "NO" and cannot be changed. The alarm will not automatically reset after the fault condition has cleared.	
---	✓	✓	✓	✓		

10.6.3 Monitoring: Generator Underfrequency

☒	<i>Monitoring</i>				Generator underfrequency monitoring	fixed to ON
☒	<i>Überwachung</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator underfrequency monitoring is always enabled and cannot be disabled.	
---	✓	✓	✓	✓		
☒	<i>Limit</i>				Generator underfrequency limit	50.0 to 130.0 %
☒	<i>Limit</i>					
52	[G-L]	[G-H]	[M-L]	[M-H]	<div style="border: 1px solid blue; padding: 2px;"> ⓘ This value refers to the Rated system frequency. (see page 66). </div>	
3	✓	✓	✓	✓	The percentage threshold value that is to be monitored. If this value is reached or fallen below for at least the delay time, the action specified by the configured alarm class is initiated.	
☒	<i>Delay</i>				Generator underfrequency delay	0.1 to 99.9 s
☒	<i>Verzögerung</i>					
53	[G-L]	[G-H]	[M-L]	[M-H]	If the monitored value exceeds the threshold value for the configured delay time, an alarm will be issued. If the monitored value falls below the threshold (minus the hysteresis) before the delay expires, the delay will be reset.	
3	✓	✓	✓	✓		
☒	<i>Alarm class</i>				Generator underfrequency alarm class	fixed to F
☒	<i>Alarmklasse</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator underfrequency alarm class is set to "F" and cannot be changed.	
---	✓	✓	✓	✓		
☒	<i>Self acknowledge</i>				Generator underfrequency self acknowledgement	fixed to NO
☒	<i>Selbstquittierend</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator underfrequency self-acknowledgement is set to "NO" and cannot be changed. The alarm will not automatically reset after the fault condition has cleared.	
---	✓	✓	✓	✓		
☒	<i>Delayed by engine speed</i>				Generator underfrequency delayed by engine speed	fixed to YES
☒	<i>Verzögert durch Motordrehz.</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator underfrequency delay by engine speed is set to "YES" and cannot be changed. Monitoring is delayed by the time configured in Engine monitoring delay time on page 69 after starting the engine.	
---	✓	✓	✓	✓		

10.6.4 Monitoring: Generator Overvoltage

EN	Monitoring				Generator overvoltage monitoring	fixed to ON
DE	Überwachung					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator overvoltage monitoring is always enabled and cannot be disabled.	
---	✓	✓	✓	✓		
EN	Limit				Generator overvoltage limit	50.0 to 125.0 %
DE	Limit					
54	[G-L]	[G-H]	[M-L]	[M-H]	① This value refers to the Rated generator voltage (see page 66.)	
3	✓	✓	✓	✓	The percentage threshold value that is to be monitored. If this value is reached or exceeded for at least the delay time, the action specified by the configured alarm class is initiated.	
EN	Delay				Generator overvoltage delay	0.1 to 99.9 s
DE	Verzögerung					
55	[G-L]	[G-H]	[M-L]	[M-H]	If the monitored value exceeds the threshold value for the configured delay time, an alarm will be issued. If the monitored value falls below the threshold (minus the hysteresis) before the delay expires, the delay will be reset.	
3	✓	✓	✓	✓		
EN	Alarm class				Generator overvoltage alarm class	fixed to F
DE	Alarmklasse					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator overvoltage alarm class is set to "F" and cannot be changed.	
---	✓	✓	✓	✓		
EN	Self acknowledge				Generator overvoltage self acknowledgement	fixed to NO
DE	Selbstquittierend					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator overvoltage self-acknowledgement is set to "NO" and cannot be changed. The alarm will not automatically reset after the fault condition has cleared.	
---	✓	✓	✓	✓		
EN	Delayed by engine speed				Generator overvoltage delayed by engine speed	fixed to NO
DE	Verzögert durch Motordrehz.					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator overvoltage delay by engine speed is set to "NO" and cannot be changed. The monitoring is not delayed by the time configured in Engine monitoring delay time. on page 69. after starting the engine.	
---	✓	✓	✓	✓		

10.6.5 Monitoring: Generator Undervoltage

☒	<i>Monitoring</i>				Generator undervoltage monitoring	fixed to ON
☒	<i>Überwachung</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator undervoltage monitoring is always enabled and cannot be disabled.	
---	✓	✓	✓	✓		
☒	<i>Limit</i>				Generator undervoltage limit	50.0 to 125.0 %
☒	<i>Limit</i>					
56	[G-L]	[G-H]	[M-L]	[M-H]	ⓘ This value refers to the Rated generator voltage (see page 66.)	
3	✓	✓	✓	✓	The percentage threshold value that is to be monitored. If this value is reached or fallen below for at least the delay time, the action specified by the configured alarm class is initiated.	
☒	<i>Delay</i>				Generator undervoltage delay	0.1 to 99.9 s
☒	<i>Verzögerung</i>					
57	[G-L]	[G-H]	[M-L]	[M-H]	If the monitored value exceeds the threshold value for the configured delay time, an alarm will be issued. If the monitored value falls below the threshold (minus the hysteresis) before the delay expires, the delay will be reset.	
3	✓	✓	✓	✓		
☒	<i>Alarm class</i>				Generator undervoltage alarm class	fixed to F
☒	<i>Alarmklasse</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator undervoltage alarm class is set to "F" and cannot be changed.	
---	✓	✓	✓	✓		
☒	<i>Self acknowledge</i>				Generator undervoltage self acknowledgement	fixed to NO
☒	<i>Selbstquittierend</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator undervoltage self-acknowledgement is set to "NO" and cannot be changed. The alarm will not automatically reset after the fault condition has cleared.	
---	✓	✓	✓	✓		
☒	<i>Delayed by engine speed</i>				Generator undervoltage delayed by engine speed	fixed to YES
☒	<i>Verzögert durch Motordrehz.</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The generator undervoltage delay by engine speed is set to "YES" and cannot be changed. The monitoring is delayed by the time configured in Engine monitoring delay time on page 69 after starting the engine.	
---	✓	✓	✓	✓		

10.6.6 Monitoring: Mains

EN	Monitoring	Mains phase rotation monitoring	fixed to ON
DE	Überwachung		
---	[G-L] [G-H] [M-L] [M-H]	The mains phase rotation monitoring is always enabled and cannot be disabled.	
---	--- ✓ ✓		
EN	Mains phase rotation	Mains phase rotation direction	CW/CC
DE	Netzdrehfeld		
---	[G-L] [G-H] [M-L] [M-H]	CW The three-phase measured mains voltage is rotating CW (clock-wise; that means the voltage rotates in direction A-B-C-Phase; default setting).	
FL	--- ✓ ✓	CCW The three-phase measured mains voltage is rotating CCW (counter clock-wise; that means the voltage rotates in direction C-B-A-Phase).	
EN	Alarm class	Mains phase rotation alarm class	fixed to B
DE	Alarmklasse		
---	[G-L] [G-H] [M-L] [M-H]	The mains phase rotation alarm class is set to "B" and cannot be changed.	
---	--- ✓ ✓		
EN	Self acknowledge	Mains phase rotation self acknowledgement	fixed to NO
DE	Selbstquittierend		
---	[G-L] [G-H] [M-L] [M-H]	The mains phase rotation self-acknowledgement is set to "NO" and cannot be changed. The alarm will not automatically reset after the fault condition has cleared.	
---	--- ✓ ✓		
EN	Delayed by engine speed	Mains phase rotation delayed by engine speed	fixed to NO
DE	Verzögert durch Motordrehz.		
---	[G-L] [G-H] [M-L] [M-H]	The mains phase rotation delay by engine speed is set to "NO" and cannot be changed. The monitoring is not delayed by the time configured in Engine monitoring delay time on page 69 after starting the engine.	
---	--- ✓ ✓		

10.6.7 Monitoring: Mains Failure Limits

EN	High voltage threshold	Emergency power: high voltage threshold	50.0 to 130.0 %
DE	Obere Grenzspannung		
81	[G-L] [G-H] [M-L] [M-H]	① This value refers to the Rated mains voltage (see page 66).	
3	--- ✓ ✓	This value is referred to for mains failure recognition and mains estimation. If the monitored value exceeds the adjusted limit, this is recognised as a mains failure and an emergency power operation is initiated.	
EN	Low voltage threshold	Emergency power: low voltage threshold	50.0 to 130.0 %
DE	Untere Grenzspannung		
82	[G-L] [G-H] [M-L] [M-H]	① This value refers to the Rated mains voltage (see page 66).	
3	--- ✓ ✓	This value is referred to for mains failure recognition and mains estimation. If the monitored value exceeds the adjusted limit, this is recognised as a mains failure and an emergency power operation is initiated.	

EN	Voltage hysteresis			
DE	Spannungshysterese			
83	[G-L]	[G-H]	[M-L]	[M-H]
3	---	---	✓	✓

Emergency power: voltage hysteresis 0.0 to 50.0

① This value refers to the Rated mains voltage (see page 66).

This value is referred to for mains failure recognition and mains estimation. If the monitored value exceeds the adjusted limit, this is recognised as a mains failure and an emergency power operation is initiated. If the monitored value has passed a configured limit and returns but remains close to the limit, the hysteresis must be exceeded (on negative deviation monitoring) or fallen below (on exceeding monitoring) for the mains failure to be assessed as over. This must occur uninterrupted for the mains settling time (see parameter on page 70). If the monitored value returns to configured limits, the delay timer is reset to 0. See Figure 10-1.

EN	High frequency threshold			
DE	Obere Grenzfrequenz			
84	[G-L]	[G-H]	[M-L]	[M-H]
3	---	---	✓	✓

Emergency power: high frequency threshold 70.0 to 160.0

① This value refers to the Rated system frequency (see page 66).

This value is referred to for mains failure recognition and mains estimation. If the monitored value exceeds the adjusted limit, this is recognised as a mains failure and an emergency power operation is initiated.

EN	Low frequency threshold			
DE	Untere Grenzfrequenz			
85	[G-L]	[G-H]	[M-L]	[M-H]
3	---	---	✓	✓

Emergency power: low frequency threshold 70.0 to 160.0 %

① This value refers to the Rated system frequency (see page 66).

This value is referred to for mains failure recognition and mains estimation. If the monitored value exceeds the adjusted limit, this is recognised as a mains failure and an emergency power operation is initiated.

EN	Frequency hysteresis			
DE	Frequenzhysterese			
86	[G-L]	[G-H]	[M-L]	[M-H]
3	---	---	✓	✓

Emergency power: frequency hysteresis 0.0 to 50.0 %

① This value refers to the Rated system frequency. (see page 66).

This value is referred to for mains failure recognition and mains estimation. If the monitored value exceeds the adjusted limit, this is recognised as a mains failure and an emergency power operation is initiated. If the monitored value has passed a configured limit and returns but remains close to the limit, the hysteresis must be exceeded (on negative deviation monitoring) or fallen below (on exceeding monitoring) for the mains failure to be assessed as over. This must occur uninterrupted for the mains settling time (see parameter on page 70). If the monitored value returns to configured limits, the delay timer is reset to 0. See Figure 10-1.




Figure 10-1: Voltage/frequency hysteresis

10.6.8 Monitoring: Engine Overspeed

EN	Monitoring				Engine overspeed monitoring	ON/OFF
DE	Überwachung					
58	[G-L]	[G-H]	[M-L]	[M-H]	ON	Overspeed monitoring of the engine speed is carried out according to the following parameters.
3	---	✓	---	✓	OFF	No monitoring is carried out.
EN	Limit				Engine overspeed limit	0 to 9,999 RPM
DE	Limit					
59	[G-L]	[G-H]	[M-L]	[M-H]	The threshold value is set by this parameter. If this value is reached or exceeded for at least the delay time, the action specified by the configured alarm class is initiated.	
3	---	✓	---	✓		
EN	Delay				Engine overspeed delay	fixed to 0.1 s
DE	Verzögerung					
---	[G-L]	[G-H]	[M-L]	[M-H]	If the monitored value exceeds the threshold value for the configured delay time, an alarm will be issued. If the monitored value falls below the threshold (minus the hysteresis) before the delay expires, the delay will be reset.	
---	---	✓	---	✓	This value is fixed to 0.1 seconds and cannot be changed.	
EN	Alarm class				Engine overspeed alarm class	fixed to F
DE	Alarmklasse					
---	[G-L]	[G-H]	[M-L]	[M-H]	The engine overspeed alarm class is set to "F" and cannot be changed.	
---	---	✓	---	✓		
EN	Self acknowledge				Engine overspeed self acknowledgement	fixed to NO
DE	Selbstquittierend					
---	[G-L]	[G-H]	[M-L]	[M-H]	The engine overspeed self-acknowledgement is set to "NO" and cannot be changed. The alarm will not automatically reset after the fault condition has cleared.	
---	---	✓	---	✓		
EN	Delayed by engine speed				Engine overspeed delayed by engine speed	fixed to NO
DE	Verzögert durch Motordrehz.					
---	[G-L]	[G-H]	[M-L]	[M-H]	The engine overspeed delay by engine speed is set to "NO" and cannot be changed. The monitoring is not delayed by the time configured in Engine monitoring delay time on page 69 after starting the engine.	
---	---	✓	---	✓		

10.6.9 Monitoring: Engine Underspeed

☞	Monitoring	Engine underspeed monitoring	fixed to ON
☞	Überwachung	The engine underspeed monitoring is always enabled and cannot be disabled.	
---	[G-L] [G-H] [M-L] [M-H]		
---	--- ✓ --- ✓		
☞	Limit	Engine underspeed limit	fixed to 1,000 RPM
☞	Limit	The threshold value is fixed in this parameter. If this value is reached or fallen below for at least the delay time, the action specified by the configured alarm class is initiated.	
---	[G-L] [G-H] [M-L] [M-H]		
---	--- ✓ --- ✓		
☞	Delay	Engine underspeed delay	fixed to 1.0 s
☞	Verzögerung	If the monitored value falls below the threshold value for the configured delay time, an alarm will be issued	
---	[G-L] [G-H] [M-L] [M-H]	This value is fixed to 1.0 seconds and cannot be changed.	
---	--- ✓ --- ✓		
☞	Alarm class	Engine underspeed alarm class	fixed to F
☞	Alarmklasse	The engine underspeed alarm class is set to "F" and cannot be changed.	
---	[G-L] [G-H] [M-L] [M-H]		
---	--- ✓ --- ✓		
☞	Self acknowledge	Engine underspeed self acknowledgement	fixed to NO
☞	Selbstquittierend	The engine underspeed self-acknowledgement is set to "NO" and cannot be changed. The alarm will not automatically reset after the fault condition has cleared.	
---	[G-L] [G-H] [M-L] [M-H]		
---	--- ✓ --- ✓		
☞	Delayed by engine speed	Engine underspeed delayed by engine speed	fixed to YES
☞	Verzögert durch Motordrehz.	The engine underspeed delay by engine speed is set to "YES" and cannot be changed.	
---	[G-L] [G-H] [M-L] [M-H]	The monitoring is delayed by the time configured in Engine monitoring delay time on page 69 after starting the engine.	
---	--- ✓ --- ✓		

10.6.10 Monitoring: Engine Start Fail

EN	Monitoring	Engine start fail monitoring	fixed to ON
DE	Überwachung		
---	[G-L] [G-H] [M-L] [M-H]	The engine start fail monitoring is always enabled and cannot be disabled.	
---	✓ ✓ ✓ ✓		
EN	Number of start attempts	Engine number of start attempts	fixed to 3
DE	Anzahl Startversuche		
---	[G-L] [G-H] [M-L] [M-H]	The control will attempt to start the engine with the configured number of start attempts. If the engine fails to start after the configured number of attempts an alarm will be initiated.	
---	✓ ✓ ✓ ✓	An engine has been successfully started if the ignition speed has been achieved within the start delay time.	
EN	Alarm class	Engine start fail alarm class	fixed to F
DE	Alarmklasse		
---	[G-L] [G-H] [M-L] [M-H]	The engine start fail alarm class is set to "F" and cannot be changed.	
---	✓ ✓ ✓ ✓		
EN	Self acknowledge	Engine start fail self acknowledgement	fixed to NO
DE	Selbstquittierend		
---	[G-L] [G-H] [M-L] [M-H]	The engine start fail undervoltage self-acknowledgement is set to "NO" and cannot be changed. The alarm will not automatically reset after the fault condition has cleared.	
---	✓ ✓ ✓ ✓		

10.6.11 Monitoring: Engine Unintended Stop

EN	Monitoring	Engine unintended stop monitoring	fixed to ON
DE	Überwachung		
---	[G-L] [G-H] [M-L] [M-H]	The engine unintended stop monitoring is always enabled and cannot be disabled.	
---	✓ ✓ ✓ ✓		
EN	Alarm class	Engine unintended stop alarm class	fixed to F
DE	Alarmklasse		
---	[G-L] [G-H] [M-L] [M-H]	The engine unintended stop alarm class is set to "F" and cannot be changed.	
---	✓ ✓ ✓ ✓		

10.6.12 Monitoring: Battery Undervoltage

☒	<i>Monitoring</i>				Battery undervoltage monitoring	fixed to ON
☒	<i>Überwachung</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The battery undervoltage monitoring is always enabled and cannot be disabled.	
---	✓	✓	✓	✓		
☒	<i>Limit</i>				Battery undervoltage limit	8.0 to 42.0 V
☒	<i>Limit</i>					
60	[G-L]	[G-H]	[M-L]	[M-H]	The threshold value is set by this parameter. If this value is reached or fallen below for at least the delay time, the action specified by the configured alarm class is initiated.	
3	✓	✓	✓	✓		
☒	<i>Delay</i>				Battery undervoltage delay	fixed to 60.0 s
☒	<i>Verzögerung</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	If the monitored value falls below the threshold value for the delay time, an alarm will be issued.	
---	✓	✓	✓	✓	This value is fixed to 60.0 seconds and cannot be changed.	
☒	<i>Alarm class</i>				Battery undervoltage alarm class	fixed to B
☒	<i>Alarmklasse</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The battery undervoltage alarm class is set to "B" and cannot be changed.	
---	✓	✓	✓	✓		
☒	<i>Self acknowledge</i>				Battery undervoltage self acknowledgement	fixed to NO
☒	<i>Selbstquittierend</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The battery undervoltage self-acknowledgement is set to "NO" and cannot be changed.	
---	✓	✓	✓	✓	The alarm will not automatically reset after the fault condition has cleared.	
☒	<i>Delayed by engine speed</i>				Battery undervoltage delayed by engine speed	fixed to NO
☒	<i>Verzögert durch Motordrehz.</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The battery undervoltage delay by engine speed is set to "NO" and cannot be changed.	
---	✓	✓	✓	✓	The monitoring is not delayed by the time configured in Engine monitoring delay time on page 69 after starting the engine.	

10.6.13 Monitoring: Battery Charge Voltage

EN	<i>Monitoring</i>				Battery charge voltage monitoring	ON/OFF
DE	<i>Überwachung</i>					
61	[G-L]	[G-H]	[M-L]	[M-H]	ON Battery charge voltage monitoring is carried out according to the following parameters.	
3	✓	✓	✓	✓	OFF No monitoring is carried out.	
EN	<i>Limit</i>				Battery charge voltage limit	00.0 to 32.0 V
DE	<i>Limit</i>					
62	[G-L]	[G-H]	[M-L]	[M-H]	The threshold value is set by this parameter. If this value is reached or fallen below for at least the delay time, the action specified by the configured alarm class is initiated.	
3	✓	✓	✓	✓		
EN	<i>Delay</i>				Battery charge voltage delay	fixed to 10.0 s
DE	<i>Verzögerung</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	If the monitored value falls below the threshold value for the delay time, an alarm will be issued.	
---	✓	✓	✓	✓	This value is fixed to 10.0 seconds and cannot be changed.	
EN	<i>Alarm class</i>				Battery charge voltage alarm class	fixed to B
DE	<i>Alarmklasse</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The battery undervoltage alarm class is set to "B" and cannot be changed.	
---	✓	✓	✓	✓		
EN	<i>Self acknowledge</i>				Battery charge voltage self acknowledgement	fixed to NO
DE	<i>Selbstsquittierend</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The battery undervoltage self-acknowledgement is set to "NO" and cannot be changed.	
---	✓	✓	✓	✓	The alarm will not automatically reset after the fault condition has cleared.	
EN	<i>Delayed by engine speed</i>				Battery charge voltage delayed by engine speed	fixed to YES
DE	<i>Verzögert durch Motordrehz.</i>					
---	[G-L]	[G-H]	[M-L]	[M-H]	The battery undervoltage delay by engine speed is set to "YES" and cannot be changed.	
---	✓	✓	✓	✓	The monitoring is delayed by the time configured in Engine monitoring delay time on page 69 after starting the engine.	

10.6.14 Monitoring: Interface

☞	Monitoring				J1939 interface monitoring	ON/OFF
☞	Überwachung					
93	[G-L]	[G-H]	[M-L]	[M-H]	ON	J1939 interface monitoring is carried out according to the following parameters.
3	---	✓	---	✓	OFF	No monitoring is carried out.
☞	Delay				J1939 interface monitoring delay	0.1 to 650.0 s
☞	Verzögerung					
---	[G-L]	[G-H]	[M-L]	[M-H]	If a J1939 alarm is present for at least the delay time, an alarm will be issued.	
FL	---	✓	---	✓		
☞	Alarm class				J1939 interface monitoring alarm class	B/F
☞	Alarmklasse					
---	[G-L]	[G-H]	[M-L]	[M-H]	An alarm class can be assigned to the J1939 monitoring. If fault condition is detected, the action specified by the alarm class is initiated. It may be possible to configure all classes of alarms in this parameter but only alarm classes B and F are implemented in the <i>NAC1</i> Series. Ensure that only class B or F is configured here.	
FL	---	✓	---	✓		
☞	Self acknowledge				J1939 interface monitoring self acknowledgement	YES/NO
☞	Selbstquittierend					
---	[G-L]	[G-H]	[M-L]	[M-H]	YES	The control will automatically clear the alarm if it is no longer valid.
FL	---	✓	---	✓	NO	An automatic reset of the alarm does not occur. Reset of the alarm must be performed manually by pressing the appropriate buttons, by enabling the appropriate discrete input, or via an interface.
☞	Delayed by engine speed				J1939 interface monitoring delayed by engine speed	YES/NO
☞	Verzögert durch Motordrehz.					
---	[G-L]	[G-H]	[M-L]	[M-H]	YES	The J1939 monitoring is delayed by the engine. Therefore the conditions of the parameter "Engine monitoring delay time" on page 69 must be fulfilled.
FL	---	✓	---	✓	NO	The J1939 monitoring is not delayed by the engine.

10.7 Discrete Inputs

The *NAC1* Series has 5 discrete inputs (DI1 to DI5). The discrete inputs 1 & 2 are pre-defined as alarm inputs for oil pressure (DI1) and coolant temperature (DI2). The discrete input 3 is a control input for remote start. The functions of the discrete inputs 4 and 5 are dependent on the parameter Ignore CB reply (see page 67). If this parameter is set to NO, these discrete inputs are configured as reply inputs for MCB (DI4) and GCB (DI5). Any changes made to the settings of the discrete inputs DI4 and DI5 have no effect. If this parameter is set to YES, these inputs can be configured freely with the following parameters using FL-SOFT3.

EN	DI {x} operation	Discrete Input DI {x} operation	N.O./N.C.
DE	DI {x} Funktion		
---	[G-L] [G-H] [M-L] [M-H]	The discrete input can be operated by a Normally Open contact or a Normally Closed contact. The Normally Closed contact input can be used to monitor for a broken wire. A positive or negative voltage potential can be applied.	
FL	✓ ✓ ✓ ✓	N.O. The discrete input is analysed as "present" by energising a voltage potential (N.O./operating current). N.C. The discrete input is analysed as "present" by de-energising a voltage potential (N.C./idle current).	
EN	DI {x} delay	Discrete Input DI {x} delay	0.02 to 650.00 s
DE	DI {x} Verzögerung		
---	[G-L] [G-H] [M-L] [M-H]	A delay time in seconds may be assigned to each alarm input. The fault condition must be continuously present for the delay time at the input before tripping occurs.	
FL	✓ ✓ ✓ ✓		
EN	DI {x} alarm class	Discrete Input DI {x} alarm class	A/B/C/D/E/F/Control
DE	DI {x} Alarmklasse		
---	[G-L] [G-H] [M-L] [M-H]	① see chapter Alarm Classes on page 95.	
FL	✓ ✓ ✓ ✓	An alarm class can be assigned to a discrete input. The alarm class is initiated when the discrete input receives a triggering signal. Only alarm classes B and F are implemented in the <i>NAC1</i> . If "control" has been configured as the alarm class, the discrete input can be evaluated by the relay outputs if configured accordingly (see Relay Outputs on page 84 for more information).	
EN	DI {x} delayed by eng. speed	Discrete Input DI {x} delayed by engine speed	YES/NO
DE	DI {x} verzög. d. Motordrehz.		
---	[G-L] [G-H] [M-L] [M-H]	YES The input monitoring is delayed by the engine. Therefore the conditions of the parameter Engine monitoring delay time on page 69 must be fulfilled. NO The input monitoring is not delayed by the engine. The input is analysed immediately.	
FL	✓ ✓ ✓ ✓		
EN	DI {x} self acknowledge	Discrete Input DI {x} self acknowledge	YES/NO
DE	DI {x} Selbstquittierend		
---	[G-L] [G-H] [M-L] [M-H]	YES The control will automatically clear the alarm if the fault is no longer present. NO An automatic reset of the alarm does not occur. Reset of the alarm must be performed manually by pressing the appropriate buttons, by enabling the appropriate discrete input, or via an interface.	
FL	✓ ✓ ✓ ✓		

10.8 Relay Outputs

The *NAC1* Series has 6 (or 4 for [G-L] & [G-H]) relay outputs. The relay outputs 3 and 4 can be freely configured with one signal output from the list of configurable parameters in Table 10-1 (only [M-L] & [M-H]). If this signal is triggered, the relay will be operated.

<table border="1"> <tr><td>☐</td><td>Relay 1</td></tr> <tr><td>☒</td><td>Relais 1</td></tr> <tr><td>---</td><td>[G-L] [G-H] [M-L] [M-H]</td></tr> <tr><td>---</td><td>--- --- ✓ ✓</td></tr> </table>	☐	Relay 1	☒	Relais 1	---	[G-L] [G-H] [M-L] [M-H]	---	--- --- ✓ ✓	<p>Relay output 1 [M-L] & [M-H] fixed to open MCB</p> <hr/> <p>The relay output is preset to the command open MCB and cannot be changed.</p>
☐	Relay 1								
☒	Relais 1								
---	[G-L] [G-H] [M-L] [M-H]								
---	--- --- ✓ ✓								
<table border="1"> <tr><td>☐</td><td>Relay 2</td></tr> <tr><td>☒</td><td>Relais 2</td></tr> <tr><td>---</td><td>[G-L] [G-H] [M-L] [M-H]</td></tr> <tr><td>---</td><td>✓ ✓ ✓ ✓</td></tr> </table>	☐	Relay 2	☒	Relais 2	---	[G-L] [G-H] [M-L] [M-H]	---	✓ ✓ ✓ ✓	<p>Relay output 2 fixed to close GCB</p> <hr/> <p>The relay output is preset to the command open GCB and cannot be changed.</p>
☐	Relay 2								
☒	Relais 2								
---	[G-L] [G-H] [M-L] [M-H]								
---	✓ ✓ ✓ ✓								
<table border="1"> <tr><td>☐</td><td>Relay 3</td></tr> <tr><td>☒</td><td>Relais 3</td></tr> <tr><td>---</td><td>[G-L] [G-H] [M-L] [M-H]</td></tr> <tr><td>FL</td><td>--- --- ✓ ✓</td></tr> </table>	☐	Relay 3	☒	Relais 3	---	[G-L] [G-H] [M-L] [M-H]	FL	--- --- ✓ ✓	<p>Relay output 3 [M-L] & [M-H] one from configurable parameter list</p> <hr/> <p>The relay output can be configured to one signal out of the configurable parameter list. The available signals are listed below.</p>
☐	Relay 3								
☒	Relais 3								
---	[G-L] [G-H] [M-L] [M-H]								
FL	--- --- ✓ ✓								
<table border="1"> <tr><td>☐</td><td>Relay 4</td></tr> <tr><td>☒</td><td>Relais 4</td></tr> <tr><td>---</td><td>[G-L] [G-H] [M-L] [M-H]</td></tr> <tr><td>FL</td><td>✓ ✓ ✓ ✓</td></tr> </table>	☐	Relay 4	☒	Relais 4	---	[G-L] [G-H] [M-L] [M-H]	FL	✓ ✓ ✓ ✓	<p>Relay output 4 one from configurable parameter list</p> <hr/> <p>The relay output can be configured to one signal out of the configurable parameter list. The available signals are listed below.</p>
☐	Relay 4								
☒	Relais 4								
---	[G-L] [G-H] [M-L] [M-H]								
FL	✓ ✓ ✓ ✓								
<table border="1"> <tr><td>☐</td><td>Relay 5</td></tr> <tr><td>☒</td><td>Relais 5</td></tr> <tr><td>---</td><td>[G-L] [G-H] [M-L] [M-H]</td></tr> <tr><td>---</td><td>✓ ✓ ✓ ✓</td></tr> </table>	☐	Relay 5	☒	Relais 5	---	[G-L] [G-H] [M-L] [M-H]	---	✓ ✓ ✓ ✓	<p>Relay output 5 fixed to fuel relay</p> <hr/> <p>The relay output is preset to the fuel relay and cannot be changed.</p>
☐	Relay 5								
☒	Relais 5								
---	[G-L] [G-H] [M-L] [M-H]								
---	✓ ✓ ✓ ✓								
<table border="1"> <tr><td>☐</td><td>Relay 6</td></tr> <tr><td>☒</td><td>Relais 6</td></tr> <tr><td>---</td><td>[G-L] [G-H] [M-L] [M-H]</td></tr> <tr><td>---</td><td>✓ ✓ ✓ ✓</td></tr> </table>	☐	Relay 6	☒	Relais 6	---	[G-L] [G-H] [M-L] [M-H]	---	✓ ✓ ✓ ✓	<p>Relay output 6 fixed to starter</p> <hr/> <p>The relay output is preset to the starter and cannot be changed.</p>
☐	Relay 6								
☒	Relais 6								
---	[G-L] [G-H] [M-L] [M-H]								
---	✓ ✓ ✓ ✓								

The following output signals may be selected from the list of configurable parameters for the relay outputs 3 and 4. If a signal is selected for an *NAC1* version without this feature, the relay will not be triggered.

generator overfrequency	generator underfrequency	generator overvoltage
generator undervoltage	mains phase rotation mismatch [M-L], [M-H]	overspeed [G-H], [M-H]
underspeed [G-H], [M-H]	start fail	unintended stop
maintenance hours exceeded	battery undervoltage	charge alternator low voltage
discrete input 1	discrete input 2	discrete input 3
discrete input 4	discrete input 5	preglow
mode : automatic operation	all alarm classes	stopping alarm
engine released	horn	delayed close MCB [M-L], [M-H]
delayed close GCB		

Table 10-1: Relay outputs - list of configurable parameters

10.9 Counter

EN	Maintenance hours
DE	Wartungsintervall Stunden
---	[G-L] [G-H] [M-L] [M-H]
FL	✓ ✓ ✓ ✓

Maintenance hours

0 to 9,999 h

① To disable the maintenance counter "hours" configure "0".

This parameter defines the remaining hours until the next maintenance call occurs. Once the configured total time (calculated from days and hours) has been exceeded, a message is displayed.

If the parameter "Reset maintenance call" is configured to "YES" (see below) the maintenance counter is reset to the configured value.

EN	Reset maintenance period h
DE	Wartungsstunden rücksetzen
71	[G-L] [G-H] [M-L] [M-H]
1	✓ ✓ ✓ ✓

Reset maintenance period hours

YES/NO

If this parameter is configured to "YES" the maintenance counter 'Hours' is set/reset to the configured value. Once the counter has been set/reset, this parameter automatically changes back to "NO".

EN	Counter value preset
DE	Zähler-Setzwert
---	[G-L] [G-H] [M-L] [M-H]
FL	✓ ✓ ✓ ✓

Counter value preset

0 to 99,999.9

The operation hour counter is set to this value (the current value is overwritten). This counter may be used to count the operation hours.

EN	Set operation hours
DE	Betriebsstunden setzen
---	[G-L] [G-H] [M-L] [M-H]
FL	✓ ✓ ✓ ✓

Set operation hours

YES/NO

If this parameter is configured to "YES" the operation hour counter is set/reset to the configured value. Once the counter has been set/reset, this parameter automatically changes back to "NO".

EN	Number of starts
DE	Anzahl Starts
---	[G-L] [G-H] [M-L] [M-H]
FL	✓ ✓ ✓ ✓

Number of starts

0 to 65,535

The start counter is set to this value (the current value is overwritten). This counter may be used to count the number of starts.

10.10 Interfaces

10.10.1 CAN Interface

☞	Baudrate				CAN baudrate	20/50/100/125/250/500/800/1000 kBd
☞	Baudrate				The CAN bus baudrate is configured here.	
---	[G-L]	[G-H]	[M-L]	[M-H]		
FL	---	✓	---	✓		



NOTE

The baud rate is the same for all devices connected to the CAN bus regardless of the selected protocol.

10.10.2 J1939

☞	Device type				J1939 device type	Off/Standard/S6 Scania/EMR
☞	Betriebsmodus					
90	[G-L]	[G-H]	[M-L]	[M-H]	Off	The J1939 visualisation is disabled. No values are displayed.
3	---	✓	---	✓	Standard	The standard J1939 messages are displayed on the unit and in FL-SOFT3.
					S6 Scania ...	The standard J1939 messages are displayed on the unit and in FL-SOFT3, and the Scania S6 messages are displayed in FL-SOFT3 in addition. The Scania S6 messages do not appear on the unit.
					EMR	The standard J1939 messages are displayed on the unit and in FL-SOFT3, and the Deutz EMR2 messages are displayed in FL-SOFT3 in addition. The Deutz EMR2 messages do not appear on the unit.

☞	Request send address				J1939 request send address	0 to 255
☞	Request Sendeadresse					
91	[G-L]	[G-H]	[M-L]	[M-H]	The J1939 protocol device number: This is necessary for requesting special parameter groups.	
3	---	✓	---	✓	The acknowledgement command for passive alarms will also be sent with this participant address (Diagnostic Data Clear/Reset of Previously Active DTCs - DM3).	

☞	Receive device number				J1939 receive device number	0 to 255
☞	Empf. Geräte Nummer					
92	[G-L]	[G-H]	[M-L]	[M-H]	Indicates the number of the J1939 device, whose data shall be visualised.	
3	---	✓	---	✓		

You find detailed information about the J1939 protocol under J1939 Protocol Descriptions starting on page 96.

10.11 System

10.11.1 Factory Settings

EN	Factory settings FL-CABLE-RS232	Enable to reset to factory settings	ON/OFF
DE	Werkseinstellung FL-CABLE-RS232	OFF The parameters "Clear event log" and "Set default values" are disabled.	
---	[320] [320X] [350] [350X]	ON The parameters "Clear event log" and "Set default values" are enabled. The event log may be cleared and the default values may be restored.	
FL	✓ ✓ ✓ ✓		
EN	Clear event log	Clear event log	ON/OFF
DE	Ereignisspeicher löschen	OFF The event log will not be cleared.	
---	[320] [320X] [350] [350X]	ON All entries in the event logger will be cleared and this parameter will be reset to "OFF" automatically. The parameter "Factory settings" must be configured "ON" to clear the event log.	
FL	✓ ✓ ✓ ✓		
EN	Set default values	Restore default values	ON/OFF
DE	Standardwerte	OFF The default values will not be restored.	
---	[320] [320X] [350] [350X]	ON All parameters will be reset to their default values and this parameter will be reset to "OFF" automatically. The parameter "Factory settings" must be configured "ON" to restore the default values.	
FL	✓ ✓ ✓ ✓		

10.11.2 Parameter Access Level

EN	Display level	Display level	1 to 3
DE	Anzeigeebene	The user may alter the number of configurable parameters that are displayed on the control unit front panel when the unit is in configuration mode. By selecting the highest level of access (level 3), all parameters will be displayed. The lower the access level selected, the fewer parameters are displayed.	
72	[G-L] [G-H] [M-L] [M-H]		
1	✓ ✓ ✓ ✓		

10.11.4 Versions



NOTE

The following parameters are not configurable. They may be viewed using FL-SOFT3 for information purposes only.

EN	Serial number	Serial number (S/N)	display only
DE	Seriennummer		
---	[G-L] [G-H] [M-L] [M-H]	This is the serial number of the <i>NAC1</i> and identifies the control clearly.	
FL	✓ ✓ ✓ ✓		
EN	Boot item number	Boot item number (P/N)	display only
DE	Boot Artikelnummer		
---	[G-L] [G-H] [M-L] [M-H]	This is the item number of the firmware, which is stored on the <i>NAC1</i> .	
FL	✓ ✓ ✓ ✓		
EN	Boot revision	Boot revision (REV)	display only
DE	Boot Revision		
---	[G-L] [G-H] [M-L] [M-H]	This is the revision of the firmware, which is stored on the <i>NAC1</i> .	
FL	✓ ✓ ✓ ✓		
EN	Boot version	Boot version	display only
DE	Boot Version		
---	[G-L] [G-H] [M-L] [M-H]	This is the version (Vx.xxxx) of the firmware, which is stored on the <i>NAC1</i> .	
FL	✓ ✓ ✓ ✓		
EN	Program item number	Program item number	display only
DE	Programm Artikelnummer		
---	[G-L] [G-H] [M-L] [M-H]	This is the item number of the application software of the <i>NAC1</i> .	
FL	✓ ✓ ✓ ✓		
EN	Program revision	Program revision	display only
DE	Programm Revision		
---	[G-L] [G-H] [M-L] [M-H]	This is the revision of the application software of the <i>NAC1</i> .	
FL	✓ ✓ ✓ ✓		
EN	Program version	Program version	display only
DE	Programm Version		
---	[G-L] [G-H] [M-L] [M-H]	This is the version (Vx.xxxx) of the application software of the <i>NAC1</i> .	
FL	✓ ✓ ✓ ✓		

11 Event Logger

The event logger is a FIFO (First In/First Out) memory for logging alarm events and operation states of the unit. The capacity of the event logger is 15 entries. Additional event messages overwrite the oldest messages. Since the **NAC1** units do not include a clock module, the operating hours are stored with each event logger entry as the timestamp.

The individual alarm messages, which are stored in the event history, are described in detail under Alarm Messages on page 37. The operation states, which are stored in the event history, are listed in Table 11-1 on page 91.



NOTE

The event logger cannot be read out directly from the front of the unit. It can only be read out using the program GetEventLog, which can either be used as a stand alone or within FL-SOFT3.

11.1 GetEventLog Software

11.1.1 Installing GetEventLog

GetEventLog can either be used as a stand alone or within FL-SOFT3. In order to call it up from FL-SOFT3, it must be installed into the FL-SOFT3 installation path.

To install GetEventLog, start GetEventLog_vxxxxx.exe from the GetEventLog directory on the CD delivered with the unit. If you want to use GetEventLog from inside FL-SOFT3, it must be installed into the FL-SOFT3 installation directory.

11.1.2 Starting GetEventLog

Connect the **NAC1** to a free COM port on your computer using the FL-CABLE-RS232 as described under Configuration Using the PC on page 62.

Start GetEventLog directly or call it up by selecting GetEventLog from the menu Tools in FL-SOFT3.

After starting GetEventLog for the first time, you must configure the communication settings. To do this, select the Interface tab, configure the COM port according to the port, to which you have connected the FL-CABLE-RS232, and enter the other settings as represented in Figure 11-1 since these are the default settings of the **NAC1**.




Figure 11-1: GetEventLog - interface configuration

a.) Reading Out GetEventLog

On the Eventlog tab of GetEventLog, click the Request Eventlog button to read out the content of the event logger memory. The content of the event logger is displayed as shown in Figure 11-2.




Figure 11-2: GetEventLog – event logger content

The 15 latest events are displayed in chronological order and each entry is composed like this:

"sign";"operating hour";"alarm/state"

whereas "sign"+" indicates the occurrence and "-" indicates the disappearance or acknowledgement of the alarm or state
 "operating hour" serves as a timestamp and indicates the operating hour of the event occurred
 "alarm/state" indicates the type of alarm or change of state that occurred

The alarm codes are the same as displayed on the unit and described under Alarm Messages on page 37. The codes for the operation states are indicated in Table 11-1 below.

Example: The entry "+";"00008.4h";"00031A" means that alarm 31A unintended stop "00031A" occurred "+" at operating hour 8.4 "00008.4h". The operating hours are indicated in decimals, i.e. 8.4 hours are 8 hours and 24 minutes.

Number	Operation state	[G-L]	[G-H]	[M-L]	[M-H]
70	Mode: Automatic	✓	✓	✓	✓
71	Mode: Stop	✓	✓	✓	✓
72	Mode: Manual	✓	✓	✓	✓
73	GCB closed	✓	✓	✓	✓
74	GCB opened	✓	✓	✓	✓
75	MCB closed	–	–	✓	✓
76	MCB opened	–	–	✓	✓
77	Mains not in range	–	–	✓	✓
78	Emergency mode active	–	–	✓	✓
79	Engine run	✓	✓	✓	✓

Table 11-1: Event logger - operation states

b.) Storing Event Logger Data

Using the Save Eventlog button on the Eventlog tab, you are able to save the content of the event logger in CSV format (comma separated values).


11.1.3 Resetting the Event Logger

The event logger can only be reset using FL-SOFT3. To do this, perform the following steps:

- Connect the **NAC1** with your PC and start FL-SOFT3 as described in Configuration Using the PC on page 62.
- Set the parameter Factory settings FL-CABLE-RS232 to YES.
- Set the parameter Clear Even Log to YES. The event logger should be cleared.

12 Technical Data

Name plate



(Example for a typical name plate)

1	S/N	Serial number (numerical)
2	S/N	Serial number (barcode)
3	S/N	Date of production (YYMM)
4	P/N	Item number (numerical)
5	REV	Item revision number
6	P/N	Item number (barcode)
7	Details	Technical data
8	Type	Unit name
9	Type	Unit name (barcode)

Measuring values, voltages

Λ/Δ

Measuring voltages

480 Vac

Rated value (V_n) 277/480 Vac

Maximum value (V_{max}) max. 346/600 Vac

- Measuring frequency Generator 15.0 to 85.0 Hz
Mains 40.0 to 85.0 Hz
- Accuracy Class 1
- Input resistance per path 2.0 MΩ
- Maximum power consumption per path < 0.15 W

Ambient variables

- Power supply 12/24 Vdc (6.5 to 32.0 Vdc)
- Intrinsic consumption max. 10 W
- Ambient temperature Storage -20 to +85°C/-4 to +185°F
Operation -20 to +70°C/-4 to +158°F
- Ambient humidity 95 %, non condensing

Discrete inputs

isolated

- Input range (V_{Cont, digital input}) Rated voltage 12/24 Vdc (6.5 to 32.0 Vdc)
- Input resistance approx. 6.7 kΩ

Relay outputs

potential free

- Contact material AgCdO
- General purpose (GP) (V_{Cont, relay output})

AC	2.00 Aac@250 Vac
DC	2.00 Adc@24 Vdc
	0.36 Adc@125 Vdc
	0.18 Adc@250 Vdc
- Pilot duty (PD) (V_{Cont, relay output})

AC	B300
DC	1.00 Adc@24 Vdc
	0.22 Adc@125 Vdc
	0.10 Adc@250 Vdc

MPU Input

capacitive isolated

- Input impedance min. approx. 17 kΩ
- Input voltage 875 mV eff.

Pre-exciter current output D+ _____

- Max. exciter current
 - 12 Vdc (terminal 4)..... 0.11 Adc
 - 24 Vdc (terminal 3)..... 0.11 Adc

Note: The charging alternator D+ acts as an output for pre-exciting the charging alternator during engine start-up only. During regular operation, it acts as an input for monitoring the charging voltage.

Interface _____

- **Service interface**..... **non isolated**
 - VersionRS-232
 - Signal level.....5V
Level conversion and insulation by using FL-CABLE-RS232
- **CAN bus interface** **isolated**
 - Insulation voltage 1,500 Vdc
 - VersionCAN bus
 - Internal line termination Not available

Housing _____

- Dimensions (W × H × D)..... 158 × 158 × 40 mm
- Front cutout (W × H)..... 138 [+1.0] × 138 [+1.0] mm
- Connection..... screw and plug terminals 2.5 mm²
- Recommended tightening torque
 - Connectors..... 0.5 Nm
 - Housing clamps 0.1 Nm
use only 60/75 °C copper leads
use only class 1 cables (or similar)
- Weight approx. 450 g

Vibration _____

- Sinusoidal4 G, 5 Hz to 100 Hz
- Endurance 4 G, 30 Hz, 1.5 h
- Random 1.04 Grms, 10 Hz to 500 Hz, 2 h

Shock _____

- Shock40 G peak, 11 ms

Protection _____

- Protection system.....IP54 from front for proper installation with gasket pending
- Front folio insulating surface
- EMC test (CE) tested according to applicable EN guidelines
- Listings CE marking; UL listing for ordinary locations pending
- Type approval..... UL/cUL, Ordinary Locations, File No.: 231544

Standards _____

- Shock EN 60255-21-2
- Vibration EN 60255-21-1; EN 60255-21-3
- Temperature..... IEC 60068-2-30; IEC 60068-2-2; IEC 60068-2-1

13 Accuracy

Measuring value		Display	Accuracy	Notes
Frequency				
Generator	$f_{L1N'}$ $f_{L2N'}$ $f_{L3N'}$	15.0 to 85.0 Hz	0.1 %	-
Mains	$f_{L1N'}$ $f_{L2N'}$ $f_{L3N'}$	40.0 to 85.0 Hz	0.1 %	-
Voltage				
Generator	$V_{L1N'}$ $V_{L2N'}$ $V_{L3N'}$	0 to 600 V	1 %	Transformer ratio selectable
Mains	$V_{L1N'}$ $V_{L2N'}$ $V_{L3N'}$	0 to 600 V	1 %	Transformer ratio selectable
Miscellaneous				
Operating hours		0 to 99,999.9 h		-
Maintenance call		0 to 9,999 h		-
Start counter		0 to 65,535		-
Battery voltage		6.5 to 32 V	1 %	-
MPU speed		f_{in} ± 40 %		-

Reference conditions (to measure the accuracy):

- Input voltagesinusoidal rated voltage
- Frequency.....rated frequency ± 2 %
- Power supplyrated voltage ± 2 %
- Ambient temperature.....23 °C ± 2 K
- Warm-up period.....20 minutes

Common

13.1 Alarm Classes

The NAC1 Series provides only the alarm classes B & F:

Alarm class	Visible in the display	LED "Alarm" & horn	Relay "Close GCB" is de-energised	Shut-down engine	Engine blocked until ack. sequence has been passed
B	yes	yes	–	–	–
Warning Alarm This alarm does not interrupt the operation. An output of the centralised alarm occurs: ⇒ Alarm text + flashing LED "Alarm" + Relay centralised alarm (horn).					
F	yes	yes	immediately	immediately	yes
Responding Alarm With this alarm the GCB is opened immediately and the engine is stopped. ⇒ Alarm text + flashing LED "Alarm" + Relay centralised alarm (horn)+ GCB open + Engine stop.					

The alarm classes A, C, D, & E can be configured, but are intended for future software revisions **and should not be used**. The behavior of the unit is the following if configured for these alarm classes:

Alarm class	Visible in the display	LED "Alarm" & horn	Relay "Close GCB" is de-energised	Shut-down engine	Engine blocked until ack. sequence has been passed
A	yes	no	no	no	no
Warning Alarm This alarm does not interrupt the unit operation. A message output without a centralised alarm occurs at the unit: ⇒ Alarm text.					
C	yes	yes	yes	after cool down	yes
Responding Alarm With this alarm the GCB is opened and the engine is stopped. Coasting occurs. ⇒ Alarm text + flashing LED "Alarm" + Relay centralised alarm (horn) + Coasting + GCB open + Engine stop.					
D	yes	yes	yes	after cool down	yes
Responding Alarm With this alarm the GCB is opened and the engine is stopped. Coasting occurs. ⇒ Alarm text + flashing LED "Alarm" + Relay centralised alarm (horn) + Coasting + GCB open + Engine stop.					
E	yes	yes	yes	immediately	yes
Responding Alarm With this alarm the GCB is opened immediately and the engine is stopped. ⇒ Alarm text + flashing LED "Alarm" + Relay centralised alarm (horn)+ GCB open + Engine stop.					



NOTE

If the control unit is in MANUAL operation mode, a cool down phase is not performed regardless of the alarm class!

13.2 Conversion Factors

13.2.1 Conversion factors: Temperature

$^{\circ}\text{C} \Leftrightarrow ^{\circ}\text{F}$	$^{\circ}\text{F} \Leftrightarrow ^{\circ}\text{C}$
$1^{\circ}\text{F} = ([\text{Value } ^{\circ}\text{C} \times 1.8 \text{ } ^{\circ}\text{F}/^{\circ}\text{C}] + 32 \text{ } ^{\circ}\text{F})$	$1^{\circ}\text{C} = \frac{([\text{Value}] \text{ } ^{\circ}\text{F} - 32 \text{ } ^{\circ}\text{F})}{1.8 \text{ } ^{\circ}\text{F}/^{\circ}\text{C}}$

13.2.2 Conversion factors: Pressure

bar \Leftrightarrow psi	psi \Leftrightarrow bar
$1 \text{ psi} = [\text{Value}] \text{ bar} \times 14.501$	$1 \text{ bar} = \frac{[\text{Value}] \text{ psi}}{14.501}$

J1939 Protocol Descriptions

13.3 J1939 Measuring Values

These J1939 measuring values are received by the **NAC1** via CAN bus from the ECU and visualised in FL-SOFT3 using direct configuration. The PC/laptop running FL-SOFT3 must be connected to the **NAC1** via the FL-CABLE-RS232 (refer to page 29).



NOTE

The values are displayed on the unit with less accuracy. Refer to J1939 Visualisation [G-H], [MH] on page 36 for more information.

13.3.1 J1939 Standard Measuring Values

Name			Unit	Value in FL-SOFT3 with defective sensor	Value in FL-SOFT3 with missing sensor value
SPN	PGN	Description in J1939 protocol			
190	61444	Engine speed	0.1 rpm	214748364.6rpm	214748364.7rpm
247	65253	Total engine hours	1 h	2147483646h	2147483647h
110	65262	Engine coolant temperature	$^{\circ}\text{C}$	32766 $^{\circ}\text{C}$	32767 $^{\circ}\text{C}$
174	65262	Fuel temperature	1°C	32766 $^{\circ}\text{C}$	32767 $^{\circ}\text{C}$
175	65262	Engine oil temperature	0.01 $^{\circ}\text{C}$	21474836.46 $^{\circ}\text{C}$	21474836.47 $^{\circ}\text{C}$
100	65263	Engine oil pressure	1kPa	65534kPa	65535kPa
111	65263	Coolant level	0.1%	6553.4%	6553.5%
91	61443	Throttle position	0.1%	6553.4%	6553.5%
92	61443	Load at current speed	1%	65534%	65535%
513	61444	Actual engine torque	1%	32766%	32767%
98	65263	Engine oil level	0.1%	6553.4%	6553.5%
183	65266	Fuel rate	0.01 l/h	21474836.46 L/h	21474836.47 L/h
108	65269	Barometric pressure	0.1kPa	65534kPa	65535kPa
172	65269	Air inlet temperature	1°C	32766 $^{\circ}\text{C}$	32767 $^{\circ}\text{C}$
102	65270	Boost pressure	1kPa	65534kPa	65535kPa
105	65270	Intake manifold temp.	1°C	32766 $^{\circ}\text{C}$	32767 $^{\circ}\text{C}$
173	65270	Exhaust gas temperature	0.001 $^{\circ}\text{C}$	21474836.46 $^{\circ}\text{C}$	21474836.47 $^{\circ}\text{C}$

SPN = Suspect Parameter Number; PGN = Parameter Group Number

13.3.2 Special EMR messages

Type	Message acc. to EMR manual	Display in FL-SOFT3
0	Engine stop information	no stop
1	Engine safety	Type 1: Engine safety
2	CAN message engine stop request	Type 2: CAN message engine stop request
3	Low oil pressure	Type 3: low oil pressure
4	Low oil level	Type 4: low oil level
5	High coolant temp	Type 5: high coolant temp
6	Low coolant level	Type 6: low coolant level
7	Intake manifold temp	Type 7: intake manifold temp
8	Reserved (Stop via SAEJ1587)	Type 8: reserved (Stop via SAEJ1587)
9	Reserved (Stop via VP2)	Type 9: reserved (Stop via VP2)



NOTE

These parameters are only visible in FL-SOFT3 and are not displayed on the unit.

13.3.3 Special S6 messages

Suspect Parameter Number	Parameter Group Number	Description	Display in FL-SOFT3
DLN2-Proprietary	65409 (FF81h)	Assessed messages: Low engine oil level High engine oil level Low oil pressure High coolant temperature	NO Sensor defect YES

If DLN2 does not transmit, "missing" is displayed in FL-SOFT3.



NOTE

These parameters are only visible in FL-SOFT3 and are not displayed on the unit.

Front Customisation

The *NAC1* Series is designed language-independent, but can be customised to your demands using paper strips. The left paper strip is intended for customisation and may contain more detailed information about the display.

The right paper strip is divided in three parts. The lowest part serves for labelling the unit indicators (refer to Display of the Operating Values on page 33). You can customise the paper strip to reflect the unit of measure in your preferred language. The middle section serves for labelling the four configurable alarm flags (refer to Alarm Messages on page 37). You can customise the paper strip to reflect the alarm message assigned to the respective flag in your preferred language. The upper field is intended for customisation and may contain more detailed information about the display.




Figure 13-1: Paper strips

The unit is delivered with English paper strips, where the left paper strip contains the alarm messages and the right paper strip contains the units of measure in English, the default alarm messages for the alarm flags, and information about the configuration parameters in the upper section.

Templates for paper strips in different languages can be found in the "Paper Strips" directory on the CD delivered with the unit. The templates are in Microsoft Word format and can be customised to your demands. Please note that the paper strip geometry must not be modified in the templates. Just edit the text in the paper strips, print them out, cut out the paper strips where indicated, and insert them into the openings at the side of the unit.

Troubleshooting

If problems are encountered while commissioning or operating the **NAC1**, please refer to the troubleshooting table below and FL-SOFT3 prior to contacting SEG for technical assistance. The most common problems and their solutions are described in the troubleshooting table. If problems are encountered between the **NAC1** and its wiring and the engine or other devices, refer to the respective manuals for solving the problem.

Symptom	Possible cause	Possible solution	Verify
Unit does not power up.	Power supply outside operating range.	With power supply voltage connected to terminals 1(-) and 2(+) of the NAC1 , measure the voltage at these terminals.	Voltage must be no less than 6.5 Volts and no greater than 32 Volts.
	Power supply polarity reversed.	With power supply voltage connected to terminals 1(-) and 2(+) of the NAC1 , measure the voltage at these terminals.	Voltage measurement reads (+) polarity when meter is connected to terminal 1(-), and 2(+).
Alarm "60A - Oil pressure" occurs, after engine has fired.	Engine produces no oil pressure.	Check engine oil pressure.	Refer to chapter "Chapter 8 - Functional Description of the Oil Pressure Input DI1" for more information.
	Oil pressure sensor is miswired.	Check wiring of the oil pressure sensor.	A "Normally Closed" contact from the oil pressure sensor must be wired to terminals 16/15 on the NAC1 .
	Incorrect oil pressure sensor is being used.	Verify the correct sensor is being used.	Refer to chapter "Chapter 8 - Functional Description of the Oil Pressure Input DI1" for more information.
	Oil pressure sensor is defective.	Check the oil pressure sensor.	Check oil pressure sensor for proper functionality and obstructions.
Alarm "61A - Coolant temperature" occurs after engine has fired.	Engine temperature is too high.	Check engine temperature.	Engine temperature must be within its specified range.
	Coolant temperature sensor is miswired.	Check wiring of the temperature sensor.	A "Normally Open" contact must be wired from the sensor to the NAC1 (terminals 17/15).
	Coolant temperature sensor is defective.	Check coolant temperature sensor.	Check coolant temperature sensor for proper functionality.
Engine does not start by pressing the "Start" button.	Unit is in operating mode "Stop" and the "Stop" LED is lit.	Unit must be in operating mode "Manual".	Press the "Operating Mode" button twice for selecting manual mode.
Engine does not start by setting the "Remote-Start" signal (discrete input 3).	Unit is in operating mode "Stop".	Unit must be in operating mode "Auto" to be started via "Remote-Start" signal.	Press the "Operating Mode" button for selecting "Auto" mode.
	Unit is in operating mode "Manual".	Unit must be in operating mode "Auto" to be started via "Remote-Start" signal.	Press the "Operating Mode" button for selecting "Auto" mode.
	"Remote-Start" signal is miswired to the NAC1 .	Measure the voltage between terminals 18/15.	If you set the "Remote Start" signal, you should measure a voltage between terminals 18/15. If a voltage is present at these terminals, everything is wired correctly.

Symptom	Possible cause	Possible solution	Verify
"Generator Circuit Breaker Closed" LED is not lit, although the Circuit Breaker is closed.	"Generator Circuit Breaker Closed" signal is miswired.	Measure the voltage between terminals 20 and 15 on the NAC1 .	If the circuit breaker is closed, you should measure around 0 Volts between terminals 20 and 15. If around 0 Volts are measured, the "Generator Circuit Breaker Closed" LED should be lit. If the circuit breaker is open, you should measure a voltage similar to the battery voltage in your system between terminals 20 and 15. In this case the "Generator Circuit Breaker Closed" LED must not be lit. Check whether you are using an N.C. contact as breaker aux. contact.
	Wrong setting of Parameter "Ignore Breaker Replies".	Use the "FL-SOFT3" configuration software to check for correct setting of the Parameter "Ignore Breaker Replies".	Within the FL-SOFT3 configuration software, the parameter "Ignore Breaker Replies" must be set to "No" to enable the MCB reply state to be visualised on the "Generator Circuit Breaker Closed" LED. If the parameter "Ignore Breaker Replies" is set to "Yes", the state of the CB reply will not be recognised!
"Mains Circuit Breaker Closed" LED is not lit, although the Circuit Breaker is closed.	"Mains Circuit Breaker Closed" signal is miswired.	Measure the voltage between terminals 19 and 15 on the NAC1 .	If the circuit breaker is closed, you should measure around 0 Volts between terminals 19 and 15. If around 0 Volts are measured, the "Mains Circuit Breaker Closed" LED should be lit. If the circuit breaker is open, you should measure a voltage similar to the battery voltage in your system between terminals 19 and 15. In this case the "Mains Circuit Breaker Closed" LED must not be lit. Check whether you are using an N.C. contact as breaker aux. contact.
	Wrong setting of Parameter "Ignore Breaker Replies".	Use the "FL-SOFT3" configuration software to check for correct setting of the Parameter "Ignore Breaker Replies".	Within the FL-SOFT3 configuration software, the parameter "Ignore Breaker Replies" must be set to "No" to enable the MCB reply state to be visualised on the "Mains Circuit Breaker Closed" LED. If the parameter "Ignore Breaker Replies" is set to "Yes", the state of the CB reply will not be recognised!

Symptom	Possible cause	Possible solution	Verify
Alarm "30A - Start fail" occurs.	Low fuel situation.	Check, if enough Fuel is present to run the engine.	Fuel level is above fuel pick-up and fuel system is properly primed
	Fuel line connection to the engine is not present.	Check whether the fuel line to engine is installed properly.	No leaks in fuel system and system is primed
	Generator produces no voltage.	Check, if the generator is excited properly.	While the crank is engaged the generator shall produce voltage.
	Fuel relay output of the NAC1 is defective or miswired.	Measure the resistance between terminals 13 and 11 on the NAC1 .	Case 1, Parameter "Fuel Relay Logic" is set to "Open to Stop": If engine is not started, the resistance between terminals 13 and 11 must be around infinite Ohms. If the NAC1 performs an start, the resistance between terminals 13 and 11 must be around 0 Ohms. Case 2, Parameter "Fuel Relay Logic" is set to "Close to Stop": If engine is not started, the resistance between terminals 13 and 11 must be around 0 Ohms. If the NAC1 performs an start, the resistance between terminals 13 and 11 must be around infinite Ohms.
	Crank Relay output of the NAC1 is defective or miswired.	Measure the resistance between terminals 14 and 11 on the NAC1 .	If engine is not started, the resistance between terminals 14 and 11 must be around infinite Ohms. If the NAC1 performs an start, the resistance between terminals 14 and 11 must be around 0 Ohms.
	Pickup Sensor is miswired to the NAC1 .	Check whether the Pickup sensor is properly wired to terminals 37(GND) and 38(+) on the NAC1 .	The NAC1 requires 2 Vac for the MPU during cranking cycle. If this voltage is not achieved perhaps the gap between the pickup and the gear is too much.
Starter is not engaged.	Parameter crank cutout speed is set too low	The crank cutout speed must be between the cranking speed and the normal operating speed of the engine	Measure engine speed when cranking engines, before ignition.
	Starting relay output of the NAC1 is defective or miswired.	Measure the resistance between terminals 14 and 11 on the NAC1 .	If engine is not running, the resistance between terminals 14 and 11 should read infinite Ohms. If the NAC1 performs a start, the resistance between terminals 14 and 11 must be around 0 Ohms.

Symptom	Possible cause	Possible solution	Verify
Alarm "21A - Underspeed" occurs, after engine has fired.	Pickup Sensor is miswired to the NAC1 .	Check whether the pickup sensor is properly wired to terminals 37 (GND) and 38(+) on the NAC1 .	The NAC1 requires 2 Vac for the MPU during cranking cycle. If this voltage is not achieved perhaps the gap between the pickup and the gear is too much.
	Pickup Sensor is defective.	Check the pickup sensor for proper functionality.	The NAC1 requires 2 Vac for the MPU during cranking cycle. If this voltage is not achieved perhaps the gap between the pickup and the gear is too much.
	Engine has stalled.	Check to see if engine fuel level is too low or fuel line is blocked or lost prime. Possible problem with engine air flow.	Troubleshoot engine fuel and air supply. Check air and fuel filters.
Alarm "13A - Generator under-voltage" occurs, after the engine has fired.	Generator voltages are not properly connected to the NAC1 .	Check generator voltages if engine is started up.	Measure the generator voltages on the terminals 29/31/33/35 while the engine is running. (Please refer to the wiring diagram for your NAC1 derivate, because the terminal assignment is different from derivate to derivate.)
	Wrong wiring selected for the generator voltage measurement.	Use the FL-SOFT3 configuration software to check for settings of parameter "Generator voltage measuring"	Check, which wiring you have to use, and then set the parameter "Generator voltage measuring" via FL-SOFT3 to one of the following selections : - 1Ph2W - 1Ph3W - 3Ph3W - 3Ph4W Note: These wirings are only selectable in the NAC1/X units! See "Chapter 6 - Connections - Voltage measurement Generator" for further details.
	Voltage regulator is not set correctly	Adjust voltage regulator rated voltage or remote voltage setting.	

Symptom	Possible cause	Possible solution	Verify
CAN/J1939 Communication does not work.	The parameter for enabling the J1939 Communication is configured "Off" in the <i>NAC1</i> .	Check for setting of Parameter 90 "J1939 Device Type" in the configuration menu of the <i>NAC1</i> .	Parameter 90 "J1939 Device Type" must be set to a value greater than "1" to enable a J1939/CAN communication. Refer to "Chapter 7 - Operation and Navigation - Configuration Displays" and "Parameters – Interfaces" for further information.
	Baud rate for CAN communication is set to an incorrect value.	Check that the correct baud rate is entered	The baud rate has to be the same for all devices connected to the CAN bus.
	Termination resistors are not correct.	Check whether the termination resistors are of the correct resistive value.	Refer to chapter "Connections - Interfaces" for further information on termination resistors.
	CAN connection is miswired.	Check whether the correct CAN lines are connected to terminals 39 (CAN-L) and 40 (CAN-H).	Refer to chapter "Connections - Interfaces" for further information on termination resistors.
	Wrong setting of parameter "Request send address".	Check whether you have selected the correct request send address.	Refer to chapter "Configuration Displays" and "Parameters – Interfaces" for further information.
	Wrong setting of parameter "Receive Device Number".	Check whether you have selected the correct receive device number.	Refer to chapter "Configuration Displays" and "Parameters – Interfaces" for further information.
Engine overspeeds on startup.	Engine governor is not set correctly.	Adjust governor settings for proper response.	Refer to governor manual.
	The Parameter for overspeed level is not set correctly.	Set the correct speed for overspeed.	
	The Parameter for Number of Pickup Teeth is not correct.	Check that this setting is correct for the engine.	Refer to engine specification.
Alarm 12 "Over-voltage" occurs on startup.	Voltage regulator is not set correctly	Adjust voltage regulator settings for proper response.	Refer to AVR manual.
Alarm "51A - Charge failure" occurs after the engine has fired, and the "Engine monitoring delay time" has expired.	Charge alternator is miswired to the <i>NAC1</i> .	If charge alternator with 24 Volts are used, connect it to terminals 1 (-) and 3 (+). If charge alternator with 12 Volts are used, connect it to terminals 1 (-) and 4 (+).	Please Refer to "Chapter 8 - Functional Description of the Charging Alternator Input/Output" for further information.
	Charge alternator polarity reversed.	With charge alternator connected to terminals 1 (-) and 3 (+) [for 24 Volt charge alternators] or 1 (-) and 4 (+) [for 12 Volt charge alternators] of the <i>NAC1</i> , measure the voltage at these terminals.	Voltage measurement reads (+) polarity when meter is connected to terminal 1 (-), and 3 (+) or 1 (-) and 4 (+). Please Refer to "Chapter 8 - Functional Description of the Charging Alternator Input/Output" for further information.
	Charge alternator defective.	Check charge alternator output.	Ensure charge alternator output is within specifications.

List of Parameters

Unit number P/N _____ Rev _____

Version NAC 1 _____

Project _____

Serial number S/N _____ Date _____

	Parameter	Setting range	Default value	Customer setting
--	-----------	---------------	---------------	------------------

MEASURING				
	Rated system frequency	50/60 Hz	50 Hz	
	Rated voltage generator	50 to 480 V	400 V	
[M-x]	Rated voltage mains	50 to 480 V	400 V	
[x-H]	Generator voltage measuring	3ph 4w 3ph 3w 1ph 2w 1ph 3w	3ph 4w	<input type="checkbox"/> 3ph 4w <input type="checkbox"/> 3ph 4w <input type="checkbox"/> 3ph 3w <input type="checkbox"/> 3ph 3w <input type="checkbox"/> 1ph 2w <input type="checkbox"/> 1ph 2w <input type="checkbox"/> 1ph 3w <input type="checkbox"/> 1ph 3w
[x-L]	Generator voltage measuring	1ph 2w	1ph 2w	n/a n/a
[M-H]	Mains voltage measuring	3ph 4w 3ph 3w 1ph 2w 1ph 3w	3ph 4w	<input type="checkbox"/> 3ph 4w <input type="checkbox"/> 3ph 4w <input type="checkbox"/> 3ph 3w <input type="checkbox"/> 3ph 3w <input type="checkbox"/> 1ph 2w <input type="checkbox"/> 1ph 2w <input type="checkbox"/> 1ph 3w <input type="checkbox"/> 1ph 3w
[M-L]	Mains voltage measuring	3ph 4w	3ph 4w	n/a n/a

APPLICATION				
	Ignore CB reply	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
	2nd GCB Close Delay Time	0.00 to 650.00 s	0.20 s	
[M-x]	2nd MCB Close Delay Time	0.00 to 650.00 s	0.20 s	

ENGINE				
Engine type: Diesel				
	Fuel relay	open to stop/close to stop	open to stop	<input type="checkbox"/> open <input type="checkbox"/> open <input type="checkbox"/> close <input type="checkbox"/> close
[G-x]	Preglow time	0 to 300 s	0 s	
[M-x]	Preglow time	0 to 300 s	3 s	
MPU (pickup)				
[x-H]	Speed Pickup	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
[x-H]	Nominal speed	500 to 4,000 RPM	1,500 RPM	
[x-H]	Number of gear teeth	5 to 260	118	
Start/stop automatic				
	Starter time	1 to 10 s	8 s	
	Start pause time	10 to 99 s	10 s	
	Cool down time	0 to 999 s	30 s	
	Crank termination by DI1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
	Engine Monit. delay time	0 to 99 s	8 s	

BREAKER				
[M-x]	Transfer time GCBCB	0.10 to 99.99 s	0.10 s	

EMERGENCY POWER (AMF)				
[M-x]	On/Off	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
[M-x]	Mains fail delay time	0.20 to 99.99 s	3.00 s	
[M-x]	Mains settling time	0 to 9,999 s	20 s	

	Parameter	Setting range	Default value	Customer setting	
PROTECTION					
	Time until horn reset	0 to 1,000 s	180 s		
Generator protection					
	Voltage monitoring generator	4 phase	4 phase	n/a	n/a
Generator: Over frequency					
	Monitoring	ON	ON	n/a	n/a
	Limit	50.0 to 130.0 %	110.0 %		
	Delay	0.1 to 99.9 s	1.0 s		
	Alarm class	F	F	n/a	n/a
	Self acknowledge	NO	NO	n/a	n/a
Generator: Under frequency					
	Monitoring	ON	ON	n/a	n/a
	Limit	50.0 to 130.0 %	90.0 %		
	Delay	0.1 to 99.9 s	5.0 s		
	Alarm class	F	F	n/a	n/a
	Self acknowledge	NO	NO	n/a	n/a
	Delayed by engine speed	YES	YES	n/a	n/a
Generator: Over voltage					
	Monitoring	ON	ON	n/a	n/a
	Limit	50.0 to 125.0 %	110.0 %		
	Delay	0.1 to 99.9 s	2.0 s		
	Alarm class	F	F	n/a	n/a
	Self acknowledge	NO	NO	n/a	n/a
	Delayed by engine speed	NO	NO	n/a	n/a
Generator: Under voltage					
	Monitoring	ON	ON	n/a	n/a
	Limit	50.0 to 125.0 %	92.0 %		
	Delay	0.1 to 99.9 s	5.0 s		
	Alarm class	F	F	n/a	n/a
	Self acknowledge	NO	NO	n/a	n/a
	Delayed by engine speed	YES	YES	n/a	n/a
Mains protection					
[M-x]	Monitoring	ON	ON	n/a	n/a
[M-x]	Mains phase rotation	CW (+)/CCW (-)	CW	<input type="checkbox"/> + <input type="checkbox"/> -	<input type="checkbox"/> + <input type="checkbox"/> -
[M-x]	Alarm class	B	B	n/a	n/a
[M-x]	Self acknowledge	NO	NO	n/a	n/a
[M-x]	Delayed by engine speed	NO	NO	n/a	n/a
Emergency power: Limits					
[M-x]	High voltage threshold	50.0 to 130.0 %	130.0 %		
[M-x]	Low voltage threshold	50.0 to 130.0 %	90.0 %		
[M-x]	Voltage hysteresis	0.0 to 50.0 %	2.0 %		
[M-x]	High frequency threshold	70.0 to 160.0 %	110.0 %		
[M-x]	Low frequency threshold	70.0 to 160.0 %	90.0 %		
[M-x]	Frequency hysteresis	0.0 to 50.0 %	2.0 %		
Engine: Overspeed					
[x-H]	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
[x-H]	Limit	0 to 9,999 RPM	1,850 RPM		
[x-H]	Delay	0.1 s	0.1 s	n/a	n/a
[x-H]	Alarm class	F	F	n/a	n/a
[x-H]	Self acknowledge	NO	NO	n/a	n/a
[x-H]	Delayed by engine speed	NO	NO	n/a	n/a
Engine: Underspeed					
[x-H]	Monitoring	ON	ON	n/a	n/a
[x-H]	Limit	1,000 RPM	1,000 RPM	n/a	n/a
[x-H]	Delay	1.0 s	1.0 s	n/a	n/a
[x-H]	Alarm class	F	F	n/a	n/a
[x-H]	Self acknowledge	NO	NO	n/a	n/a

MONITORING

[x-H]	Delayed by engine speed	YES	YES	n/a	n/a
Engine: Start fail					
	Monitoring	ON	ON	n/a	n/a
	Number of start attempts	3	3	n/a	n/a
	Alarm class	F	F	n/a	n/a
	Self acknowledge	NO	NO	n/a	n/a
Engine: Unintended stop					
	Monitoring	ON	ON	n/a	n/a
	Alarm class	F	F	n/a	n/a
Battery: Undervoltage					
	Monitoring	ON	ON	n/a	n/a
	Limit	8.0 to 42.0 V	10.0 V		
	Delay	60.0 s	60.0 s	n/a	n/a
	Alarm class	B	B	n/a	n/a
	Self acknowledge	NO	NO	n/a	n/a
	Delayed by engine speed	NO	NO	n/a	n/a
Battery: charge voltage					
	Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Limit	0.0 to 32.0 V	16.0 V		
	Delay	10.0 s	10.0 s	n/a	n/a
	Alarm class	B	B	n/a	n/a
	Self acknowledge	NO	NO	n/a	n/a
	Delayed by engine speed	YES	YES	n/a	n/a
Interface: J1939					
[x-H]	Monitoring	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
[x-H]	Delay	0.1 to 650.0 s	20.0 s		
[x-H]	Alarm class	B/F	B		
[x-H]	Self acknowledge	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
[x-H]	Delayed by engine speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

DISCRETE INPUTS

Discrete input [DI1] oil pressure					
	DI 1 operation	N.C.	N.C.	n/a	n/a
	DI 1 delay	0.5 s	0.5 s	n/a	n/a
	DI 1 alarm class	F	F	n/a	n/a
	DI 1 delayed by eng. speed	YES	YES	n/a	n/a
	DI 1 self acknowledge	NO	NO	n/a	n/a
Discrete input [DI2] coolant temperature					
	DI 2 operation	N.C.	N.C.	n/a	n/a
	DI 2 delay	1.0 s	1.0 s	n/a	n/a
	DI 2 alarm class	F	F	n/a	n/a
	DI 2 delayed by eng. speed	YES	YES	n/a	n/a
	DI 2 self acknowledge	NO	NO	n/a	n/a
Discrete input [DI3] remote start					
	DI 3 operation	N.C.	N.C.	n/a	n/a
	DI 3 delay	0.02 s	0.02 s	n/a	n/a
	DI 3 alarm class	Control	Control	n/a	n/a
	DI 3 delayed by eng. speed	NO	NO	n/a	n/a
	DI 3 self acknowledge	NO	NO	n/a	n/a
Discrete input [DI4] reply MCB or freely configurable If parameter "Ignore CB reply" is set to "YES", this input is freely configurable					
	DI 4 operation	N.O./N.C.	N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
	DI 4 delay	0.02 to 650.00 s	0.00 s		
	DI 4 alarm class	A/B/C/D/E/F/Control	Control		
	DI 4 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	DI 4 self acknowledge	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Discrete input [DI5] reply GCB or freely configurable If parameter "Ignore CB reply" is set to "YES", this input is freely configurable					
	DI 5 operation	N.O./N.C.	N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.	<input type="checkbox"/> N.O. <input type="checkbox"/> N.C.
	DI 5 delay	0.02 to 650.00 s	0.00 s		
	DI 5 alarm class	A/B/C/D/E/F/Control	Control		
	DI 5 delayed by eng. speed	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	DI 5 self acknowledge	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

DIGITAL OUTPUTS					
[M-x]	Relay 1	Command: open MCB	open MCB	n/a	n/a
	Relay 2	Command: close GCB	close GCB	n/a	n/a
[M-x]	Relay 3	one from configurable parameter list (see end of table)	Preglow		
	Relay 4	one from configurable parameter list (see end of table)	stopping alarm		
	Relay 5	Fuel relay	Fuel relay	n/a	n/a
	Relay 6	Starter	Starter	n/a	n/a
	Relay 7	internal relay			

COUNTER					
	Maintenance hours	0 to 9,999 h	300 h		
	Reset maintenance period h	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Counter value preset	0 to 99,999.9 h	-		
	Set operation hours	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Number of starts	0 to 65,535	-		

COMM. INTERFACES					
[x-H]	CAN Interfaces				
	Baudrate	20/50/100/125/250/ 500/800/1000 kBd	125 kBd		
	J1939				
[x-H]	Device type	Off/Standard/S6 Scania/EMR	Standard		
[x-H]	Request send address	0 to 255	3		
[x-H]	Receive device number	0 to 255	0		

SYSTEM

Codes				
Factory settings FL-CABLE-RS232	ON / OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
Clear event log	ON / OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
Set default values	ON / OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
Display level	1 to 3	1		
Flag 1 gen. overfreq. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 gen. underfreq. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 gen. overvolt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 gen. undervolt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 mains rot. field alarm	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 overspeed 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 underspeed 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 unintended stop	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 start fail	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 maintenance hours exc.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 J1939 CAN Error	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 undervolt. aux. alt.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 undervolt. batt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 DI 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 DI 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 DI 3	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 DI 4	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 1 DI 5	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 gen. overfreq. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 gen. underfreq. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 gen. overvolt. 1	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 gen. undervolt. 1	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 mains rot. field alarm	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 overspeed 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 underspeed 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 unintended stop	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 start fail	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 maintenance hours exc.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 J1939 CAN Error	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 undervolt. aux. alt.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 undervolt. batt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 DI 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 DI 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 DI 3	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 DI 4	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
Flag 2 DI 5	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

SYSTEM					
Flag 3 gen. overfreq. 1	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 gen. underfreq. 1	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 gen. overvolt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 gen. undervolt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 mains rot. field alarm	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 overspeed 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 underspeed 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 unintended stop	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 start fail	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 maintenance hours exc.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 J1939 CAN Error	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 undervolt. aux. alt.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 undervolt. batt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 DI 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 DI 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 DI 3	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 DI 4	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 3 DI 5	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 gen. overfreq. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 gen. underfreq. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 gen. overvolt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 gen. undervolt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 mains rot. field alarm	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 overspeed 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 underspeed 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 unintended stop	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 start fail	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 maintenance hours exc.	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 J1939 CAN Error	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 undervolt. aux. alt.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 undervolt. batt. 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 DI 1	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 DI 2	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 DI 3	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 DI 4	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Flag 4 DI 5	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N	
Versions					
Serial number	Info	–			
Boot item number	Info	–			
Boot revision	Info	–			
Boot version	Info	–			
Program item number	Info	–			
Program revision	Info	–			
Program version	Info	–			

[x-H] applies only to NAC1-G-H and M-H
 [G-x] applies only to NAC1-G-L and G-H
 [M-L] applies only to NAC1-M-L

[x-L] applies only to NAC1-G-L and M-L
 [M-x] applies only to NAC1-M-L and M-H
 [M-H] applies only to NAC1-M-H

The output signals, which may be selected from the list of configurable parameters for the discrete inputs 1 and 4, are listed in Table 10-1 on page 84.



NOTE

All parameters shaded in gray colour are fixed parameters and cannot be configured by the operator. The "light gray" parameters for DI4 & DI 5 can be configured if the parameter "Ignore CB reply" is set to "YES".



Woodward SEG GmbH & Co. KG

Krefelder Weg 47 · D – 47906 Kempen (Germany)

Postfach 10 07 55 (P.O.Box) · D – 47884 Kempen (Germany)

Phone: +49 (0) 21 52 145 1

Internet

Homepage <http://www.woodward-seg.com>

Documentation <http://doc.seg-pp.com>

Sales

Phone: +49 (0) 21 52 145 635 · Telefax: +49 (0) 21 52 145 354

e-mail: kemp.electronics@woodward.com

Service

Phone: +49 (0) 21 52 145 614 · Telefax: +49 (0) 21 52 145 455

e-mail: kemp.pd@woodward.com