



**MRI4 – Profibus DP
HighPROTEC**

Data point list

Manual DOK-TD-MRI4PDE

Table of Contents

| | |
|--------------------------------|----------|
| TABLE OF CONTENTS | 2 |
| PROFIBUS | 3 |
| Configuration..... | 3 |
| DATA POINT LISTS | 4 |
| Signals..... | 4 |
| Measuring values..... | 10 |
| Commands..... | 11 |

This manual applies to devices (version):

Version 3.4.a

Build: 35596

Profibus

The Slave is a so-called “Modular Slave”. Within the GSD-File the optional available Configuration Modules are described only. The precise configuration for a device can be inquired by means of the Profibus-Command “GetConfig”. The configuration consists of so-called “Modules”. The description of the modules can be taken from the Profibus specification. Please contact the Technical Support in case of questions regarding the configuration. The meaning of the Input and Output fields can be taken from the following tables. The input fields are sent from the Slave to the Master. The output fields are sent from the Master to the Slave. The Output field contain the Commands and the Input field contain the States of the device.

Configuration

The configuration telegram follows right after the parameter telegram and declares the number of input and output bytes. The Master sends to all Slaves how many bytes for each input and output message cycle are required. The following table defines the required size of a single input and output frame.

| <i>Direction</i> | <i>Length</i> | <i>Configuration</i> |
|-------------------------|----------------------|-----------------------------|
| Input | 44 | 0x1F 0x1F 0x1b |
| Output | 8 | 0x27 |

Data Point Lists

Signals

These Data can be taken from the Input Field of the Profibus. The Input Field is sent from the Slave to the Master and it contains device states.

| Module (- ANSI / IEEE Device Number) | Names Function | Offset (BytePosition/BitPosition) | Self Latching | Description |
|---|---------------------------------|--|----------------------|--|
| SG[1] | Pos | 0/0 | | Signal: Circuit Breaker Position (0 = Indeterminate, 1 = OFF, 2 = ON, 3 = Disturbed) |
| Sys | PS 1 | 2/0 | | Signal: Parameter Set 1 |
| Sys | PS 2 | 2/1 | | Signal: Parameter Set 2 |
| Sys | PS 3 | 2/2 | | Signal: Parameter Set 3 |
| Sys | PS 4 | 2/3 | | Signal: Parameter Set 4 |
| Profibus | Data OK | 2/4 | | Data within the Input field are OK (Yes=1) |
| Prot | active | 2/5 | | Signal: active |
| Prot | Alarm L1 | 2/6 | | Signal: General-Alarm L1 |
| Prot | Alarm L2 | 2/7 | | Signal: General-Alarm L2 |
| Prot | Alarm L3 | 3/0 | | Signal: General-Alarm L3 |
| Prot | Alarm G | 3/1 | | Signal: General-Alarm - Earth fault |
| Prot | Alarm | 3/2 | | Signal: General Alarm |
| Prot | Trip L1 | 3/3 | * | Signal: General Trip L1 |
| Prot | Trip L2 | 3/4 | * | Signal: General Trip L2 |
| Prot | Trip L3 | 3/5 | * | Signal: General Trip L3 |
| Prot | Trip G | 3/6 | * | Signal: General Trip Ground fault |
| Prot | Trip | 3/7 | * | Signal: General Trip |
| Profibus | Assignment 1-I | 5/0 | | Module input state: Scada Assignment |
| Profibus | Assignment 2-I | 5/1 | | Module input state: Scada Assignment |

Data Point Lists

| Module (- ANSI / IEEE Device Number) | Names Function | Offset (BytePosition/BitPosition) | Self Latching | Description |
|---|---------------------------|--|----------------------|--------------------------------------|
| Profibus | Assignment 3-I | 5/2 | | Module input state: Scada Assignment |
| Profibus | Assignment 4-I | 5/3 | | Module input state: Scada Assignment |
| Profibus | Assignment 5-I | 5/4 | | Module input state: Scada Assignment |
| Profibus | Assignment 6-I | 5/5 | | Module input state: Scada Assignment |
| Profibus | Assignment 7-I | 5/6 | | Module input state: Scada Assignment |
| Profibus | Assignment 8-I | 5/7 | | Module input state: Scada Assignment |
| Profibus | Assignment 9-I | 6/0 | | Module input state: Scada Assignment |
| Profibus | Assignment 10-I | 6/1 | | Module input state: Scada Assignment |
| Profibus | Assignment 11-I | 6/2 | | Module input state: Scada Assignment |
| Profibus | Assignment 12-I | 6/3 | | Module input state: Scada Assignment |
| Profibus | Assignment 13-I | 6/4 | | Module input state: Scada Assignment |
| Profibus | Assignment 14-I | 6/5 | | Module input state: Scada Assignment |
| Profibus | Assignment 15-I | 6/6 | | Module input state: Scada Assignment |
| Profibus | Assignment 16-I | 6/7 | | Module input state: Scada Assignment |
| Profibus | Assignment 17-I | 7/0 | | Module input state: Scada Assignment |
| Profibus | Assignment 18-I | 7/1 | | Module input state: Scada Assignment |
| Profibus | Assignment 19-I | 7/2 | | Module input state: Scada Assignment |

Data Point Lists

| Module (- ANSI / IEEE Device Number) | Names Function | Offset (BytePosition/BitPosition) | Self Latching | Description |
|---|---------------------------|--|----------------------|--------------------------------------|
| Profibus | Assignment 20-l | 7/3 | | Module input state: Scada Assignment |
| Profibus | Assignment 21-l | 7/4 | | Module input state: Scada Assignment |
| Profibus | Assignment 22-l | 7/5 | | Module input state: Scada Assignment |
| Profibus | Assignment 23-l | 7/6 | | Module input state: Scada Assignment |
| Profibus | Assignment 24-l | 7/7 | | Module input state: Scada Assignment |
| Profibus | Assignment 25-l | 8/0 | | Module input state: Scada Assignment |
| Profibus | Assignment 26-l | 8/1 | | Module input state: Scada Assignment |
| Profibus | Assignment 27-l | 8/2 | | Module input state: Scada Assignment |
| Profibus | Assignment 28-l | 8/3 | | Module input state: Scada Assignment |
| Profibus | Assignment 29-l | 8/4 | | Module input state: Scada Assignment |
| Profibus | Assignment 30-l | 8/5 | | Module input state: Scada Assignment |
| Profibus | Assignment 31-l | 8/6 | | Module input state: Scada Assignment |
| Profibus | Assignment 32-l | 8/7 | | Module input state: Scada Assignment |
| SG[1] | TripCmd | 9/0 | * | Signal: Trip Command |
| I[1] - 50, 51 | Alarm | 10/0 | | Signal: Alarm |
| I[1] - 50, 51 | TripCmd | 10/1 | * | Signal: Trip Command |

Data Point Lists

| Module (- ANSI / IEEE Device Number) | Names Function | Offset (BytePosition/BitPosition) | Self Latching | Description |
|---|---------------------------------|--|----------------------|--|
| I[2] - 50, 51 | Alarm | 10/2 | | Signal: Alarm |
| I[2] - 50, 51 | TripCmd | 10/3 | * | Signal: Trip Command |
| I[3] - 50, 51 | Alarm | 10/4 | | Signal: Alarm |
| I[3] - 50, 51 | TripCmd | 10/5 | * | Signal: Trip Command |
| I[4] - 50, 51 | Alarm | 10/6 | | Signal: Alarm |
| I[4] - 50, 51 | TripCmd | 10/7 | * | Signal: Trip Command |
| IG[1] - 50N, 51N | Alarm | 11/0 | | Signal: Alarm IG |
| IG[1] - 50N, 51N | TripCmd | 11/1 | * | Signal: Trip Command |
| IG[2] - 50N, 51N | Alarm | 11/2 | | Signal: Alarm IG |
| IG[2] - 50N, 51N | TripCmd | 11/3 | * | Signal: Trip Command |
| ThR - 49 | Alarm | 11/4 | | Signal: Alarm Thermal Overload |
| ThR - 49 | TripCmd | 11/5 | * | Signal: Trip Command |
| I2>[1] - 46 | Alarm | 11/6 | | Signal: Alarm Negative Sequence |
| I2>[1] - 46 | TripCmd | 11/7 | * | Signal: Trip Command |
| I2>[2] - 46 | Alarm | 12/0 | | Signal: Alarm Negative Sequence |
| I2>[2] - 46 | TripCmd | 12/1 | * | Signal: Trip Command |
| IH2 | Blo L1 | 12/2 | | Signal: Blocked L1 |
| IH2 | Blo L2 | 12/3 | | Signal: Blocked L2 |
| IH2 | Blo L3 | 12/4 | | Signal: Blocked L3 |
| IH2 | Blo IG meas | 12/5 | | Signal: Blocking of the ground (earth) protection module (measured ground current) |
| IH2 | 3-ph Blo | 12/6 | | Signal: Inrush was detected in at least one phase - trip command blocked. |
| Exp[1] | Alarm | 12/7 | | Signal: Alarm |
| Exp[1] | TripCmd | 13/0 | * | Signal: Trip Command |

Data Point Lists

| Module (- ANSI / IEEE Device Number) | Names Function | Offset (BytePosition/BitPosition) | Self Latching | Description |
|---|---------------------------------|--|----------------------|---|
| ExP[2] | Alarm | 13/1 | | Signal: Alarm |
| ExP[2] | TripCmd | 13/2 | * | Signal: Trip Command |
| ExP[3] | Alarm | 13/3 | | Signal: Alarm |
| ExP[3] | TripCmd | 13/4 | * | Signal: Trip Command |
| ExP[4] | Alarm | 13/5 | | Signal: Alarm |
| ExP[4] | TripCmd | 13/6 | * | Signal: Trip Command |
| CBF - 50BF, 62BF | Alarm | 13/7 | | Signal: Circuit Breaker Failure |
| TCS - 74TC | Alarm | 14/0 | | Signal: Alarm Trip Circuit Supervision |
| CTS - 60L | Alarm | 14/1 | | Signal: Alarm Current Transformer Measuring Circuit Supervision |
| SG[1] | Isum Intr trip | 14/2 | * | Signal: Maximum permissible Summation of the interrupting (tripping) currents exceeded in at least one phase. |
| DI Slot X1 | DI 1 | 14/3 | | Signal: Digital Input |
| DI Slot X1 | DI 2 | 14/4 | | Signal: Digital Input |
| DI Slot X1 | DI 3 | 14/5 | | Signal: Digital Input |
| DI Slot X1 | DI 4 | 14/6 | | Signal: Digital Input |
| DI Slot X1 | DI 5 | 14/7 | | Signal: Digital Input |
| DI Slot X1 | DI 6 | 15/0 | | Signal: Digital Input |
| DI Slot X1 | DI 7 | 15/1 | | Signal: Digital Input |
| DI Slot X1 | DI 8 | 15/2 | | Signal: Digital Input |
| BO Slot X2 | BO 1 | 15/3 | | Signal: Binary Output Relay |
| BO Slot X2 | BO 2 | 15/4 | | Signal: Binary Output Relay |
| BO Slot X2 | BO 3 | 15/5 | | Signal: Binary Output Relay |
| BO Slot X2 | BO 4 | 15/6 | | Signal: Binary Output Relay |
| BO Slot X2 | BO 5 | 15/7 | | Signal: Binary Output Relay |
| CLPU | detected | 16/0 | | Signal: Cold Load detected |

Data Point Lists

| Module (- ANSI / IEEE Device Number) | Names Function | Offset (BytePosition/BitPosition) | Self Latching | Description |
|---|---------------------------------|--|----------------------|---|
| SOTF | active | 16/1 | | Signal: active |
| SOTF | I< | 16/2 | | Signal: No Load Current. |
| SOTF | enabled | 16/3 | | Signal: Switch Onto Fault enabled. This Signal can be used to modify Overcurrent Protection Settings. |

Measuring values

These Data can be taken from the Input Field of the Profibus. The Input Field is sent from the Slave to the Master and contains device states.

| Module (- ANSI / IEEE Device Number) | Names Functions | Offset (BytePosition) | Format | Description |
|---|----------------------------------|--|---------------|--|
| CT | IL1 | 20/0 | Float IEEE754 | Measured value: Phase current (fundamental) |
| CT | IL2 | 24/0 | Float IEEE754 | Measured value: Phase current (fundamental) |
| CT | IL3 | 28/0 | Float IEEE754 | Measured value: Phase current (fundamental) |
| CT | IG meas | 32/0 | Float IEEE754 | Measured value (measured): IG (fundamental) |
| CT | %(I2/I1) | 36/0 | Float IEEE754 | Measured value (calculated): I2/I1, phase sequence will be taken into account automatically. |
| Values | Operating hours Cr | 40/0 | Float IEEE754 | Operating hours counter of the protective device |

Commands

The commands are set within the Output Field. These data fields are sent from the master to the slave. The slave will respond on data modifications only. For example if a 2 Bit state changes from Off (01) to On (2).

| Module (- ANSI / IEEE Device Number) | Names Function | Offset (BytePosition/BitPosition) in Output field | Description |
|--|-------------------------------------|--|---|
| SG[1] | Control/Position of circuit breaker | 0/0 | Control respectively Position of circuit breaker (1 = OFF, 2 = On). |
| Sys | Ack LED | 2/0 | All acknowledgeable LEDs will be acknowledged. |
| Sys | Ack BO | 2/2 | All acknowledgeable binary output relays will be acknowledged. |
| Sys | Ack Scada | 2/4 | SCADA will be acknowledged. |
| PSS via Scada | PSS via Scada | 3/0 | Signal: Parameter Set Switch via Scada. Write into this output byte the integer of the parameter set that should become active (e.g. 4 => Switch onto parameter set 4). |
| Commands | Scada Cmd 1 | 4/0 | Scada Command |
| Commands | Scada Cmd 2 | 4/2 | Scada Command |
| Commands | Scada Cmd 3 | 4/4 | Scada Command |
| Commands | Scada Cmd 4 | 4/6 | Scada Command |
| Commands | Scada Cmd 5 | 5/0 | Scada Command |
| Commands | Scada Cmd 6 | 5/2 | Scada Command |
| Commands | Scada Cmd 7 | 5/4 | Scada Command |
| Commands | Scada Cmd 8 | 5/6 | Scada Command |
| Commands | Scada Cmd 9 | 6/0 | Scada Command |
| Commands | Scada Cmd 10 | 6/2 | Scada Command |
| Commands | Scada Cmd 11 | 6/4 | Scada Command |
| Commands | Scada Cmd 12 | 6/6 | Scada Command |
| Commands | Scada Cmd 13 | 7/0 | Scada Command |

Data Point Lists

| Module (- ANSI / IEEE Device Number) | Names Function | Offset (BytePosition/BitPosition) in Output field | Description |
|---|---------------------------------|--|--------------------|
| Commands | Scada Cmd 14 | 7/2 | Scada Command |
| Commands | Scada Cmd 15 | 7/4 | Scada Command |
| Commands | Scada Cmd 16 | 7/6 | Scada Command |

We appreciate your comments about the content of our publications.

Please send comments to: kemp.doc@woodward.com

Please include the manual number from the front cover of this publication.

Woodward Kempen GmbH reserves the right to update any portion of this publication at any time. Information provided by Woodward Kempen GmbH is believed to be correct and reliable. However, Woodward Kempen GmbH assumes no responsibility unless otherwise expressly undertaken.
© Woodward Kempen GmbH, all rights reserved



Woodward Kempen GmbH

Krefelder Weg 47 · D – 47906 Kempen (Germany)
Postfach 10 07 55 (P.O.Box) · D – 47884 Kempen (Germany)
Phone: +49 (0) 21 52 145 1

Internet

www.woodward.com

Sales

Phone: +49 (0) 21 52 145 331 or +49 (0) 711 789 54 510
Fax: +49 (0) 21 52 145 354 or +49 (0) 711 789 54 101
e-mail: SalesPGD_EUROPE@woodward.com

Service

Phone: +49 (0) 21 52 145 600
Fax: +49 (0) 21 52 145 455
e-mail: SupportPGD_Europe@woodward.com