

MANUAL

 Function Line
 PROTECTION TECHNOLOGY

 BL18
 POWER SUPPLY AND BATTERY CHARGING UNIT



POWER SUPPLY AND BATTERY CHARGING UNIT

Original document

English

Revision: B

SEG Electronics reserves the right to update any portion of this publication at any time. Information provided by SEG Electronics is believed to be correct and reliable. However, no responsibility is assumed by SEG Electronics unless otherwise expressly undertaken.

© SEG Electronics 1994–2020. All rights reserved.

Table of Content

1.	Application	4
2.	Characteristics and Features	5
3.	Functions and Adjustments	6
3.	.1 Mounting and Connecting	6
3.	.2 Application as stabilized power pack supply unit	7
3.	.3 Application as battery charger	7
	3.3.1 Battery charging in compliance with I-V - Characteristics	7
3.	.4 Reduction of the power output	8
4.	Technical Data	9
5.	Order form	12

1. Application

The *BL18* is a versatile direct voltage supply unit that can be applied both, as battery charger and as stabilized power pack supply unit.

If applied as battery charger, the *BL18* serves to either charge or to maintain closed or gas-proof 24 V lead-acid batteries in full charge condition by providing the facility to simultaneously supply consumers with DC current (parallel operation). When the *BL18* is operated in parallel with a battery or with another consumer and the battery has to be disconnected, e.g. for maintenance or exchange, the supply of this consumer will be backed-up to the battery charger's nominal capacity.

Thanks to the unit's short-circuit capacity, it must not be switched off in case of short-circuit type occurrences, such as e.g. start of an Diesel engine or similar situations.

As stabilized power pack supply unit, the *BL18* supplies connected consumers with a stabilized DC voltage that can be adjusted within a range of 24V to 27.5 V and/or 12 V to 24 V.

Attention!

The internal over voltage protection of the BL18 is up to the standards as per EN6100-4-5 whereas particular over voltage situations (e.g. lightning effects, switching actions, converter reactions etc) that might occur in switchgear assemblies, may lead to an overload and even destruction of the unit's internal protection.

For the energy coordination of an external over voltage limitation, it is therefore essential that the device-internal over voltage protection function of the BL18-400 will be available from a line-to-line voltage of \geq 624 Vac_rms and up! For the voltage limitation, star connected metal-oxide varistors (MOV) of the type S14K320 are applied.

In case that the coordination with external over voltage protection can not be realized or ensured, we would recommend to connect impedances in series with the mains supply inputs of the *BL18-400* in order to assure the energy limitation of the device's internal over voltage protection.

2. Characteristics and Features

- Input voltage 3x380-500VAC ±10%
- Safety according to VDE 0805/EN 60950
- Surge voltage stability according to EN 6100-4-5
- High stability of output voltage
- Low residual ripple
- High efficiency
- Screw type and plug-in connectors
- Suppression of radio interferences acc. to VDE 0875/T11/EN 55011, class B
- Interference immunity according to EN 50082-2
- Short-circuit and no-load proof
- Compact housing
- Low weight (1.9 kg)
- Snap-on fastening on DIN rail
- Indication of working condition (via LED)

3. Functions and Adjustments

Apart from the lower plug-and-socket connector, the *BL18* is equipped with a trimming potentiometer for the adjustment of the output voltage (see fig. 3.1). By means of a normal slotted screwdriver, the output voltage can be adjusted within a range of 24 v to 27.5 V and from 12 V to 14 V. Turning the screwdriver to the left reduces and turning it to the right increases the output voltage. The LED at the front plate of the unit indicates readiness for operation.



Figure 3.1: Secondary side connecting terminals and trimming potentiometer for the output voltage

3.1 Mounting and Connecting

To allow best possible cooling, the proper mounting position has to be unconditionally observed taking into account that input terminals (L1/L2/L3/PE or L1/N/PE) have to be placed on top and the output terminals (+/-) at the bottom.

There must be a head space of at least 100 mm above and below and of at least 30 mm at both sides of the *BL18* device.

The inlet air temperature must not exceed the admissible ambient temperature specified in the technical data.

Connection of the three-phase input voltage is to be made according to the scheme that is printed on the housing of the unit. For this purpose it is not necessary to observe the indicated phase sequence. The feed lines (= primary sides?) of the unit should be protected by either a three-pole L-miniature circuit breaker or via a three-pole motor protecting switch (adjusted to 2.5 A). It is not allowed to operate the unit if one of the phases had failed. The protected earth (PE) of the BL18 and protected earth of the switchboard have to be connected. Installation of the switchboard has to be carried out in compliance with the regulations VDE 0100 and VDE 0160.





Netz / Line 3~ 400VAC ± 15% 50 / 60Hz



Figure 3.2: Mains Connection

Attention!

For all servicing or installation works, the locally valid safety instructions have to be observed.

The secondary side plug connectors have two parallel connection terminals per pole (+/-) but the current can also be carried by one terminal only.

3.2 Application as stabilized power pack supply unit

As a stabilized power pack supply unit, the BL18 provides a constant output voltage that – each depending on the selected adjustment value - ranges from 24 V to 27.5 V/DC or from 12 V to 14 V/DC.

The output voltage is maintained up to the rated current's load value. If this value is exceeded, the output voltage will automatically be reduced.



3.3 Application as battery charger

For the loading of lead acid batteries at normal temperatures up to 30°C, the trickle charge voltage recommended by battery manufacturers is 2.25 V per cell, i.e. the trickle charge voltage for a 24 V lead-acid battery would be 27 V per cell. At higher ambient temperatures, charging voltages have to be reduced and must be increased accordingly in case of external voltage losses. The factory default setting for the units BL18-400-24 and BL18-230-24 is an output voltage of 27 V/DC.

3.3.1 Battery charging in compliance with I-V – Characteristics

Charging is effected according to I-V characteristics (see fig. 3.4). The initial discharge capacity / rating is high, i.e. approx. 21 - 23 A (I-charge). During discharging of batteries a high initial charging current of approx. 21-23 A (I-charge) flows that is limited by the BL18. As soon as the charging voltage reaches the adjusted value (trickle charge voltage) there is transition to charging at constant voltage (U-charge). In doing so the charging current will decrease until the unit supplies a lower trickle current and the current that is possibly required by connected consumers. In this case the advantage of this charging method - compared to loading at constant current - becomes quite obvious: The reduction of current upon reaching of the trickle charge voltage avoids overcharge of the battery thus preventing inadmissibly high generation of gas which would be the case if a high charging continued flowing after the battery's full charge.



Figure 3.4: Charging acc. to IU-characteristic

3.4 Reduction of the power output

At an ambient temperature of more than 60°C the load capacity of the unit will decrease proportional as shown in the diagram below.



Figure 3.5: Reduction of the power output

To avoid overheating of the units, it is necessary to reduce the consumer load accordingly.

4. Technical Data

General Data

Type: Permissible operating time: Connection terminals: Type of cooling: Maintenance: Short circuit: No-load: Mounting position:	<i>BL18</i> continuous operation max. 2.5 mm ² (wire connection) convection cooling none sustained short circuit proof sustained no-load proof wall mounting, input terminals on top, output terminals at bottom
Input Circuit (three-phase)	
Input voltage: Over voltage protection: Application (1 mA-value): Energy absorbtion: Input rated current: Frequency range: In-rush current: Power factor cosφ: Fuse:	3 x 380-500VAC ±10 star connected metal-oxide varistors (MOV) S14K320 510 V (single varistor) 84 J (2 ms) (single varistor) 3 x 1.5 A (24 V type)/3 x 0,8 A (12 V type) 47 - 63 Hz 50 A 0.55 capacitive three-pole miniature c.b. or motor protection switch setting 2.5 A)
Input Circuit (single-phase)	
Input voltage: Input rated current:	$\begin{array}{rl} 1 \ x \ 230 \ V \ AC & \pm 15\% \ at \ U_{sec} = 24 \ V \ DC/18 \ A, \\ & + 15\%/-10\% \ at \ U_{sec} = 27.5 \ V \ DC/18 \ A \\ 4.4 \ A \ (24 \ V \ type)/2.4 \ A \ (12 \ V \ type) \end{array}$
Output Circuit	
Output voltage: Setting range: Max. output current: Limitation of current: Output: Residual ripple: Efficiency: Max. power loss: Load capacity of output terminals:	27 V DC ±1% / 13,5 V DC ±1% (preset by manufacturer) 24 - 27.5 V (24 V type)/12 - 14 V (12 V type) 18 A typically 20 A, starting point at 18.5 21.5 A limit point at 20.0 26.0 A 480 W <100 mV 90% 53 W <20 A at Tu = 0°C up to ±45°C
	0.2 A- reduction/°C from +45°C to \leq 17 A at T _U = +60°C
Regulation	
Mains regulation: Load regulation: Correction time:	<0.1% of the output voltage at $U_{mains} \pm 15\%$ <0.1% of the output voltage between 0 and 20 A <2 ms at a load change from 10 to 90% of rated current, overshooting <2%
Mains failure bridging time:	>5 ms at U_{mains} = 400 V AC and U_{sec} = 24 V DC / 16 A

Tests and regulations

Radio-interference suppression: Static discharge ESD, IEC 801-2:

Electromagnetic fields, IEC 801-3: Burst IEC 801-4:

Surge IEC 801-5, EN 6100-4-5:

Safety rules

Test voltage:

CE

pression: IEC 801-2:	VDE 0875 p 8 kV contact 15 kV air dis	art 11, EN 55011 class B t discharge scharge
IEC 801-3:	10 V/m	5
	4 kV input 2 kV output,	capacitive coupling
100-4-5:	4 kV asymm	etric, 4 kV symmetric
	VDE 0805/1	1.93, EN 60950, IEC 950
	3 kV AC :	all safety relevant components
	1.5 kV DC:	finished product between primary and secondary side
	1.5 kV DC:	finished product between primary and protection earth
	0.5 kV DC:	finished product between secondary and protection earth
	class I IP20	
	<0.75 mA (4	7 - 63 Hz mains frequency and $U_{mains, max}$)

Operating data

protection class: Degree of protection: Discharge current:

Temperature range	during operation:	0 to +70°C, with free convection
	during storage:	-25 to +85°C
Derating of output:	2.5 %/K above +60°C (see Fig.3.5)	

Housing

Dimensions (Width x Height x Depth):240 mm x 130 mm (153 mm) x 86 mmSpace for convection:above and below the unit 100 mm, at the sides 30 mmWeight:approx.1.9 kgMounting:DIN-rail mounting acc.to DIN EN 50022-35





Figure 4.1: Housing dimensions

All dimensions in mm!

Please observe!

A free space of at least 100 mm must be left above and below the *BL18*, and of at least 30 mm at both sides.

5. Order form

Power supply and battery charging unit BL18 -		
Output current 18 A		
Input voltage 230 V 1-phase 400/530 V 3-phase	230 400	
Output voltage 12 V (12 - 13.75 V DC) 24 V (24 - 27.5 V DC)		12 24



Function Line

https://docs.SEGelectronics.de/bl18



SEG Electronics GmbH reserves the right to update any portion of this publication at any time. Information provided by SEG Electronics GmbH is believed to be correct and reliable. However, SEG Electronics GmbH assumes no responsibility unless otherwise expressly undertaken.



SEG Electronics GmbH Krefelder Weg 47 • D-47906 Kempen (Germany) Postfach 10 07 55 (P.O.Box) • D-47884 Kempen (Germany) Telephone: +49 (0) 21 52 145 1

Internet: www.SEGelectronics.de

Sales Telephone: +49 (0) 21 52 145 331 Fax: +49 (0) 21 52 145 354 E-mail: info@SEGelectronics.de

Service Telephone: +49 (0) 21 52 145 614 Fax: +49 (0) 21 52 145 354 E-mail: info@SEGelectronics.de

SEG Electronics has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address / phone / fax / email information for all locations is available on our website.

MANUAL | BL18