



MCDGV4 – IEC60870-5-103
HighPROTEC

Data point list

Manual DOK-TD-MCDGV4IDE

Table of Contents

PHYSICAL LAYER.....	3
LINK LAYER.....	3
APPLICATION LAYER.....	4
DATA POINTS LIST.....	8
Signals.....	8
Measuring Values.....	49
Commands.....	54
Analog Traces.....	56

This manual applies to devices (version):

Version 2.4.a

Build: 24038

Physical layer

Electrical interface

EIA RS-485

Number of loads for one equipment: 32

Optical interface

Glass fibre

F-SMA type connector

Plastic fibre

BFOC/2,5 type connector

Transmission speed

9600 bit/s

19200 bit/s

38400 bit/s

Link Layer

There are no choices for the link layer

Application layer

Transmission mode for application data Mode 1 (least significant octet first) as defined in 4.10 of IEC 60870-5-4

Common address of ADSU

- | | |
|--|---|
| <input checked="" type="checkbox"/> One common address of ADSU
(identical with station address) | <input type="checkbox"/> More than one common address of ASDU |
|--|---|

Selection of standard information numbers in monitor direction

System functions in monitor direction

- | | |
|--|--|
| <input checked="" type="checkbox"/> 0 = End of general interrogation | <input checked="" type="checkbox"/> 0 = Time synchronization |
| <input checked="" type="checkbox"/> 2 = Reset FCB | <input checked="" type="checkbox"/> 3 = Reset CU |
| <input checked="" type="checkbox"/> 4 = Start/Restart | <input checked="" type="checkbox"/> 5 = Power on |

Application layer

Measurands in monitor direction

- | | |
|--|--|
| <input type="checkbox"/> 144 Measurand I | <input type="checkbox"/> 145 Measurands I,V |
| <input type="checkbox"/> 146 Measurand I, V,P,Q | <input type="checkbox"/> 147 Measurands I _N , V _{EN} |
| <input checked="" type="checkbox"/> 148 Measurands I _{L1,2,3} , V _{L1,2,3} , P, Q, f | |

Generic functions in monitor direction

- | | |
|---|--|
| <input type="checkbox"/> 240 Read headings of all defined groups | <input type="checkbox"/> 241 Read values of all entries of one group |
| <input type="checkbox"/> 243 Read directory of a single entry | <input type="checkbox"/> 244 Read value of a single entry |
| <input type="checkbox"/> 245 End of general interrogation of generic data | <input type="checkbox"/> 249 Write entry with confirmation |
| <input type="checkbox"/> 250 Write entry with execution | <input type="checkbox"/> 251 Write entry aborted |

Selection of standard information numbers in control direction

System functions in control direction

- | | |
|---|--|
| <input checked="" type="checkbox"/> 0 = Initiation of general interrogation | <input checked="" type="checkbox"/> 0 Time synchronization |
|---|--|

General commands in control direction

- | | |
|--|--|
| <input checked="" type="checkbox"/> 16 Auto-recloser on/off | <input checked="" type="checkbox"/> 17 Teleprotection on/off |
| <input checked="" type="checkbox"/> 18 Protection on/off | <input checked="" type="checkbox"/> 19 LED reset |
| <input checked="" type="checkbox"/> 23 Activate characteristic 1 | <input checked="" type="checkbox"/> 24 Activate characteristic 2 |
| <input checked="" type="checkbox"/> 25 Activate characteristic 3 | <input checked="" type="checkbox"/> 26 Activate characteristic 4 |

Generic functions in control direction

- | | |
|--|--|
| <input type="checkbox"/> 240 Read headings of all defined groups | <input type="checkbox"/> 241 Read values of all entries of one group |
| <input type="checkbox"/> 243 Read directory of a single entry | <input type="checkbox"/> 244 Read value of a single entry |
| <input type="checkbox"/> 245 General interrogation of generic data | <input type="checkbox"/> 248 Write entry |
| <input type="checkbox"/> 249 Write entry with confirmation | <input type="checkbox"/> 250 Write entry with execution |
| <input type="checkbox"/> 251 Write entry abort | |

Basic application functions

- | | |
|--|--|
| <input type="checkbox"/> Test mode | <input type="checkbox"/> Blocking of monitor direction |
| <input checked="" type="checkbox"/> Disturbance data | <input type="checkbox"/> Generic services |
| <input checked="" type="checkbox"/> Private data | |

Miscellaneous

Measurand	max. value = rated value x	
	1.2	2.4
Current L ₁	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Current L ₂	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Current L ₃	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Voltage L _{1-E}	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Voltage L _{2-E}	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Voltage L _{3-E}	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Voltage L ₁ – L ₂	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Active power P	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Reactive power Y	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Frequency f	<input checked="" type="checkbox"/>	<input type="checkbox"/>

Data Points List

Signals

<i>Module</i>	<i>Subgroups Names Functions</i>	<i>Function Type ASDU</i>	<i>Function (FUN)</i>	<i>Information Number (INF)</i>	<i>Device Interrogation</i>	<i>Description</i>
Prot	active	1	178	18	GI	Signal: active
PSet-Switch	min 1 param changed	1	178	22	GI	Signal: At least one parameter has been changed
DI Slot X 1	DI 1	1	178	27	GI	Signal: Digital Input
DI Slot X 1	DI 2	1	178	28	GI	Signal: Digital Input
DI Slot X 1	DI 3	1	178	29	GI	Signal: Digital Input
DI Slot X 1	DI 4	1	178	30	GI	Signal: Digital Input
CTS	Alarm	1	178	32	GI	Signal: Alarm Current Transformer Measuring Circuit Supervision
Prot	IG meas dir fwd	1	178	51	GI	Signal: Ground fault (measured) forward
Prot	IG meas rev dir	1	178	52	GI	Signal: Ground fault (measured) reverse direction
Prot	Alarm L1	2	178	64	GI	Signal: General-Alarm L1
Prot	Alarm L2	2	178	65	GI	Signal: General-Alarm L2
Prot	Alarm L3	2	178	66	GI	Signal: General-Alarm L3
Prot	Alarm G	2	178	67	GI	Signal: General-Alarm - Earth fault
Prot	Trip	2	178	68		Signal: General Trip
Prot	Trip L1	2	178	69		Signal: General Trip L1
Prot	Trip L2	2	178	70		Signal: General Trip L2

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Prot	Trip L3	2	178	71		Signal: General Trip L3
Prot	I dir fwd	2	178	74		Signal: Phase current failure forward direction
Prot	I dir rev	2	178	75		Signal: Phase current failure reverse direction
Prot	Alarm	2	178	84	GI	Signal: General Alarm
CBF	Alarm	2	178	85		Signal: Circuit Breaker Failure
I[1]	TripCmd	2	178	90		Signal: Trip Command
I[2]	TripCmd	2	178	91		Signal: Trip Command
IG[1]	TripCmd	2	178	92		Signal: Trip Command
IG[2]	TripCmd	2	178	93		Signal: Trip Command
Ctrl	Local	1	178	160	GI	Switching Authority: Local
Id	active	1	30	50	GI	Signal: active
Id	Blo TripCmd	1	30	60	GI	Signal: Trip Command blocked
Id	Trip L1	2	30	90		Signal: Trip System Phase L1
Id	Trip L2	2	30	91		Signal: Trip System Phase L2
Id	Trip L3	2	30	92		Signal: Trip System Phase L3
Id	TripCmd	2	30	93		Signal: Trip Command
Id	Alarm	2	30	100	GI	Signal: Alarm
Id	Alarm L1	2	30	101	GI	Signal: Alarm System Phase L1
Id	Alarm L2	2	30	102	GI	Signal: Alarm System Phase L2
Id	Alarm L3	2	30	103	GI	Signal: Alarm System L3

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Id	Restraining	1	30	120	GI	Signal: Restraining of the differential protection by means of rising the tripping curve.
Id	Transient	1	30	121	GI	Signal: Temporary stabilization of the differential protection afterwards the transformer is being energized.
Id	IH2 Blo L1	1	30	122	GI	Signal:Phase L1: Blocking of the Phase Differential Protection because of second Harmonic.
Id	IH2 Blo L2	1	30	123	GI	Signal:Phase L2: Blocking of the Phase Differential Protection because of second Harmonic.
Id	IH2 Blo L3	1	30	124	GI	Signal:Phase L3: Blocking of the Phase Differential Protection because of second Harmonic.
Id	IH4 Blo L1	1	30	125	GI	Signal:Phase L1: Blocking of the Phase Differential Protection because of fourth Harmonic.
Id	IH4 Blo L2	1	30	126	GI	Signal:Phase L2: Blocking of the Phase Differential Protection because of fourth Harmonic.
Id	IH4 Blo L3	1	30	127	GI	Signal:Phase L3: Blocking of the Phase Differential Protection because of fourth Harmonic.
Id	IH5 Blo L1	1	30	128	GI	Signal:Phase L1: Blocking of the Phase Differential Protection because of fifth Harmonic.

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Id	IH5 Blo L2	1	30	129	GI	Signal:Phase L2: Blocking of the Phase Differential Protection because of fifth Harmonic.
Id	IH5 Blo L3	1	30	130	GI	Signal:Phase L3: Blocking of the Phase Differential Protection because of fifth Harmonic.
IdH	active	1	31	50	GI	Signal: active
IdH	Blo TripCmd	1	31	60	GI	Signal: Trip Command blocked
IdH	Trip L1	2	31	90		Signal: Trip System Phase L1
IdH	Trip L2	2	31	91		Signal: Trip System Phase L2
IdH	Trip L3	2	31	92		Signal: Trip System Phase L3
IdH	TripCmd	2	31	93		Signal: Trip Command
IdH	Alarm	2	31	100	GI	Signal: Alarm
IdH	Alarm L1	2	31	101	GI	Signal: Alarm System Phase L1
IdH	Alarm L2	2	31	102	GI	Signal: Alarm System Phase L2
IdH	Alarm L3	2	31	103	GI	Signal: Alarm System L3
IdG[1]	active	1	32	50	GI	Signal: active
IdG[2]	active	1	32	51	GI	Signal: active
IdGH[1]	active	1	32	52	GI	Signal: active
IdGH[2]	active	1	32	53	GI	Signal: active
IdG[1]	Blo TripCmd	1	32	60	GI	Signal: Trip Command blocked
IdG[2]	Blo TripCmd	1	32	61	GI	Signal: Trip Command blocked
IdGH[1]	Blo TripCmd	1	32	62	GI	Signal: Trip Command blocked
IdGH[2]	Blo TripCmd	1	32	63	GI	Signal: Trip Command blocked

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
IdG[1]	TripCmd	2	32	92		Signal: Trip Command
IdG[2]	TripCmd	2	32	93		Signal: Trip Command
IdGH[1]	TripCmd	2	32	94		Signal: Trip Command
IdGH[2]	TripCmd	2	32	95		Signal: Trip Command
IdG[1]	Alarm	2	32	100	GI	Signal: Alarm
IdG[2]	Alarm	2	32	101	GI	Signal: Alarm
IdGH[1]	Alarm	2	32	102	GI	Signal: Alarm
IdGH[2]	Alarm	2	32	103	GI	Signal: Alarm
Q->&V<	Fuse Fail VT Blo	1	35	40	GI	Signal: Blocked by Fuse Failure (VT)
Q->&V<	ExBlo	1	35	80	GI	Signal: External Blocking
Q->&V<	Alarm	1	35	100	GI	Signal: Alarm Reactive Power Undervoltage Protection
Q->&V<	Release Energy Resource	1	35	111	GI	Signal: Release Energy Resource. Internal (local) voltage release
Q->&V<	PCC V Release	1	35	112	GI	Signal: Voltage Release from the Point of Common Coupling
Q->&V<	V Ext Release PCC-I	1	35	113	GI	Module input state: Release signal is being generated by the PCC (External Release)
Q->&V<	Decoupling Energy Resource	1	35	120	GI	Signal: Decoupling of the (local) Energy Resource
Q->&V<	Decoupling PCC	1	35	121	GI	Signal: Decoupling at the Point of Common Coupling
Q->&V<	PCC Fuse Fail VT-I	1	35	122	GI	State of the module input: Blocking if the fuse of a voltage transformer has tripped at the PCC.

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
RTD	TripCmd	2	46	90		Signal: Trip Command
RTD	Alarm	2	46	100	GI	Alarm RTD Temperature Protection
IEC 103	Failure Event lost	1	100	100		Failure event lost
I[1]	active	1	101	50	GI	Signal: active
I[2]	active	1	101	51	GI	Signal: active
I[3]	active	1	101	52	GI	Signal: active
I[4]	active	1	101	53	GI	Signal: active
I[5]	active	1	101	54	GI	Signal: active
I[6]	active	1	101	55	GI	Signal: active
IG[1]	active	1	101	56	GI	Signal: active
IG[2]	active	1	101	57	GI	Signal: active
IG[3]	active	1	101	58	GI	Signal: active
IG[4]	active	1	101	59	GI	Signal: active
I[1]	Blo TripCmd	1	101	60	GI	Signal: Trip Command blocked
I[2]	Blo TripCmd	1	101	61	GI	Signal: Trip Command blocked
I[3]	Blo TripCmd	1	101	62	GI	Signal: Trip Command blocked
I[4]	Blo TripCmd	1	101	63	GI	Signal: Trip Command blocked
I[5]	Blo TripCmd	1	101	64	GI	Signal: Trip Command blocked
I[6]	Blo TripCmd	1	101	65	GI	Signal: Trip Command blocked
IG[1]	Blo TripCmd	1	101	66	GI	Signal: Trip Command blocked
IG[2]	Blo TripCmd	1	101	67	GI	Signal: Trip Command blocked
IG[3]	Blo TripCmd	1	101	68	GI	Signal: Trip Command blocked
IG[4]	Blo TripCmd	1	101	69	GI	Signal: Trip Command blocked

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
I[3]	TripCmd	2	101	92		Signal: Trip Command
I[4]	TripCmd	2	101	93		Signal: Trip Command
I[5]	TripCmd	2	101	94		Signal: Trip Command
I[6]	TripCmd	2	101	95		Signal: Trip Command
IG[3]	TripCmd	2	101	98		Signal: Trip Command
IG[4]	TripCmd	2	101	99		Signal: Trip Command
I[1]	Alarm	2	101	100	GI	Signal: Alarm
I[2]	Alarm	2	101	101	GI	Signal: Alarm
I[3]	Alarm	2	101	102	GI	Signal: Alarm
I[4]	Alarm	2	101	103	GI	Signal: Alarm
I[5]	Alarm	2	101	104	GI	Signal: Alarm
I[6]	Alarm	2	101	105	GI	Signal: Alarm
IG[1]	Alarm	2	101	106	GI	Signal: Alarm IG
IG[2]	Alarm	2	101	107	GI	Signal: Alarm IG
IG[3]	Alarm	2	101	108	GI	Signal: Alarm IG
IG[4]	Alarm	2	101	109	GI	Signal: Alarm IG
ThR	active	1	102	50	GI	Signal: active
ThR	Blo TripCmd	1	102	60	GI	Signal: Trip Command blocked
ThR	TripCmd	2	102	90		Signal: Trip Command
ThR	Alarm	2	102	100	GI	Signal: Alarm Thermal Overload
V012[1]	active	1	103	50	GI	Signal: active
V012[2]	active	1	103	51	GI	Signal: active
V012[3]	active	1	103	52	GI	Signal: active

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
V012[4]	active	1	103	53	GI	Signal: active
V012[5]	active	1	103	54	GI	Signal: active
V012[6]	active	1	103	55	GI	Signal: active
I2>[1]	active	1	103	56	GI	Signal: active
I2>[2]	active	1	103	57	GI	Signal: active
I2>G	active	1	103	58	GI	Signal: active
V012[1]	Blo TripCmd	1	103	60	GI	Signal: Trip Command blocked
V012[2]	Blo TripCmd	1	103	61	GI	Signal: Trip Command blocked
V012[3]	Blo TripCmd	1	103	62	GI	Signal: Trip Command blocked
V012[4]	Blo TripCmd	1	103	63	GI	Signal: Trip Command blocked
V012[5]	Blo TripCmd	1	103	64	GI	Signal: Trip Command blocked
V012[6]	Blo TripCmd	1	103	65	GI	Signal: Trip Command blocked
I2>[1]	Blo TripCmd	1	103	66	GI	Signal: Trip Command blocked
I2>[2]	Blo TripCmd	1	103	67	GI	Signal: Trip Command blocked
I2>G	Blo TripCmd	1	103	68	GI	Signal: Trip Command blocked
I2>[1]	TripCmd	2	103	90		Signal: Trip Command
I2>[2]	TripCmd	2	103	91		Signal: Trip Command
V012[1]	TripCmd	2	103	92		Signal: Trip Command
V012[2]	TripCmd	2	103	93		Signal: Trip Command
V012[3]	TripCmd	2	103	94		Signal: Trip Command
V012[4]	TripCmd	2	103	95		Signal: Trip Command
V012[5]	TripCmd	2	103	96		Signal: Trip Command
V012[6]	TripCmd	2	103	97		Signal: Trip Command

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
I2>G	TripCmd	2	103	98		Signal: Trip Command
I2>[1]	Alarm	2	103	100	GI	Signal: Alarm Negative Sequence
I2>[2]	Alarm	2	103	101	GI	Signal: Alarm Negative Sequence
V012[1]	Alarm	2	103	102	GI	Signal: Alarm voltage asymmetry
V012[2]	Alarm	2	103	103	GI	Signal: Alarm voltage asymmetry
V012[3]	Alarm	2	103	104	GI	Signal: Alarm voltage asymmetry
V012[4]	Alarm	2	103	105	GI	Signal: Alarm voltage asymmetry
V012[5]	Alarm	2	103	106	GI	Signal: Alarm voltage asymmetry
V012[6]	Alarm	2	103	107	GI	Signal: Alarm voltage asymmetry
I2>G	Alarm	2	103	108	GI	Signal: Alarm Negative Sequence
V[1]	active	1	104	50	GI	Signal: active
V[2]	active	1	104	51	GI	Signal: active
V[3]	active	1	104	52	GI	Signal: active
V[4]	active	1	104	53	GI	Signal: active
VG[1]	active	1	104	54	GI	Signal: active
VG[2]	active	1	104	55	GI	Signal: active
V[5]	active	1	104	56	GI	Signal: active
V[6]	active	1	104	57	GI	Signal: active
V[1]	Blo TripCmd	1	104	60	GI	Signal: Trip Command blocked
V[2]	Blo TripCmd	1	104	61	GI	Signal: Trip Command blocked
V[3]	Blo TripCmd	1	104	62	GI	Signal: Trip Command blocked
V[4]	Blo TripCmd	1	104	63	GI	Signal: Trip Command blocked
VG[1]	Blo TripCmd	1	104	64	GI	Signal: Trip Command blocked

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
VG[2]	Blo TripCmd	1	104	65	GI	Signal: Trip Command blocked
V[5]	Blo TripCmd	1	104	66	GI	Signal: Trip Command blocked
V[6]	Blo TripCmd	1	104	67	GI	Signal: Trip Command blocked
V[1]	TripCmd	2	104	90		Signal: Trip Command
V[2]	TripCmd	2	104	91		Signal: Trip Command
V[3]	TripCmd	2	104	92		Signal: Trip Command
V[4]	TripCmd	2	104	93		Signal: Trip Command
VG[1]	TripCmd	2	104	94		Signal: Trip Command
VG[2]	TripCmd	2	104	95		Signal: Trip Command
V[5]	TripCmd	2	104	96		Signal: Trip Command
V[6]	TripCmd	2	104	97		Signal: Trip Command
V[1]	Alarm	2	104	100	GI	Signal: Alarm voltage stage
V[2]	Alarm	2	104	101	GI	Signal: Alarm voltage stage
V[3]	Alarm	2	104	102	GI	Signal: Alarm voltage stage
V[4]	Alarm	2	104	103	GI	Signal: Alarm voltage stage
VG[1]	Alarm	2	104	104	GI	Signal: Alarm Residual Voltage Supervision-stage
VG[2]	Alarm	2	104	105	GI	Signal: Alarm Residual Voltage Supervision-stage
V[5]	Alarm	2	104	106	GI	Signal: Alarm voltage stage
V[6]	Alarm	2	104	107	GI	Signal: Alarm voltage stage
f[1]	active	1	105	50	GI	Signal: active
f[2]	active	1	105	51	GI	Signal: active
f[3]	active	1	105	52	GI	Signal: active

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
f[4]	active	1	105	53	GI	Signal: active
f[5]	active	1	105	54	GI	Signal: active
f[6]	active	1	105	55	GI	Signal: active
f[1]	Blo TripCmd	1	105	60	GI	Signal: Trip Command blocked
f[2]	Blo TripCmd	1	105	61	GI	Signal: Trip Command blocked
f[3]	Blo TripCmd	1	105	62	GI	Signal: Trip Command blocked
f[4]	Blo TripCmd	1	105	63	GI	Signal: Trip Command blocked
f[5]	Blo TripCmd	1	105	64	GI	Signal: Trip Command blocked
f[6]	Blo TripCmd	1	105	65	GI	Signal: Trip Command blocked
f[1]	TripCmd	2	105	90		Signal: Trip Command
f[2]	TripCmd	2	105	91		Signal: Trip Command
f[3]	TripCmd	2	105	92		Signal: Trip Command
f[4]	TripCmd	2	105	93		Signal: Trip Command
f[5]	TripCmd	2	105	94		Signal: Trip Command
f[6]	TripCmd	2	105	95		Signal: Trip Command
f[1]	Alarm	2	105	100	GI	Signal: Alarm Frequency Protection (collective signal)
f[2]	Alarm	2	105	101	GI	Signal: Alarm Frequency Protection (collective signal)
f[3]	Alarm	2	105	102	GI	Signal: Alarm Frequency Protection (collective signal)
f[4]	Alarm	2	105	103	GI	Signal: Alarm Frequency Protection (collective signal)

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
f[5]	Alarm	2	105	104	GI	Signal: Alarm Frequency Protection (collective signal)
f[6]	Alarm	2	105	105	GI	Signal: Alarm Frequency Protection (collective signal)
f[1]	Alarm df/dt DF/DT	2	105	110	GI	Alarm instantaneous or average value of the rate-of-frequency-change
f[2]	Alarm df/dt DF/DT	2	105	111	GI	Alarm instantaneous or average value of the rate-of-frequency-change
f[3]	Alarm df/dt DF/DT	2	105	112	GI	Alarm instantaneous or average value of the rate-of-frequency-change
f[4]	Alarm df/dt DF/DT	2	105	113	GI	Alarm instantaneous or average value of the rate-of-frequency-change
f[5]	Alarm df/dt DF/DT	2	105	114	GI	Alarm instantaneous or average value of the rate-of-frequency-change
f[6]	Alarm df/dt DF/DT	2	105	115	GI	Alarm instantaneous or average value of the rate-of-frequency-change
f[1]	Alarm delta phi	2	105	120	GI	Signal: Alarm Vector Surge
f[2]	Alarm delta phi	2	105	121	GI	Signal: Alarm Vector Surge
f[3]	Alarm delta phi	2	105	122	GI	Signal: Alarm Vector Surge
f[4]	Alarm delta phi	2	105	123	GI	Signal: Alarm Vector Surge
f[5]	Alarm delta phi	2	105	124	GI	Signal: Alarm Vector Surge
f[6]	Alarm delta phi	2	105	125	GI	Signal: Alarm Vector Surge
f[1]	Trip df/dt DF/DT	2	105	130		Signal: Trip df/dt or DF/DT
f[2]	Trip df/dt DF/DT	2	105	131		Signal: Trip df/dt or DF/DT
f[3]	Trip df/dt DF/DT	2	105	132		Signal: Trip df/dt or DF/DT

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
f[4]	Trip df/dt DF/DT	2	105	133		Signal: Trip df/dt or DF/DT
f[5]	Trip df/dt DF/DT	2	105	134		Signal: Trip df/dt or DF/DT
f[6]	Trip df/dt DF/DT	2	105	135		Signal: Trip df/dt or DF/DT
f[1]	Trip delta phi	2	105	140		Signal: Trip Vector Surge
f[2]	Trip delta phi	2	105	141		Signal: Trip Vector Surge
f[3]	Trip delta phi	2	105	142		Signal: Trip Vector Surge
f[4]	Trip delta phi	2	105	143		Signal: Trip Vector Surge
f[5]	Trip delta phi	2	105	144		Signal: Trip Vector Surge
f[6]	Trip delta phi	2	105	145		Signal: Trip Vector Surge
CBF	active	1	108	50	GI	Signal: active
CBF	running	1	108	60	GI	Signal: CBF-Module started
CBF	Trigger1-l	1	108	100	GI	Module Input: Trigger that will start the CBF
CBF	Trigger2-l	1	108	101	GI	Module Input: Trigger that will start the CBF
CBF	Trigger3-l	1	108	102	GI	Module Input: Trigger that will start the CBF
CBF	Lockout	1	108	106	GI	Signal: Lockout
CBF	Waiting for Trigger	1	108	107	GI	Waiting for Trigger
Ex Oil Temp	Trip-l	2	113	40	GI	Module input state: Trip
Ext Sudd Press	Trip-l	2	113	41	GI	Module input state: Trip
Ext Temp Superv[1]	Trip-l	2	113	42	GI	Module input state: Trip
Ext Temp Superv[2]	Trip-l	2	113	43	GI	Module input state: Trip
Ext Temp Superv[3]	Trip-l	2	113	44	GI	Module input state: Trip
Ex Oil Temp	active	1	113	50	GI	Signal: active
Ext Sudd Press	active	1	113	51	GI	Signal: active

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Ext Temp Superv[1]	active	1	113	52	GI	Signal: active
Ext Temp Superv[2]	active	1	113	53	GI	Signal: active
Ext Temp Superv[3]	active	1	113	54	GI	Signal: active
Ex Oil Temp	Blo TripCmd	1	113	60	GI	Signal: Trip Command blocked
Ext Sudd Press	Blo TripCmd	1	113	61	GI	Signal: Trip Command blocked
Ext Temp Superv[1]	Blo TripCmd	1	113	62	GI	Signal: Trip Command blocked
Ext Temp Superv[2]	Blo TripCmd	1	113	63	GI	Signal: Trip Command blocked
Ext Temp Superv[3]	Blo TripCmd	1	113	64	GI	Signal: Trip Command blocked
Ex Oil Temp	TripCmd	2	113	90		Signal: Trip Command
Ext Sudd Press	TripCmd	2	113	91		Signal: Trip Command
Ext Temp Superv[1]	TripCmd	2	113	92		Signal: Trip Command
Ext Temp Superv[2]	TripCmd	2	113	93		Signal: Trip Command
Ext Temp Superv[3]	TripCmd	2	113	94		Signal: Trip Command
Ex Oil Temp	Alarm	2	113	100	GI	Signal: Alarm
Ext Sudd Press	Alarm	2	113	101	GI	Signal: Alarm
Ext Temp Superv[1]	Alarm	2	113	102	GI	Signal: Alarm
Ext Temp Superv[2]	Alarm	2	113	103	GI	Signal: Alarm
Ext Temp Superv[3]	Alarm	2	113	104	GI	Signal: Alarm
Exp[1]	active	1	114	50	GI	Signal: active
Exp[2]	active	1	114	51	GI	Signal: active
Exp[3]	active	1	114	52	GI	Signal: active
Exp[4]	active	1	114	53	GI	Signal: active
Exp[1]	Blo TripCmd	1	114	60	GI	Signal: Trip Command blocked

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Exp[2]	Blo TripCmd	1	114	61	GI	Signal: Trip Command blocked
Exp[3]	Blo TripCmd	1	114	62	GI	Signal: Trip Command blocked
Exp[4]	Blo TripCmd	1	114	63	GI	Signal: Trip Command blocked
Exp[1]	TripCmd	2	114	90		Signal: Trip Command
Exp[2]	TripCmd	2	114	91		Signal: Trip Command
Exp[3]	TripCmd	2	114	92		Signal: Trip Command
Exp[4]	TripCmd	2	114	93		Signal: Trip Command
Exp[1]	Alarm	2	114	100	GI	Signal: Alarm
Exp[2]	Alarm	2	114	101	GI	Signal: Alarm
Exp[3]	Alarm	2	114	102	GI	Signal: Alarm
Exp[4]	Alarm	2	114	103	GI	Signal: Alarm
SOTF	active	1	115	50	GI	Signal: active
CLPU	active	1	115	51	GI	Signal: active
CLPU	enabled	2	115	91		Signal: Cold Load enabled
PQS[1]	active	1	116	50	GI	Signal: active
PQS[2]	active	1	116	51	GI	Signal: active
PQS[3]	active	1	116	52	GI	Signal: active
PQS[4]	active	1	116	53	GI	Signal: active
PQS[5]	active	1	116	54	GI	Signal: active
PQS[6]	active	1	116	55	GI	Signal: active
PF[1]	active	1	116	56	GI	Signal: active
PF[2]	active	1	116	57	GI	Signal: active
PQS[1]	Blo TripCmd	1	116	60	GI	Signal: Trip Command blocked

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
PQS[2]	Blo TripCmd	1	116	61	GI	Signal: Trip Command blocked
PQS[3]	Blo TripCmd	1	116	62	GI	Signal: Trip Command blocked
PQS[4]	Blo TripCmd	1	116	63	GI	Signal: Trip Command blocked
PQS[5]	Blo TripCmd	1	116	64	GI	Signal: Trip Command blocked
PQS[6]	Blo TripCmd	1	116	65	GI	Signal: Trip Command blocked
PF[1]	Blo TripCmd	1	116	66	GI	Signal: Trip Command blocked
PF[2]	Blo TripCmd	1	116	67	GI	Signal: Trip Command blocked
PQS[1]	TripCmd	2	116	90		Signal: Trip Command
PQS[2]	TripCmd	2	116	91		Signal: Trip Command
PQS[3]	TripCmd	2	116	92		Signal: Trip Command
PQS[4]	TripCmd	2	116	93		Signal: Trip Command
PQS[5]	TripCmd	2	116	94		Signal: Trip Command
PQS[6]	TripCmd	2	116	95		Signal: Trip Command
PF[1]	TripCmd	2	116	96		Signal: Trip Command
PF[2]	TripCmd	2	116	97		Signal: Trip Command
PQS[1]	Alarm	2	116	100	GI	Signal: Alarm Power Protection
PQS[2]	Alarm	2	116	101	GI	Signal: Alarm Power Protection
PQS[3]	Alarm	2	116	102	GI	Signal: Alarm Power Protection
PQS[4]	Alarm	2	116	103	GI	Signal: Alarm Power Protection
PQS[5]	Alarm	2	116	104	GI	Signal: Alarm Power Protection
PQS[6]	Alarm	2	116	105	GI	Signal: Alarm Power Protection
PF[1]	Alarm	2	116	106	GI	Signal: Alarm Power Factor
PF[2]	Alarm	2	116	107	GI	Signal: Alarm Power Factor

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
PF[1]	Compensator	2	116	110	GI	Signal: Compensation Signal
PF[2]	Compensator	2	116	111	GI	Signal: Compensation Signal
DI Slot X 1	DI 5	1	121	27	GI	Signal: Digital Input
DI Slot X 1	DI 6	1	121	28	GI	Signal: Digital Input
DI Slot X 1	DI 7	1	121	29	GI	Signal: Digital Input
DI Slot X 1	DI 8	1	121	30	GI	Signal: Digital Input
DI Slot X 5	DI 1	1	121	31	GI	Signal: Digital Input
DI Slot X 5	DI 2	1	121	32	GI	Signal: Digital Input
DI Slot X 5	DI 3	1	121	33	GI	Signal: Digital Input
DI Slot X 5	DI 4	1	121	34	GI	Signal: Digital Input
DI Slot X 5	DI 5	1	121	35	GI	Signal: Digital Input
DI Slot X 5	DI 6	1	121	36	GI	Signal: Digital Input
DI Slot X 5	DI 7	1	121	37	GI	Signal: Digital Input
DI Slot X 5	DI 8	1	121	38	GI	Signal: Digital Input
DI Slot X 6	DI 1	1	122	31	GI	Signal: Digital Input
DI Slot X 6	DI 2	1	122	32	GI	Signal: Digital Input
DI Slot X 6	DI 3	1	122	33	GI	Signal: Digital Input
DI Slot X 6	DI 4	1	122	34	GI	Signal: Digital Input
DI Slot X 6	DI 5	1	122	35	GI	Signal: Digital Input
DI Slot X 6	DI 6	1	122	36	GI	Signal: Digital Input
DI Slot X 6	DI 7	1	122	37	GI	Signal: Digital Input
DI Slot X 6	DI 8	1	122	38	GI	Signal: Digital Input
BO Slot X2	BO 1	1	123	160	GI	Signal: Binary Output Relay

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
BO Slot X2	BO 2	1	123	161	GI	Signal: Binary Output Relay
BO Slot X2	BO 3	1	123	162	GI	Signal: Binary Output Relay
BO Slot X2	BO 4	1	123	163	GI	Signal: Binary Output Relay
BO Slot X2	BO 5	1	123	164	GI	Signal: Binary Output Relay
BO Slot X2	BO 6	1	123	165	GI	Signal: Binary Output Relay
BO Slot X5	BO 1	1	123	172	GI	Signal: Binary Output Relay
BO Slot X5	BO 2	1	123	173	GI	Signal: Binary Output Relay
BO Slot X5	BO 3	1	123	174	GI	Signal: Binary Output Relay
BO Slot X5	BO 4	1	123	175	GI	Signal: Binary Output Relay
BO Slot X6	BO 1	1	123	178	GI	Signal: Binary Output Relay
BO Slot X6	BO 2	1	123	179	GI	Signal: Binary Output Relay
BO Slot X6	BO 3	1	123	180	GI	Signal: Binary Output Relay
BO Slot X6	BO 4	1	123	181	GI	Signal: Binary Output Relay
BO Slot X6	BO 5	1	123	182	GI	Signal: Binary Output Relay
Logics	LE1.Gate Out	1	162	160	GI	Signal: Output of the logic gate
Logics	LE1.Timer Out	1	162	161	GI	Signal: Timer Output
Logics	LE1.Out	1	162	162	GI	Signal: Latched Output (Q)
Logics	LE1.Gate In1-I	1	162	163	GI	State of the module input: Assignment of the Input Signal
Logics	LE1.Gate In2-I	1	162	164	GI	State of the module input: Assignment of the Input Signal
Logics	LE1.Gate In3-I	1	162	165	GI	State of the module input: Assignment of the Input Signal

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE1.Gate In4-I	1	162	166	GI	State of the module input: Assignment of the Input Signal
Logics	LE2.Gate Out	1	162	167	GI	Signal: Output of the logic gate
Logics	LE2.Timer Out	1	162	168	GI	Signal: Timer Output
Logics	LE2.Out	1	162	169	GI	Signal: Latched Output (Q)
Logics	LE2.Gate In1-I	1	162	170	GI	State of the module input: Assignment of the Input Signal
Logics	LE2.Gate In2-I	1	162	171	GI	State of the module input: Assignment of the Input Signal
Logics	LE2.Gate In3-I	1	162	172	GI	State of the module input: Assignment of the Input Signal
Logics	LE2.Gate In4-I	1	162	173	GI	State of the module input: Assignment of the Input Signal
Logics	LE3.Gate Out	1	162	174	GI	Signal: Output of the logic gate
Logics	LE3.Timer Out	1	162	175	GI	Signal: Timer Output
Logics	LE3.Out	1	162	176	GI	Signal: Latched Output (Q)
Logics	LE3.Gate In1-I	1	162	177	GI	State of the module input: Assignment of the Input Signal
Logics	LE3.Gate In2-I	1	162	178	GI	State of the module input: Assignment of the Input Signal
Logics	LE3.Gate In3-I	1	162	179	GI	State of the module input: Assignment of the Input Signal
Logics	LE3.Gate In4-I	1	162	180	GI	State of the module input: Assignment of the Input Signal
Logics	LE4.Gate Out	1	162	181	GI	Signal: Output of the logic gate
Logics	LE4.Timer Out	1	162	182	GI	Signal: Timer Output

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE4.Out	1	162	183	GI	Signal: Latched Output (Q)
Logics	LE4.Gate In1-I	1	162	184	GI	State of the module input: Assignment of the Input Signal
Logics	LE4.Gate In2-I	1	162	185	GI	State of the module input: Assignment of the Input Signal
Logics	LE4.Gate In3-I	1	162	186	GI	State of the module input: Assignment of the Input Signal
Logics	LE4.Gate In4-I	1	162	187	GI	State of the module input: Assignment of the Input Signal
Logics	LE5.Gate Out	1	162	188	GI	Signal: Output of the logic gate
Logics	LE5.Timer Out	1	162	189	GI	Signal: Timer Output
Logics	LE5.Out	1	162	190	GI	Signal: Latched Output (Q)
Logics	LE5.Gate In1-I	1	162	191	GI	State of the module input: Assignment of the Input Signal
Logics	LE5.Gate In2-I	1	162	192	GI	State of the module input: Assignment of the Input Signal
Logics	LE5.Gate In3-I	1	162	193	GI	State of the module input: Assignment of the Input Signal
Logics	LE5.Gate In4-I	1	162	194	GI	State of the module input: Assignment of the Input Signal
Logics	LE6.Gate Out	1	162	195	GI	Signal: Output of the logic gate
Logics	LE6.Timer Out	1	162	196	GI	Signal: Timer Output
Logics	LE6.Out	1	162	197	GI	Signal: Latched Output (Q)
Logics	LE6.Gate In1-I	1	162	198	GI	State of the module input: Assignment of the Input Signal

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE6.Gate In2-I	1	162	199	GI	State of the module input: Assignment of the Input Signal
Logics	LE6.Gate In3-I	1	162	200	GI	State of the module input: Assignment of the Input Signal
Logics	LE6.Gate In4-I	1	162	201	GI	State of the module input: Assignment of the Input Signal
Logics	LE7.Gate Out	1	162	202	GI	Signal: Output of the logic gate
Logics	LE7.Timer Out	1	162	203	GI	Signal: Timer Output
Logics	LE7.Out	1	162	204	GI	Signal: Latched Output (Q)
Logics	LE7.Gate In1-I	1	162	205	GI	State of the module input: Assignment of the Input Signal
Logics	LE7.Gate In2-I	1	162	206	GI	State of the module input: Assignment of the Input Signal
Logics	LE7.Gate In3-I	1	162	207	GI	State of the module input: Assignment of the Input Signal
Logics	LE7.Gate In4-I	1	162	208	GI	State of the module input: Assignment of the Input Signal
Logics	LE8.Gate Out	1	162	209	GI	Signal: Output of the logic gate
Logics	LE8.Timer Out	1	162	210	GI	Signal: Timer Output
Logics	LE8.Out	1	162	211	GI	Signal: Latched Output (Q)
Logics	LE8.Gate In1-I	1	162	212	GI	State of the module input: Assignment of the Input Signal
Logics	LE8.Gate In2-I	1	162	213	GI	State of the module input: Assignment of the Input Signal
Logics	LE8.Gate In3-I	1	162	214	GI	State of the module input: Assignment of the Input Signal

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE8.Gate In4-I	1	162	215	GI	State of the module input: Assignment of the Input Signal
Logics	LE9.Gate Out	1	162	216	GI	Signal: Output of the logic gate
Logics	LE9.Timer Out	1	162	217	GI	Signal: Timer Output
Logics	LE9.Out	1	162	218	GI	Signal: Latched Output (Q)
Logics	LE9.Gate In1-I	1	162	219	GI	State of the module input: Assignment of the Input Signal
Logics	LE9.Gate In2-I	1	162	220	GI	State of the module input: Assignment of the Input Signal
Logics	LE9.Gate In3-I	1	162	221	GI	State of the module input: Assignment of the Input Signal
Logics	LE9.Gate In4-I	1	162	222	GI	State of the module input: Assignment of the Input Signal
Logics	LE10.Gate Out	1	162	223	GI	Signal: Output of the logic gate
Logics	LE10.Timer Out	1	162	224	GI	Signal: Timer Output
Logics	LE10.Out	1	162	225	GI	Signal: Latched Output (Q)
Logics	LE10.Gate In1-I	1	162	226	GI	State of the module input: Assignment of the Input Signal
Logics	LE10.Gate In2-I	1	162	227	GI	State of the module input: Assignment of the Input Signal
Logics	LE10.Gate In3-I	1	162	228	GI	State of the module input: Assignment of the Input Signal
Logics	LE10.Gate In4-I	1	162	229	GI	State of the module input: Assignment of the Input Signal
Logics	LE11.Gate Out	1	163	160	GI	Signal: Output of the logic gate
Logics	LE11.Timer Out	1	163	161	GI	Signal: Timer Output

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE11.Out	1	163	162	GI	Signal: Latched Output (Q)
Logics	LE11.Gate In1-I	1	163	163	GI	State of the module input: Assignment of the Input Signal
Logics	LE11.Gate In2-I	1	163	164	GI	State of the module input: Assignment of the Input Signal
Logics	LE11.Gate In3-I	1	163	165	GI	State of the module input: Assignment of the Input Signal
Logics	LE11.Gate In4-I	1	163	166	GI	State of the module input: Assignment of the Input Signal
Logics	LE12.Gate Out	1	163	167	GI	Signal: Output of the logic gate
Logics	LE12.Timer Out	1	163	168	GI	Signal: Timer Output
Logics	LE12.Out	1	163	169	GI	Signal: Latched Output (Q)
Logics	LE12.Gate In1-I	1	163	170	GI	State of the module input: Assignment of the Input Signal
Logics	LE12.Gate In2-I	1	163	171	GI	State of the module input: Assignment of the Input Signal
Logics	LE12.Gate In3-I	1	163	172	GI	State of the module input: Assignment of the Input Signal
Logics	LE12.Gate In4-I	1	163	173	GI	State of the module input: Assignment of the Input Signal
Logics	LE13.Gate Out	1	163	174	GI	Signal: Output of the logic gate
Logics	LE13.Timer Out	1	163	175	GI	Signal: Timer Output
Logics	LE13.Out	1	163	176	GI	Signal: Latched Output (Q)
Logics	LE13.Gate In1-I	1	163	177	GI	State of the module input: Assignment of the Input Signal

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE13.Gate In2-I	1	163	178	GI	State of the module input: Assignment of the Input Signal
Logics	LE13.Gate In3-I	1	163	179	GI	State of the module input: Assignment of the Input Signal
Logics	LE13.Gate In4-I	1	163	180	GI	State of the module input: Assignment of the Input Signal
Logics	LE14.Gate Out	1	163	181	GI	Signal: Output of the logic gate
Logics	LE14.Timer Out	1	163	182	GI	Signal: Timer Output
Logics	LE14.Out	1	163	183	GI	Signal: Latched Output (Q)
Logics	LE14.Gate In1-I	1	163	184	GI	State of the module input: Assignment of the Input Signal
Logics	LE14.Gate In2-I	1	163	185	GI	State of the module input: Assignment of the Input Signal
Logics	LE14.Gate In3-I	1	163	186	GI	State of the module input: Assignment of the Input Signal
Logics	LE14.Gate In4-I	1	163	187	GI	State of the module input: Assignment of the Input Signal
Logics	LE15.Gate Out	1	163	188	GI	Signal: Output of the logic gate
Logics	LE15.Timer Out	1	163	189	GI	Signal: Timer Output
Logics	LE15.Out	1	163	190	GI	Signal: Latched Output (Q)
Logics	LE15.Gate In1-I	1	163	191	GI	State of the module input: Assignment of the Input Signal
Logics	LE15.Gate In2-I	1	163	192	GI	State of the module input: Assignment of the Input Signal
Logics	LE15.Gate In3-I	1	163	193	GI	State of the module input: Assignment of the Input Signal

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE15.Gate In4-I	1	163	194	GI	State of the module input: Assignment of the Input Signal
Logics	LE16.Gate Out	1	163	195	GI	Signal: Output of the logic gate
Logics	LE16.Timer Out	1	163	196	GI	Signal: Timer Output
Logics	LE16.Out	1	163	197	GI	Signal: Latched Output (Q)
Logics	LE16.Gate In1-I	1	163	198	GI	State of the module input: Assignment of the Input Signal
Logics	LE16.Gate In2-I	1	163	199	GI	State of the module input: Assignment of the Input Signal
Logics	LE16.Gate In3-I	1	163	200	GI	State of the module input: Assignment of the Input Signal
Logics	LE16.Gate In4-I	1	163	201	GI	State of the module input: Assignment of the Input Signal
Logics	LE17.Gate Out	1	163	202	GI	Signal: Output of the logic gate
Logics	LE17.Timer Out	1	163	203	GI	Signal: Timer Output
Logics	LE17.Out	1	163	204	GI	Signal: Latched Output (Q)
Logics	LE17.Gate In1-I	1	163	205	GI	State of the module input: Assignment of the Input Signal
Logics	LE17.Gate In2-I	1	163	206	GI	State of the module input: Assignment of the Input Signal
Logics	LE17.Gate In3-I	1	163	207	GI	State of the module input: Assignment of the Input Signal
Logics	LE17.Gate In4-I	1	163	208	GI	State of the module input: Assignment of the Input Signal
Logics	LE18.Gate Out	1	163	209	GI	Signal: Output of the logic gate
Logics	LE18.Timer Out	1	163	210	GI	Signal: Timer Output

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE18.Out	1	163	211	GI	Signal: Latched Output (Q)
Logics	LE18.Gate In1-I	1	163	212	GI	State of the module input: Assignment of the Input Signal
Logics	LE18.Gate In2-I	1	163	213	GI	State of the module input: Assignment of the Input Signal
Logics	LE18.Gate In3-I	1	163	214	GI	State of the module input: Assignment of the Input Signal
Logics	LE18.Gate In4-I	1	163	215	GI	State of the module input: Assignment of the Input Signal
Logics	LE19.Gate Out	1	163	216	GI	Signal: Output of the logic gate
Logics	LE19.Timer Out	1	163	217	GI	Signal: Timer Output
Logics	LE19.Out	1	163	218	GI	Signal: Latched Output (Q)
Logics	LE19.Gate In1-I	1	163	219	GI	State of the module input: Assignment of the Input Signal
Logics	LE19.Gate In2-I	1	163	220	GI	State of the module input: Assignment of the Input Signal
Logics	LE19.Gate In3-I	1	163	221	GI	State of the module input: Assignment of the Input Signal
Logics	LE19.Gate In4-I	1	163	222	GI	State of the module input: Assignment of the Input Signal
Logics	LE20.Gate Out	1	163	223	GI	Signal: Output of the logic gate
Logics	LE20.Timer Out	1	163	224	GI	Signal: Timer Output
Logics	LE20.Out	1	163	225	GI	Signal: Latched Output (Q)
Logics	LE20.Gate In1-I	1	163	226	GI	State of the module input: Assignment of the Input Signal

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Logics	LE20.Gate In2-I	1	163	227	GI	State of the module input: Assignment of the Input Signal
Logics	LE20.Gate In3-I	1	163	228	GI	State of the module input: Assignment of the Input Signal
Logics	LE20.Gate In4-I	1	163	229	GI	State of the module input: Assignment of the Input Signal
InEn	active	1	165	50	GI	Signal: active
InEn	TripCmd	2	165	90		Signal: Trip Command
InEn	Alarm	2	165	100	GI	Signal: Inadvertent Energization
Intertripping	active	1	166	50	GI	Signal: active
Intertripping	TripCmd	2	166	90		Signal: Trip Command
Intertripping	Alarm	2	166	100	GI	Signal: Alarm
LoE-Z1[1]	active	1	167	50	GI	Signal: active
LoE-Z1[1]	TripCmd	2	167	90		Signal: Trip Command
LoE-Z1[1]	Alarm	2	167	100	GI	Signal: Alarm Loss of Excitation
LoE-Z2[1]	active	1	167	51	GI	Signal: active
LoE-Z2[1]	TripCmd	2	167	91		Signal: Trip Command
LoE-Z2[1]	Alarm	2	167	101	GI	Signal: Alarm Loss of Excitation
LoE-Z1[2]	active	1	167	52	GI	Signal: active
LoE-Z1[2]	TripCmd	2	167	92		Signal: Trip Command
LoE-Z1[2]	Alarm	2	167	102	GI	Signal: Alarm Loss of Excitation
LoE-Z2[2]	active	1	167	53	GI	Signal: active
LoE-Z2[2]	TripCmd	2	167	93		Signal: Trip Command
LoE-Z2[2]	Alarm	2	167	103	GI	Signal: Alarm Loss of Excitation

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
delta phi	active	1	169	50	GI	Signal: active
delta phi	TripCmd	2	169	90		Signal: Trip Command
delta phi	Alarm	2	169	100	GI	Signal: Alarm Frequency Protection (collective signal)
LVRT	active	1	170	50	GI	Signal: active
LVRT	TripCmd	2	170	90		Signal: Trip Command
LVRT	Alarm	2	170	100	GI	Signal: Alarm voltage stage
V/f>[1]	active	1	171	50	GI	Signal: active
V/f>[1]	TripCmd	2	171	90		Signal: Trip Command
V/f>[1]	Alarm	2	171	100	GI	Signal: Alarm Overexcitation
V/f>[2]	active	1	172	50	GI	Signal: active
V/f>[2]	TripCmd	2	172	90		Signal: Trip Command
V/f>[2]	Alarm	2	172	100	GI	Signal: Alarm Overexcitation
P	active	1	173	50	GI	Signal: active
P	TripCmd	2	173	90		Signal: Trip Command
P	Alarm	2	173	100	GI	Signal: Alarm Power Protection
Q	active	1	174	50	GI	Signal: active
Q	TripCmd	2	174	90		Signal: Trip Command
Q	Alarm	2	174	100	GI	Signal: Alarm Power Protection
df/dt	active	1	175	50	GI	Signal: active
df/dt	TripCmd	2	175	90		Signal: Trip Command
df/dt	Alarm	2	175	100	GI	Signal: Alarm Frequency Protection (collective signal)
IH2	active	1	180	50	GI	Signal: active

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
IH2	Blo L1	1	180	60		Signal: Blocked L1
IH2	Blo L2	1	180	61		Signal: Blocked L2
IH2	Blo L3	1	180	62		Signal: Blocked L3
IH2	Blo IG meas	1	180	63		Signal: Blocking of the ground (earth) protection module (measured ground current)
IH2	3-ph Blo	1	180	64		Signal: Inrush was detected in at least one phase - trip command blocked.
IH2	Blo IG calc	1	180	65		Signal: Blocking of the ground (earth) protection module (calculated ground current)
SysA	active	1	182	50	GI	Signal: active
SysA	Alarm Watt Power	2	182	100	GI	Signal: Alarm permitted Active Power exceeded
SysA	Alarm VAr Power	2	182	101	GI	Signal: Alarm permitted Reactive Power exceeded
SysA	Alarm VA Power	2	182	102	GI	Signal: Alarm permitted Apparent Power exceeded
SysA	Alarm Watt Demand	2	182	103	GI	Signal: Alarm averaged Active Power exceeded
SysA	Alarm VAr Demand	2	182	104	GI	Signal: Alarm averaged Reactive Power exceeded
SysA	Alarm VA Demand	2	182	105	GI	Signal: Alarm averaged Apparent Power exceeded
SysA	Alm Current Demd	2	182	106	GI	Signal: Alarm averaged demand current
SysA	Alarm I THD	2	182	107	GI	Signal: Alarm Total Harmonic Distortion Current

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SysA	Alarm V THD	2	182	108	GI	Signal: Alarm Total Harmonic Distortion Voltage
SysA	Trip Watt Power	2	182	90		Signal: Trip permitted Active Power exceeded
SysA	Trip VAr Power	2	182	91		Signal: Trip permitted Reactive Power exceeded
SysA	Trip VA Power	2	182	92		Signal: Trip permitted Apparent Power exceeded
SysA	Trip Watt Demand	2	182	93		Signal: Trip averaged Active Power exceeded
SysA	Trip VAr Demand	2	182	94		Signal: Trip averaged Reactive Power exceeded
SysA	Trip VA Demand	2	182	95		Signal: Trip averaged Apparent Power exceeded
SysA	Trip Current Demand	2	182	96		Signal: Trip averaged demand current
SysA	Trip I THD	2	182	97		Signal: Trip Total Harmonic Distortion Current
SysA	Trip V THD	2	182	98		Signal: Trip Total Harmonic Distortion Voltage
PQSCr	Cr OfIwW Wp Net	1	183	30		Signal: Counter Wp Net will overflow soon
PQSCr	Cr OfIwW Wp-	1	183	31		Signal: Counter Wp- will overflow soon
PQSCr	Cr OfIwW Wp+	1	183	32		Signal: Counter Wp+ will overflow soon
PQSCr	Cr OfIwW Wq Net	1	183	33		Signal: Counter Wq Net will overflow soon
PQSCr	Cr OfIwW Wq-	1	183	34		Signal: Counter Wq- will overflow soon
PQSCr	Cr OfIwW Wq+	1	183	35		Signal: Counter Wq+ will overflow soon
PQSCr	Cr OfIwW Ws Net	1	183	36		Signal: Counter Ws Net will overflow soon

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
PQSCr	Cr Ofw Wp-	1	183	37		Signal: Counter Overflow Wp-
PQSCr	Cr Ofw Wp+	1	183	38		Signal: Counter Overflow Wp+
PQSCr	Cr Ofw Wq-	1	183	39		Signal: Counter Overflow Wq-
PQSCr	Cr Ofw Wq+	1	183	40		Signal: Counter Overflow Wq+
PQSCr	Cr Ofw Wp Net	1	183	41		Signal: Counter Overflow Wp Net
PQSCr	Cr Ofw Wq Net	1	183	42		Signal: Counter Overflow Wq Net
PQSCr	Cr Ofw Ws Net	1	183	43		Signal: Counter Overflow Ws Net
AnaP[1]	active	1	226	50	GI	Signal: active
AnaP[2]	active	1	226	51	GI	Signal: active
AnaP[3]	active	1	226	52	GI	Signal: active
AnaP[4]	active	1	226	53	GI	Signal: active
AnaP[1]	TripCmd	2	226	90		Signal: Trip Command
AnaP[2]	TripCmd	2	226	91		Signal: Trip Command
AnaP[3]	TripCmd	2	226	92		Signal: Trip Command
AnaP[4]	TripCmd	2	226	93		Signal: Trip Command
AnaP[1]	Pickup	2	226	100	GI	Signal: Alarm Analog Input
AnaP[2]	Pickup	2	226	101	GI	Signal: Alarm Analog Input
AnaP[3]	Pickup	2	226	102	GI	Signal: Alarm Analog Input
AnaP[4]	Pickup	2	226	103	GI	Signal: Alarm Analog Input
TCS	active	1	241	50	GI	Signal: active
TCS	ExBlo	1	241	80		Signal: External Blocking
TCS	Alarm	1	241	100	GI	Signal: Alarm Trip Circuit Supervision

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
TCS	Not Possible	1	241	110	GI	Not possible because no state indicator assigned to the breaker.
SG[1]	Operations Alarm	1	242	104	GI	Signal: Service Alarm, too many Operations
SG[2]	Operations Alarm	1	242	109		Signal: Service Alarm, too many Operations
SG[3]	Operations Alarm	1	242	114		Signal: Service Alarm, too many Operations
SG[4]	Operations Alarm	1	242	119		Signal: Service Alarm, too many Operations
SG[5]	Operations Alarm	1	242	124		Signal: Service Alarm, too many Operations
SG[6]	Operations Alarm	1	242	129		Signal: Service Alarm, too many Operations
SG[1]	WearLevel Alarm	1	242	130	GI	Signal: Threshold for the Alarm
SG[1]	WearLevel Lockout	1	242	131	GI	Signal: Threshold for the Lockout Level
SG[2]	WearLevel Alarm	1	242	132	GI	Signal: Threshold for the Alarm
SG[2]	WearLevel Lockout	1	242	133	GI	Signal: Threshold for the Lockout Level
SG[3]	WearLevel Alarm	1	242	134	GI	Signal: Threshold for the Alarm
SG[3]	WearLevel Lockout	1	242	135	GI	Signal: Threshold for the Lockout Level
SG[4]	WearLevel Alarm	1	242	136	GI	Signal: Threshold for the Alarm
SG[4]	WearLevel Lockout	1	242	137	GI	Signal: Threshold for the Lockout Level
SG[5]	WearLevel Alarm	1	242	138	GI	Signal: Threshold for the Alarm
SG[5]	WearLevel Lockout	1	242	139	GI	Signal: Threshold for the Lockout Level
SG[6]	WearLevel Alarm	1	242	140	GI	Signal: Threshold for the Alarm
SG[6]	WearLevel Lockout	1	242	141	GI	Signal: Threshold for the Lockout Level
LOP	active	1	243	50	GI	Signal: active
LOP	ExBlo	1	243	80	GI	Signal: External Blocking
LOP	Alarm	1	243	100	GI	Signal: Alarm Loss of Potential

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
LOP	LOP Blo	1	243	110	GI	Signal: Loss of Potential blocks other elements.
LOP	Ex FF EVT	1	243	111	GI	Signal: Alarm Fuse Failure Earth Voltage Transformers
LOP	Ex FF VT	1	243	112	GI	Signal: Ex FF VT
Sync	active	1	244	50	GI	Signal: active
Sync	ExBlo	1	244	80		Signal: External Blocking
Sync	AngleDiffTooHigh	1	244	110	GI	Signal: Phase Angle difference between bus and line voltages too high.
Sync	Sys-in-Sync	1	244	111	GI	Signal: Bus and line voltages are in synchronism according to the system synchronism criteria.
Sync	LiveBus	1	244	112	GI	Signal: Live-Bus flag: 1=Live-Bus, 0=Voltage is below the LiveBus threshold
Sync	LiveLine	1	244	113	GI	Signal: Live Line flag: 1=Live-Line, 0=Voltage is below the LiveLine threshold
Sync	SlipTooHigh	1	244	114	GI	Signal: Frequency difference (slip frequency) between bus and line voltages too high.
Sync	Ready to Close	1	244	115	GI	Signal: Ready to Close
Sync	SynchronFailed	1	244	116	GI	Signal: This signal indicates a failed synchronization. It is set for 5s when the circuit breaker is still open after the Synchron-Run-timer has timed out.
Sync	VDiffTooHigh	1	244	117	GI	Signal: Voltage difference between bus and line too high.
Ctrl	SG Disturb	1	246	32	GI	Minimum one Switchgear is disturbed.

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Ctrl	SG Indeterm	1	246	33	GI	Minimum one Switchgear is moving (Position cannot be determined).
SG[1]	Removed-I	1	246	34	GI	State of the module input: The withdrawable circuit breaker is Removed
SG[1]	CES SG removed	1	246	35	GI	Signal: Command Execution Supervision: Switching Command unsuccessful, Switchgear removed.
SG[1]	Removed	1	246	36	GI	Signal: The withdrawable circuit breaker is Removed
SG[1]	SCmd OFF-I	1	246	110	GI	State of the module input: Switching OFF Command, e.g. the state of the Logics or the state of the digital input
SG[1]	SCmd ON-I	1	246	111	GI	State of the module input: Switching ON Command, e.g. the state of the Logics or the state of the digital input
SG[1]	Position Ind manipul	1	246	112	GI	Signal: Position Indicators faked
SG[1]	Prot ON	1	246	113	GI	Signal: ON Command issued by the Prot module
SG[1]	TripCmd	2	246	114		Signal: Trip Command
SG[1]	OFF Cmd	1	246	115		Signal: OFF Command issued to the switchgear. Depending on the setting the signal may include the OFF command of the Prot module.
SG[1]	ON Cmd	1	246	116		Signal: ON Command issued to the switchgear. Depending on the setting the signal may include the ON command of the Prot module.

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SG[1]	CES succesf	1	246	117	GI	Signal: Command Execution Supervision: Switching command executed successfully.
SG[1]	Interl OFF	1	246	118	GI	Signal: One or more IL_Off inputs are active.
SG[1]	Interl ON	1	246	119	GI	Signal: One or more IL_On inputs are active.
SG[1]	Ready	1	246	120	GI	Signal: Circuit breaker is ready for operation.
SG[2]	Removed-I	1	247	34	GI	State of the module input: The withdrawable circuit breaker is Removed
SG[2]	CES SG removed	1	247	35	GI	Signal: Command Execution Supervision: Switching Command unsuccessful, Switchgear removed.
SG[2]	Removed	1	247	36	GI	Signal: The withdrawable circuit breaker is Removed
SG[2]	SCmd OFF-I	1	247	110	GI	State of the module input: Switching OFF Command, e.g. the state of the Logics or the state of the digital input
SG[2]	SCmd ON-I	1	247	111	GI	State of the module input: Switching ON Command, e.g. the state of the Logics or the state of the digital input
SG[2]	Position Ind manipul	1	247	112	GI	Signal: Position Indicators faked
SG[2]	Prot ON	1	247	113	GI	Signal: ON Command issued by the Prot module
SG[2]	TripCmd	2	247	114		Signal: Trip Command
SG[2]	OFF Cmd	1	247	115		Signal: OFF Command issued to the switchgear. Depending on the setting the signal may include the OFF command of the Prot module.

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SG[2]	ON Cmd	1	247	116		Signal: ON Command issued to the switchgear. Depending on the setting the signal may include the ON command of the Prot module.
SG[2]	CES succesf	1	247	117	GI	Signal: Command Execution Supervision: Switching command executed successfully.
SG[2]	Interl OFF	1	247	118	GI	Signal: One or more IL_Off inputs are active.
SG[2]	Interl ON	1	247	119	GI	Signal: One or more IL_On inputs are active.
SG[2]	Ready	1	247	120	GI	Signal: Circuit breaker is ready for operation.
SG[3]	Removed-I	1	248	34	GI	State of the module input: The withdrawable circuit breaker is Removed
SG[3]	CES SG removed	1	248	35	GI	Signal: Command Execution Supervision: Switching Command unsuccessful, Switchgear removed.
SG[3]	Removed	1	248	36	GI	Signal: The withdrawable circuit breaker is Removed
SG[3]	SCmd OFF-I	1	248	110	GI	State of the module input: Switching OFF Command, e.g. the state of the Logics or the state of the digital input
SG[3]	SCmd ON-I	1	248	111	GI	State of the module input: Switching ON Command, e.g. the state of the Logics or the state of the digital input
SG[3]	Position Ind manipul	1	248	112	GI	Signal: Position Indicators faked
SG[3]	Prot ON	1	248	113	GI	Signal: ON Command issued by the Prot module
SG[3]	TripCmd	2	248	114		Signal: Trip Command

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SG[3]	OFF Cmd	1	248	115		Signal: OFF Command issued to the switchgear. Depending on the setting the signal may include the OFF command of the Prot module.
SG[3]	ON Cmd	1	248	116		Signal: ON Command issued to the switchgear. Depending on the setting the signal may include the ON command of the Prot module.
SG[3]	CES succesf	1	248	117	GI	Signal: Command Execution Supervision: Switching command executed successfully.
SG[3]	Interl OFF	1	248	118	GI	Signal: One or more IL_Off inputs are active.
SG[3]	Interl ON	1	248	119	GI	Signal: One or more IL_On inputs are active.
SG[3]	Ready	1	248	120	GI	Signal: Circuit breaker is ready for operation.
SG[4]	Removed-I	1	249	34	GI	State of the module input: The withdrawable circuit breaker is Removed
SG[4]	CES SG removed	1	249	35	GI	Signal: Command Execution Supervision: Switching Command unsuccessful, Switchgear removed.
SG[4]	Removed	1	249	36	GI	Signal: The withdrawable circuit breaker is Removed
SG[4]	SCmd OFF-I	1	249	110	GI	State of the module input: Switching OFF Command, e.g. the state of the Logics or the state of the digital input
SG[4]	SCmd ON-I	1	249	111	GI	State of the module input: Switching ON Command, e.g. the state of the Logics or the state of the digital input
SG[4]	Position Ind manipul	1	249	112	GI	Signal: Position Indicators faked

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SG[4]	Prot ON	1	249	113	GI	Signal: ON Command issued by the Prot module
SG[4]	TripCmd	2	249	114		Signal: Trip Command
SG[4]	OFF Cmd	1	249	115		Signal: OFF Command issued to the switchgear. Depending on the setting the signal may include the OFF command of the Prot module.
SG[4]	ON Cmd	1	249	116		Signal: ON Command issued to the switchgear. Depending on the setting the signal may include the ON command of the Prot module.
SG[4]	CES succesf	1	249	117	GI	Signal: Command Execution Supervision: Switching command executed successfully.
SG[4]	Interl OFF	1	249	118	GI	Signal: One or more IL_Off inputs are active.
SG[4]	Interl ON	1	249	119	GI	Signal: One or more IL_On inputs are active.
SG[4]	Ready	1	249	120	GI	Signal: Circuit breaker is ready for operation.
SG[5]	Removed-I	1	250	34	GI	State of the module input: The withdrawable circuit breaker is Removed
SG[5]	CES SG removed	1	250	35	GI	Signal: Command Execution Supervision: Switching Command unsuccessful, Switchgear removed.
SG[5]	Removed	1	250	36	GI	Signal: The withdrawable circuit breaker is Removed
SG[5]	SCmd OFF-I	1	250	110	GI	State of the module input: Switching OFF Command, e.g. the state of the Logics or the state of the digital input

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SG[5]	SCmd ON-I	1	250	111	GI	State of the module input: Switching ON Command, e.g. the state of the Logics or the state of the digital input
SG[5]	Position Ind manipul	1	250	112	GI	Signal: Position Indicators faked
SG[5]	Prot ON	1	250	113	GI	Signal: ON Command issued by the Prot module
SG[5]	TripCmd	2	250	114		Signal: Trip Command
SG[5]	OFF Cmd	1	250	115		Signal: OFF Command issued to the switchgear. Depending on the setting the signal may include the OFF command of the Prot module.
SG[5]	ON Cmd	1	250	116		Signal: ON Command issued to the switchgear. Depending on the setting the signal may include the ON command of the Prot module.
SG[5]	CES succesf	1	250	117	GI	Signal: Command Execution Supervision: Switching command executed successfully.
SG[5]	Interl OFF	1	250	118	GI	Signal: One or more IL_Off inputs are active.
SG[5]	Interl ON	1	250	119	GI	Signal: One or more IL_On inputs are active.
SG[5]	Ready	1	250	120	GI	Signal: Circuit breaker is ready for operation.
SG[6]	Removed-I	1	251	34	GI	State of the module input: The withdrawable circuit breaker is Removed
SG[6]	CES SG removed	1	251	35	GI	Signal: Command Execution Supervision: Switching Command unsuccessful, Switchgear removed.
SG[6]	Removed	1	251	36	GI	Signal: The withdrawable circuit breaker is Removed

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SG[6]	SCmd OFF-I	1	251	110	GI	State of the module input: Switching OFF Command, e.g. the state of the Logics or the state of the digital input
SG[6]	SCmd ON-I	1	251	111	GI	State of the module input: Switching ON Command, e.g. the state of the Logics or the state of the digital input
SG[6]	Position Ind manipul	1	251	112	GI	Signal: Position Indicators faked
SG[6]	Prot ON	1	251	113	GI	Signal: ON Command issued by the Prot module
SG[6]	TripCmd	2	251	114		Signal: Trip Command
SG[6]	OFF Cmd	1	251	115		Signal: OFF Command issued to the switchgear. Depending on the setting the signal may include the OFF command of the Prot module.
SG[6]	ON Cmd	1	251	116		Signal: ON Command issued to the switchgear. Depending on the setting the signal may include the ON command of the Prot module.
SG[6]	CES succesf	1	251	117	GI	Signal: Command Execution Supervision: Switching command executed successfully.
SG[6]	Interl OFF	1	251	118	GI	Signal: One or more IL_Off inputs are active.
SG[6]	Interl ON	1	251	119	GI	Signal: One or more IL_On inputs are active.
SG[6]	Ready	1	251	120	GI	Signal: Circuit breaker is ready for operation.
Scada Cmd	PS 1	1	178	23	GI	Signal: Parameter Set 1
Scada Cmd	PS 2	1	178	24	GI	Signal: Parameter Set 2
Scada Cmd	PS 3	1	178	25	GI	Signal: Parameter Set 3
Scada Cmd	PS 4	1	178	26	GI	Signal: Parameter Set 4

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SG[1]	Control/Position of circuit breaker	1	131	32	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[2]	Control/Position of circuit breaker	1	131	33	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[3]	Control/Position of circuit breaker	1	131	34	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[4]	Control/Position of circuit breaker	1	131	35	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[5]	Control/Position of circuit breaker	1	131	36	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[6]	Control/Position of circuit breaker	1	131	37	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).

Measuring Values

Module	Subgroup Names Functions	Function type ASDU	Function code (FUN)	Information Number (INF)	Factor	Position	Description
CT Ntrl	IL1 [%]	9	178	148	2.4	0	Measured value: Phase current (fundamental)
CT Ntrl	IL2 [%]	9	178	148	2.4	1	Measured value: Phase current (fundamental)
CT Ntrl	IL3 [%]	9	178	148	2.4	2	Measured value: Phase current (fundamental)
Voltage	VL1 [%]	9	178	148	2.4	3	Measured value: Phase-to-neutral voltage (fundamental)
Voltage	VL2 [%]	9	178	148	2.4	4	Measured value: Phase-to-neutral voltage (fundamental)
Voltage	VL3 [%]	9	178	148	2.4	5	Measured value: Phase-to-neutral voltage (fundamental)
PQSCr	P [%]	9	178	148	2.4	6	Measured value (calculated): Active power (P- = Fed Active Power, P+ = Consumed Active Power) (fundamental)
PQSCr	Q [%]	9	178	148	2.4	7	Measured value (calculated): Reactive power (Q- = Fed Reactive Power, Q+ = Consumed Reactive Power) (fundamental)

Data Points List

Module	Subgroup Names Functions	Function type ASDU	Function code (FUN)	Information Number (INF)	Factor	Position	Description
Voltage	f [%]	9	178	148	1.2	8	Measured value: Frequency
CT Ntrl	IL1 [%]	9	152	148	2.4	0	Measured value: Phase current (fundamental)
CT Ntrl	IL2 [%]	9	152	148	2.4	1	Measured value: Phase current (fundamental)
CT Ntrl	IL3 [%]	9	152	148	2.4	2	Measured value: Phase current (fundamental)
CT Ntrl	IG meas [%]	9	152	148	2.4	3	Measured value (measured): IG (fundamental)
Voltage	VL1 [%]	9	152	148	2.4	4	Measured value: Phase-to-neutral voltage (fundamental)
Voltage	VL2 [%]	9	152	148	2.4	5	Measured value: Phase-to-neutral voltage (fundamental)
Voltage	VL3 [%]	9	152	148	2.4	6	Measured value: Phase-to-neutral voltage (fundamental)
Voltage	VX meas [%]	9	152	148	2.4	7	Measured value (measured): VX measured (fundamental)
Voltage	VL12 [%]	9	152	148	2.4	8	Measured value: Phase-to-phase voltage (fundamental)
Voltage	VL23 [%]	9	152	148	2.4	9	Measured value: Phase-to-phase voltage (fundamental)

Data Points List

Module	Subgroup Names Functions	Function type ASDU	Function code (FUN)	Information Number (INF)	Factor	Position	Description
Voltage	VL31 [%]	9	152	148	2.4	10	Measured value: Phase-to-phase voltage (fundamental)
PQSCr	P [%]	9	152	148	2.4	11	Measured value (calculated): Active power (P- = Fed Active Power, P+ = Consumted Active Power) (fundamental)
PQSCr	Q [%]	9	152	148	2.4	12	Measured value (calculated): Reactive power (Q- = Fed Reactive Power, Q+ = Consumted Reactive Power) (fundamental)
PQSCr	cos phi [%]	9	152	148	1.0	13	Measured value (calculated): Power factor
Voltage	f [%]	9	152	148	1.2	14	Measured value: Frequency
CT Mains	IL1 [%]	9	152	148	2.4	15	Measured value: Phase current (fundamental)
CT Mains	IL2 [%]	9	152	148	2.4	16	Measured value: Phase current (fundamental)
CT Mains	IL3 [%]	9	152	148	2.4	17	Measured value: Phase current (fundamental)
CT Mains	IG meas [%]	9	152	148	2.4	18	Measured value (measured): IG (fundamental)

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
CT Ntrl	IL1	4	92	150		Measured value: Phase current (fundamental)
CT Ntrl	IL2	4	92	151		Measured value: Phase current (fundamental)
CT Ntrl	IL3	4	92	152		Measured value: Phase current (fundamental)
CT Mains	IL1	4	92	153		Measured value: Phase current (fundamental)
CT Mains	IL2	4	92	154		Measured value: Phase current (fundamental)
CT Mains	IL3	4	92	155		Measured value: Phase current (fundamental)
CT Ntrl	IG meas	4	92	186		Measured value (measured): IG (fundamental)
CT Mains	IG meas	4	92	187		Measured value (measured): IG (fundamental)
Voltage	VL12	4	92	190		Measured value: Phase-to-phase voltage (fundamental)
Voltage	VL23	4	92	191		Measured value: Phase-to-phase voltage (fundamental)
Voltage	VL31	4	92	192		Measured value: Phase-to-phase voltage (fundamental)
Voltage	VL1	4	92	193		Measured value: Phase-to-neutral voltage (fundamental)
Voltage	VL2	4	92	194		Measured value: Phase-to-neutral voltage (fundamental)

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Voltage	VL3	4	92	195		Measured value: Phase-to-neutral voltage (fundamental)
Voltage	VX meas	4	92	196		Measured value (measured): VX measured (fundamental)
Id	Id L1	4	93	150		Measured value (calculated): Differential Current Phase L1
Id	Id L2	4	93	151		Measured value (calculated): Differential Current Phase L2
Id	Id L3	4	93	152		Measured value (calculated): Differential Current Phase L3
Id	IS L1	4	93	153		Measured value (calculated): Restraint Current Phase L1
Id	IS L2	4	93	154		Measured value (calculated): Restraint Current Phase L2
Id	IS L3	4	93	155		Measured value (calculated): Restraint Current Phase L3

Commands

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
Scada Cmd	Ack LED	20	178	19		Signal: LEDs acknowledgement
Scada Cmd	PS 1	1	178	23	GI	Signal: Parameter Set 1
Scada Cmd	PS 2	1	178	24	GI	Signal: Parameter Set 2
Scada Cmd	PS 3	1	178	25	GI	Signal: Parameter Set 3
Scada Cmd	PS 4	1	178	26	GI	Signal: Parameter Set 4
Scada Cmd	Scada Cmd 1	20	130	15		Scada Command
Scada Cmd	Scada Cmd 2	20	130	16		Scada Command
Scada Cmd	Scada Cmd 3	20	130	17		Scada Command
Scada Cmd	Scada Cmd 4	20	130	18		Scada Command
Scada Cmd	Scada Cmd 5	20	130	19		Scada Command
Scada Cmd	Scada Cmd 6	20	130	20		Scada Command
Scada Cmd	Scada Cmd 7	20	130	21		Scada Command
Scada Cmd	Scada Cmd 8	20	130	22		Scada Command
Scada Cmd	Scada Cmd 9	20	130	23		Scada Command
Scada Cmd	Scada Cmd 10	20	130	24		Scada Command
Scada Cmd	Ack BO	20	130	40		Signal: Acknowledgement of the Binary Outputs
Scada Cmd	Ack TripCmd	20	130	41		Signal: Reset Trip Command
SG[1]	Control/Position of circuit breaker	1	131	32	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).

Data Points List

Module	Subgroups Names Functions	Function Type ASDU	Function (FUN)	Information Number (INF)	Device Interrogation	Description
SG[2]	Control/Position of circuit breaker	1	131	33	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[3]	Control/Position of circuit breaker	1	131	34	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[4]	Control/Position of circuit breaker	1	131	35	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[5]	Control/Position of circuit breaker	1	131	36	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).
SG[6]	Control/Position of circuit breaker	1	131	37	GI	Control respectively Position of circuit breaker (1 = OFF, 2 = On).

Analog Traces

Module	IEC60870-5-103 Channel Number	Desc
I L1	70	Analog trace I L1
I L2	71	Analog trace I L2
I L3	72	Analog trace I L3
IG	73	Analog trace IG
I L1	74	Analog trace I L1
I L2	75	Analog trace I L2
I L3	76	Analog trace I L3
IG	77	Analog trace IG
W1.Idg	78	Winding 1.Measured value (calculated): Ground Differential Current
W2.Idg	79	Winding 2.Measured value (calculated): Ground Differential Current
Id L1	80	Measured value (calculated): Differential Current Phase L1
Id L2	81	Measured value (calculated): Differential Current Phase L2
Id L3	82	Measured value (calculated): Differential Current Phase L3
W1.ISG	83	Winding 1.Measured value (calculated): Ground Stabilizing Current
W2.ISG	84	Winding 2.Measured value (calculated): Ground Stabilizing Current
IS L1	85	Measured value (calculated): Restraint Current Phase L1
IS L2	86	Measured value (calculated): Restraint Current Phase L2
IS L3	87	Measured value (calculated): Restraint Current Phase L3
V L1 / V L12	88	Analog trace V L1 / V L12
V L2 / V L23	89	Analog trace V L2 / V L23
V L3 / V L31	90	Analog trace V L3 / V L31

Data Points List

Module	IEC60870-5-103 Channel Number	Desc
VX	91	Analog trace VX

We appreciate your comments about the content of our publications.

Please send comments to: kemp.doc@woodward.com

Please include the manual number from the front cover of this publication.

Woodward Kempen GmbH reserves the right to update any portion of this publication at any time. Information provided by Woodward Kempen GmbH is believed to be correct and reliable. However, Woodward Kempen GmbH assumes no responsibility unless otherwise expressly undertaken.
© Woodward Kempen GmbH, all rights reserved



Woodward Kempen GmbH

Krefelder Weg 47 xD – 47906 Kempen (Germany)
Postfach 10 07 55 (P.O.Box) xD – 47884 Kempen (Germany)
Phone: +49 (0) 21 52 145 1

Internet

www.woodward.com

Sales

Phone: +49 (0) 21 52 145 216 or 342
Fax: +49 (0) 21 52 145 354
e-mail: salesEMEA_PGD@woodward.com

Service

Phone: +49 (0) 21 52 145 614
Fax: +49 (0) 21 52 145 455
e-mail: supportEMEA_PGD@woodward.com