


DX - Start Module for the Engine Supervision Unit DU2



Contents

- 1 General
- 2 Mode of Operation
- 3 Putting into Operation
- 4 Technical Data
- 5 Order form

1 General

When using unit DU2 with the additional module DX automatic starts and stops of engines are possible.

Module *DX* receives, for instance, the external start signal from a voltage supervision unit that notices an undervoltage. After reaching the rated voltage again, the engine is stopped automatically.

At any time, module *DX* can easily be retrofitted for such automatic starts.

On the rear cover of supervision unit DU are explanations for adjusting and coding of the additional module.

2 Mode of Operation

If terminals B1 and B2 (see fig. 2) are closed by an external contact (e.g. from a voltage supervision unit) an automatic start is initiated: The relay between terminals B3 and B4 operates, the engine is preheated, the supervision unit **DU2** is activated.

Depending on the coding of module DX up to 6 starts are possible. Preglowing time, starting time and start interval can be set by spindle potentiometers between 3 s and 30 s.

Relay "preglowing" (see fig. 2) remains activated during the whole starting process.

When module *DX* is used, signal "start failure" is always signal no. 3 at the supervision unit *DU2*.

If the engine is started automatically by module *DX* the LED at push button "I" of unit *DU* lights during the starting process until the signal "engine running" is received. During this time the function of push button "I" is blocked. Cranking into a running engine is not possible.

The engine is stopped automatically by opening the external contact between terminals B1 and B2 or manually by pressing push button "O" of supervision unit DU.




Fig. 1: Mechanical design of supervision unit DU with module DX

3 Putting into Operation

Mounting and Connecting Module DX to the Supervision Unit DU

The module *DX* can either be supplied mounted on the supervision unit *DU* or supplied for retrofitting, which is quite simple (see fig. 1). A ribbon cable connects the *DU* supervision unit to the *DX* module.

Adjusting the DX Module

Preglowing time, starting time and start interval can be adjusted between 3 s and 30 s by three potentiometers

Coding the Supervision Unit DU when Using the Module DX

If a *DX* module is used the first free available error signal of the supervision unit *DU* (signal no. 3) must be the signal "start failure". Therefore a code plug must be inserted on position 3a of the code strip of function unit *DU*. This signal no. 3 must be programmed as "shut down". Further code plugs for the 3rd error signal are not necessary.

Coding the DX Module

At the code plug in the middle of the *DX* PCB the number of start repetitions can be coded.

1 start	plug at position B
2 starts	plug at position A
3 starts	plug at B and C
4 starts	plug at A and C
5 starts	plug at B and D
6 starts	plug at A and D

Example: Plugs inserted for 4 starts






Fig. 2: Connection diagram




Fig. 3: Back panel

4 Technical Data

General Data

Construction: extension printed circuit board for the DU2

Maintenance: maintenance-free

Mounting position:

Attachment:

Codes:

fixed by mounting on DU supervision unit
by screws, fixing materials are supplied
1 code strip to select start repetitions

Adjustments:

1 potentiometer each for adjusting preglowing time, starting time and start interval between 3 s and 30 s

Dimensions of DU2-Supervision

Unit after mounting of the

DX Module: height x width x depth = $96 \times 214 \times 80 \text{ mm}$

Notes: Since the DX Start Module is an additional board for the DU2, all

other specifications, e.g. tests, protection classes, etc. are identical

to the DU2 (see description of DU2, Technical Data).

5 Order form

Please use the form on this page to order preadjusted/coded start modules.

If modules are ordered without giving details of coding, they will be supplied with standard settings.

Start module		DX			
Number					
Coding:					
Required number Standard					
Adjustments					
Time	Range	standard	required time		
Preglowing time	3s - 30s	5s			
Starting time	3s - 30s	10s			
Start interval	3s - 30s	5s			



Woodward Kempen GmbH

Krefelder Weg 47 · D – 47906 Kempen (Germany)
Postfach 10 07 55 (P.O.Box) · D – 47884 Kempen (Germany)
Phone: +49 (0) 21 52 145 1

Internet

www.woodward.com

Sales

Phone: +49 (0) 21 52 145 216 or 342 · Telefax: +49 (0) 21 52 145 354 e-mail: salesEMEA_PGD@woodward.com

Service

Phone: +49 (0) 21 52 145 614 · Telefax: +49 (0) 21 52 145 455 e-mail: SupportEMEA_PGD@woodward.com