


WI Line

WIC1

SELF-/DUAL POWERED PROTECTION DEVICE

- WIC1-1 | Self-powered device, parameter settings via DiggiMEC / Smart view
- WIC1-2 | Self-powered device, parameter settings via DIP switches and/or DiggiMEC / Smart view
- WIC1-3 | Self-powered device, parameter settings via HEX switches and/or DiggiMEC / Smart view
- WIC1-4 | Dual-powered device, parameter settings via DiggiMEC / Smart view



SELF-/DUAL POWERED PROTECTION DEVICE

Version: 1.0


Original document

English

WIRING DIAGRAMS

This document does not replace the Technical Manual.

WIC1-1SN0NN1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NN1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NN1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NN2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NN2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NN2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NF1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NF1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NF1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NF2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NF2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NF2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NC1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NC1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NC1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NC2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NC2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0NC2PA



CT-Powered Protection Device, configuration via DigiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FN1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FN1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FN1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FN2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FN2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FN2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FF1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FF1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FF1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FF2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FF2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FF2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FC1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FC1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FC1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FC2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FC2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0FC2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CN1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CN1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CN1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CN2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CN2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CN2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CF1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CF1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CF1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CF2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CF2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CF2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CC1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CC1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CC1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CC2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CC2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SN0CC2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NN1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NN1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NN1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NN2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NN2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NN2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NF1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NF1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NF1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NF2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NF2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NF2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NC1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NC1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NC1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NC2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NC2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0NC2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FN1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FN1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FN1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FN2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FN2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FN2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FF1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FF1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FF1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FF2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FF2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FF2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FC1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FC1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FC1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FC2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FC2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0FC2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CN1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CN1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CN1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CN2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CN2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CN2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CF1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CF1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CF1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CF2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CF2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at 20·In,max
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CF2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CC1SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CC1AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CC1PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CC2SA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CC2AA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-1SG0CC2PA



CT-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5NC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5FC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN5CC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6NC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6FC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SN6CC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5NC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5FC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG5CC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6NC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6FC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CN1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CN1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CN1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CN2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CN2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CN2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CF1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CF1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CF1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CF2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CF2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CF2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CC1SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CC1AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CC1PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CC2SA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CC2AA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-2SG6CC2PA



CT-Powered Protection Device, configuration via DIP switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5NC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5FC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN5CC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection


PE - Protective Earth

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6NC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6FC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SN6CC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Calculated earth current
- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5NC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FF2PA



CT-Powered Protection Device, configuration via HEX switches or DigiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DigiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DigiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FC2SA



CT-Powered Protection Device, configuration via HEX switches or DigiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DigiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DigiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5FC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG5CC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 50 Hz. (Setting to 60 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NN1SA



CT-Powered Protection Device, configuration via HEX switches or DigiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DigiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DigiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth


X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6NC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6FC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Trip flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CN1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CN1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CN1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CN2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CN2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CN2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)


X1...X3 - WIC CTs

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CF1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CF1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CF1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CF2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CF2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CF2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - DI2, fixed to External trip input (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CC1SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CC1AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CC1PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CC2SA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CC2AA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-3SG6CC2PA



CT-Powered Protection Device, configuration via HEX switches or DiggiMEC / Smart view

- Nominal frequency is 60 Hz. (Setting to 50 Hz is possible via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground current via 1A CT input. (Setting to calc. IG is also possible via DiggiMEC/Smart view.)

X1...X3 - WIC CTs


X4-2,3 - 1 assignable Digital Input DI2 (115Vac or 230Vac)

X4-5,6 - Assignable flag indicator

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NM1SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NM1AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NM1PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE – Protective Earth

X0 – Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 – WIC CTs


X4-3,4 – Dual Power (Optional auxiliary power supply)

X4-5,6 – Output, optional use for self-supervision signaling

X4-7,8 – Trip pulse output

X5 – DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NM2SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NM2AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NM2PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NG1SA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NG1AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NG1PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NG2SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NG2AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0NG2PA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0ND1SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0ND1AA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0ND1PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0ND2SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0ND2AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0ND2PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FM1SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FM1AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FM1PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FM2SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FM2AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FM2PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE – Protective Earth

X0 – Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 – WIC CTs


X4-3,4 – Dual Power (Optional auxiliary power supply)

X4-5,6 – Trip flag indicator, optional use for self-supervision signaling

X4-7,8 – Trip pulse output

X5 – DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FG1SA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FG1AA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FG1PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FG2SA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FG2AA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FG2PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FD1SA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FD1AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FD1PA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FD2SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FD2AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0FD2PA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Trip flag indicator, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CM1SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CM1AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CM1PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE – Protective Earth

X0 – Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 – WIC CTs


X4-3,4 – Dual Power (Optional auxiliary power supply)

X4-5,6 – Configurable Output, optional use for self-supervision signaling

X4-7,8 – Trip pulse output

X5 – DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CM2SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CM2AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CM2PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CG1SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CG1AA



Dual-Powered Protection Device, configuration via DigiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DigiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DigiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CG1PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CG2SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CG2AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CG2PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - Digital Inputs, fixed to: DI1=ext. reset, DI2=ext. trip


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CD1SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CD1AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CD1PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Backup protection operates directly
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CD2SA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CD2AA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs


X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

WIC1-4SG0CD2PA



Dual-Powered Protection Device, configuration via DiggiMEC / Smart view

- Nominal frequency is 50 Hz or 60 Hz. (Setting via DiggiMEC/Smart view.)
- Trip at $20 \cdot I_{n,max}$
- ANSI 50, 50G/N, 51, 51G/N, inrush, 46, 51Q, 49, 50BF, 74TC, SOTF, ultra-fast overcurrent protection

PE - Protective Earth

X0 - Measured ground (earth) current via 1 A CT input. (Calc. IG is also possible.)

X1...X3 - WIC CTs

X4-1,2 - 2 assignable Digital Inputs

X4-3,4 - Dual Power (Optional auxiliary power supply)

X4-5,6 - Configurable Output, optional use for self-supervision signaling

X4-7,8 - Trip pulse output

X5 - DiggiMEC-WIC1 connection. Use network cable CAT3 (or better). No crossover cable!

Appendix – Legend

In this legend designations of various device types are listed, e.g. transformer protection, motor protection, generator protection, etc. Therefore it can occur that not every designation actually appears on the wiring diagram of your device.


PE	– Connection of protective earth (see chapter Grounding in the Technical Manual).
FE	– Connection of functional earth (see chapter Grounding in the Technical Manual).
Power Supply	– Connection for auxiliary power supply.
IL1	– Phase current input L1 (in some countries designated as IA).
IL2	– Phase current input L2 (in some countries designated as IB).
IL3	– Phase current input L3 (in some countries designated as IC).
ILx C–D	– WIC1 Test windings.
ILx 1S1–1S2, 2S1–2S2	– WIC1 phase current inputs.
IL1 W1 ... IL3 W1	– Phase current input L1...L3, winding side 1.
IL1 W2 ... IL3 W2	– Phase current input L1...L3, winding side 2.
IG	– Ground (earth) current input.
IG W1, IG W2	– Ground (earth) current input, winding side 1 / 2.
VL1	– Phase-to-neutral voltage L1 (in some countries designated as VA).
VL2	– Phase-to-neutral voltage L2 (in some countries designated as VB).
VL3	– Phase-to-neutral voltage L3 (in some countries designated as VC).
VL12	– Phase-to-phase voltage V12 (in some countries designated as VAB).
VL23	– Phase-to-phase voltage V23 (in some countries designated as VBC).
VL31	– Phase-to-phase voltage V31 (in some countries designated as VCA).
VX	– 4th voltage measuring input for measuring residual voltage or synchro-check.
BO	– Binary output relay.
NO / NC	– Contact output, normally open (Form A) / closed (Form B).
DI	– Digital input.
COM	– Common connection of digital inputs.
Out+, AnOut	– Analog output + (0/4...20 mA or 0...10 V).
In–, AnIn	– Analog input + (0/4...20 mA or 0...10 V).
n.c.	– Not connected.
DO NOT USE	– Do not use. (Caution: Non-usable internal wiring may exist.)
SC	– Self-supervision contact.
HF SHIELD	– Connection cable shield.
Fiber Optics / LWL	– Fiber optic connection.

WI Line

WIC1

WIRING DIAGRAMS

docs.SEGelectronics.de/wic1



SEG Electronics GmbH reserves the right to update any portion of this publication at any time.
Information provided by SEG Electronics GmbH is believed to be correct and reliable.
However, SEG Electronics GmbH assumes no responsibility unless otherwise expressly undertaken.



SEG Electronics GmbH
Krefelder Weg 47 • D-47906 Kempen (Germany)
Telephone: +49 (0) 21 52 145 1
Internet: www.SEGelectronics.de

Sales

Telephone: +49 (0) 21 52 145 331
Fax: +49 (0) 21 52 145 354
E-mail: sales@SEGelectronics.de

Service

Telephone: +49 (0) 21 52 145 600
Fax: +49 (0) 21 52 145 354
E-mail: support@SEGelectronics.de

Complete address / phone / fax / email information for all locations is available on our website.